

[manuals.plus](#) /› [OLV](#) /› **OLV D27 Portable Neck Fan User Manual - 6000mAh Rechargeable, 3-Speed Cooling**

OLV D27

OLV D27 Portable Neck Fan User Manual

Model: D27

INTRODUCTION

The OLV D27 Portable Neck Fan provides personal cooling with its innovative design and powerful features. This manual will guide you through the setup, operation, and maintenance of your device to ensure optimal performance and longevity.

Key features include a 6000mAh rechargeable battery offering up to 18 hours of use, 3 adjustable fan speeds with 360° cooling airflow from 4 turbine motors, and a lightweight, foldable design for portability. It operates quietly at just 35dB on low speed.

IMPORTANT SAFETY INFORMATION

- Do not put your fingers or foreign objects into the fan blades.
- Keep the device away from water and excessive moisture.
- Do not disassemble or attempt to repair the device yourself. Contact customer support if issues arise.
- Keep out of reach of children under 14 years old.
- Use only the provided USB-C charging cable or a certified equivalent.
- Avoid exposing the device to extreme temperatures or direct sunlight for prolonged periods.

PACKAGE CONTENTS

Verify that all items are present in your package:

- OLV D27 Portable Neck Fan
- USB-C Charging Cable
- User Manual (this document)



Image: The OLV D27 Portable Neck Fan, USB-C charging cable, and user manual laid out on a surface.

SETUP

1. Initial Charging

Before first use, fully charge your OLV D27 Neck Fan.

1. Locate the USB-C charging port on the side of the fan.
2. Connect the provided USB-C cable to the fan and the other end to a compatible USB power source (e.g., wall adapter, computer USB port).
3. The indicator light will show charging status (e.g., red for charging, green for fully charged). A full charge typically takes approximately 3 hours.



Cooking

Working

Running

Climbing

Image: A close-up of the OLV D27 Neck Fan being charged via its USB-C port.

2. Unfolding and Wearing

The fan features a foldable design for easy storage and transport.

1. Gently unfold the fan until it forms a U-shape.
2. Place the fan around your neck, ensuring the air vents are positioned to direct airflow towards your face and neck. The flexible design allows for comfortable adjustment.

Max Long-Lasting Battery Capacity

8-18 Hours

Battery Life

6000 mAh

Large Capacity

+90%

Cooling Airflow



Image: A person wearing the OLV D27 Neck Fan, demonstrating its ergonomic fit around the neck.

OPERATING INSTRUCTIONS

1. Power On/Off

- To turn on the fan, press and hold the power button located on the side of the device for 2 seconds.
- To turn off the fan, press and hold the power button again for 2 seconds.

2. Adjusting Fan Speed

The OLV D27 Neck Fan offers 3 adjustable fan speeds:

1. With the fan powered on, press the power button once to cycle through the speed settings.
2. **First Press:** Low Speed (gentle breeze, up to 18 hours battery life).
3. **Second Press:** Medium Speed (moderate airflow, up to 13 hours battery life).
4. **Third Press:** High Speed (powerful airflow, up to 8 hours battery life).
5. **Fourth Press:** Turns the fan off.

Quad-Turbo Make the Cooling Gale

Ultra-strong motor running enhanced ice cool airflow



Image: A detailed view of the power button and air vents on the OLV D27 Neck Fan.

3. Cooling Plates

The fan is equipped with two cooling plates located at the back, designed to provide additional cooling sensation against your neck.

MAINTENANCE

1. Cleaning

- Wipe the sweat-resistant surface of the fan with a soft, damp cloth.
- Do not use abrasive cleaners or immerse the device in water.
- Ensure the air vents are clear of dust and debris for optimal airflow. Use a soft brush or compressed air if necessary.

2. Storage

- When not in use, fold the fan for compact storage.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---|---|---|
| Fan does not turn on. | Battery is depleted. | Charge the fan fully using the provided USB-C cable. |
| Weak or no airflow. | Air vents are blocked; fan speed is too low. | Clear any obstructions from the vents. Increase the fan speed by pressing the power button. |
| Fan stops working shortly after charging. | Battery not holding charge; charging port damage. | Ensure the charging cable is securely connected. If the issue persists, contact customer support. |
| Noise level is too high. | Fan is on a higher speed setting. | Reduce the fan speed to a lower setting. The fan operates at 35dB on low speed. |

SPECIFICATIONS

| Feature | Detail |
|------------------------|--|
| Brand | OLV |
| Model Name | D27 |
| Electric Fan Design | Wearable Fan |
| Power Source | Battery Powered |
| Battery Capacity | 6000mAh |
| Battery Life (Max) | 18 hours (on 1st gear) |
| Number of Power Levels | 3 |
| Noise Level | 35 Decibels (on low speed) |
| Special Feature | 6000mAh Large Battery, Foldable Design, Four turbine motors |
| Control Method | Touch |
| Item Weight | 0.35 Kilograms (12.3 ounces) |
| Product Dimensions | 1"D x 1"W x 1"H (Note: These dimensions seem generic and might not reflect actual size when unfolded/worn) |

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official OLV website. Keep your purchase receipt for warranty claims.

PRODUCT VIDEOS

Your browser does not support the video tag.

Video: An overview of the OLV Neck Fan's features, including its 6000mAh battery and portability.

Your browser does not support the video tag.

Video: A demonstration of the OLV Neck Fan's 6000mAh rechargeable battery and its usage.

© 2025 OLV. All rights reserved.