

Replacement Remote Control for Veatool S50L Soundbar

User Manual: Replacement Remote Control

For Veatool S50L 100W 2.2ch Sound Bars

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your replacement infrared (IR) remote control for Veatool S50L 100W 2.2ch Sound Bars. This remote is designed to function as a direct replacement for your original remote. Please ensure your original remote matches the appearance of this replacement for full compatibility.



Image: Front view of the replacement remote control, showing all buttons clearly. The remote is black with grey buttons.

SETUP

Battery Installation

The remote control requires two (2) AAA batteries (not included). Follow these steps to install the batteries:

- 1. Locate the battery compartment on the back of the remote control.
- 2. Press down on the tab and slide the battery cover downwards to open it.
- 3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
- 4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the remote control with the battery cover removed, illustrating the correct orientation for AAA battery insertion.

Important: Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries.

OPERATING INSTRUCTIONS

This remote control is pre-programmed and requires no setup or programming. Simply point the remote directly at your Veatool S50L Sound Bar to operate it.

Button Functions

Button	Function
--------	----------

Button	Function
Power (Red Circle)	Turns the soundbar On or Off.
Mute (Green Speaker with X)	Mutes or unmutes the sound.
TREBLE+ / TREBLE-	Adjusts the treble level up or down.
BASS+ / BASS-	Adjusts the bass level up or down.
Volume Up (+) / Volume Down (-)	Increases or decreases the master volume.
Play/Pause (▶)	Plays or pauses media playback.
Previous Track (◀◀)	Skips to the previous track.
Next Track (▶▶)	Skips to the next track.
MODE	Cycles through available input modes (e.g., AUX, OPT, BT, USB, HDMI ARC).
AUX	Selects Auxiliary input.
OPT	Selects Optical input.
BT	Selects Bluetooth input.
USB	Selects USB input.
HDMI ARC	Selects HDMI ARC input.
EQ	Cycles through equalizer presets.
3D	Activates or deactivates 3D sound mode.
Loop/Repeat (Arrow Circle)	Controls playback repeat functions (e.g., repeat one, repeat all).

MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's range decreases or it becomes unresponsive. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as internal components can be damaged.

TROUBLESHOOTING

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote Not Responding:**
 - Ensure batteries are inserted correctly with the correct polarity (+/-).
 - Replace old batteries with new ones.
 - Make sure there are no obstructions between the remote control and the soundbar's IR receiver.
 - Ensure you are within the effective operating range of the soundbar.

- **Specific Functions Not Working:**
 - Verify that your soundbar model (Veatool S50L) is compatible with this replacement remote. This remote is an IR replacement and may not have all functions identical to your original remote if it was a different type (e.g., RF).
 - Refer to your soundbar's original manual for specific functions or settings that might require interaction directly on the soundbar unit.
- **Remote Appears Different from Original:**
 - This is a replacement remote. While designed for compatibility, its physical appearance or button layout may differ slightly from your original remote. Functionality for the specified soundbar model should remain.

If the issue persists after trying these steps, please contact the seller for further assistance.



SPECIFICATIONS





- **Product Type:** Infrared (IR) Replacement Remote Control
- **Compatible Devices:** Veatool S50L 100W 2.2ch Sound Bars (Home Theater Systems)
- **Power Source:** 2 x AAA Batteries (not included)
- **Color:** Black
- **Max Number of Supported Devices:** 1
- **Manufacturer:** Easytry

WARRANTY AND SUPPORT

Specific warranty information for this replacement remote control is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to the purchase documentation or contact the seller directly through the platform where the product was purchased.

Related Documents - Replacement Remote Control for Veatool S50L Soundbar

	<p>Denon DHT-S217 Dolby Atmos Sound Bar Owner's Manual</p> <p>Comprehensive owner's manual for the Denon DHT-S217 Dolby Atmos 2.1 Sound Bar. Learn about setup, connections, playback modes, settings, troubleshooting, and specifications for an enhanced home audio experience.</p>
	<p>LG SC9S Wi-Fi Sound Bar Owner's Manual</p> <p>Comprehensive owner's manual for the LG SC9S Wi-Fi Sound Bar, detailing installation, setup, features, connectivity options, and troubleshooting. Learn how to enhance your home audio experience.</p>

 <p>The image shows the cover of the GEOYEAO BT103 Soundbar User Manual. It features a black soundbar and two black satellite speakers. The text 'USER MANUAL' and 'Model: BT103' is visible at the bottom.</p>	<p>GEOYEAO BT103 Soundbar User Manual</p> <p>Comprehensive user manual for the GEOYEAO BT103 Soundbar, covering features, safety information, installation, connections, remote control, troubleshooting, and product specifications.</p>
 <p>The image shows the cover of the LG SK9Y Wi-Fi Sound Bar - Simple Manual. It features a black soundbar and a subwoofer. The text 'LG SK9Y' and 'Wi-Fi Sound Bar' is visible.</p>	<p>LG SK9Y Wi-Fi Sound Bar - Simple Manual</p> <p>User manual for the LG SK9Y Wi-Fi Sound Bar, covering setup, connections (Wi-Fi, TV, Subwoofer), remote control functions, specifications, and FCC compliance.</p>
 <p>The image shows the cover of the WOHOME S9920 Wireless Sound Bar User Manual. It features a black soundbar and a subwoofer. The text 'WOHOME S9920' is visible.</p>	<p>WOHOME S9920 Wireless Sound Bar User Manual</p> <p>User manual for the WOHOME S9920 Wireless Sound Bar, covering safety instructions, component checking, product overview, connection methods (Optical, ARC, AUX, USB, Bluetooth), wall installation, remote control guide, troubleshooting, and specifications.</p>
 <p>The image shows the cover of the Polk MagniFi Soundbar Setup Guide and Product Information. It features a brown background with the Polk logo and the text 'magniFi soundbar'.</p>	<p>Polk MagniFi Soundbar Setup Guide and Product Information</p> <p>Comprehensive setup guide and product information for the Polk MagniFi Voice-optimizing Wireless Sound Bar System, including connection instructions, remote control details, safety precautions, and troubleshooting.</p>