ZdalaMit Midea Duo

ZdalaMit Replacement Remote Control User Manual

For Midea Duo Inverter Portable Air Conditioners

Introduction

This manual provides instructions for the ZdalaMit Replacement Remote Control, designed for use with various Midea Duo Inverter Portable Air Conditioner models. Please read this manual thoroughly before using the remote control to ensure proper operation and longevity.

Product Overview



Figure 1: Front view of the remote control, displaying the screen and button layout.



Figure 2: Angled view of the remote control, showing its profile and button arrangement.



Figure 3: Second angled view of the remote control, offering a comprehensive look at its design.



Figure 4: Front view with approximate dimensions: 7.6 inches (length) by 2.0 inches (width).

Setup

Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two (2) 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

Note: Batteries are not included with the remote control. Always use new alkaline batteries for optimal performance.

Operating Instructions

This replacement remote control is pre-programmed and requires no additional setup for compatible Midea Duo Inverter Portable Air Conditioners. Simply install batteries, and it is ready for use.

Compatibility

This remote control is compatible with Midea Duo Inverter Portable Air Conditioner models including:

- Duo 12,000 BTU
- Duo 8,000 BTU
- Duo 8,500 BTU
- Duo 10,000 BTU
- Duo 14,000 BTU

Key Functions

The remote control features standard functions for operating your Midea Duo air conditioner. Refer to your air conditioner's original manual for specific function details if needed.

- **Power Button** ( ): Turns the air conditioner on or off.
- **Mode Button**: Cycles through operating modes (e.g., Cool, Fan, Dry, Heat).
- **Eco Gear Button** (**eco gear**): Activates or deactivates the energy-saving mode.
- **Temperature Adjustment Buttons** (⌃ / ⌄): Adjusts the desired temperature.
- **SET Button**: Used for setting specific parameters or entering menus.
- **OK Button**: Confirms selections.
- **Timer Button** ( ): Sets or cancels the timer function.
- **Fan Speed Button** (☯): Adjusts the fan speed.
- **Swing Button**: Controls the louver swing function.
- **Sleep Mode Button** (♂): Activates or deactivates sleep mode.
- **Boost Button**: Engages a rapid cooling or heating function.
- **LED Button**: Controls the display light on the air conditioner unit.
- **Clean Button**: Initiates the self-clean function (if available on your AC model).

Note: The remote control displays temperature readings in Celsius only.

Maintenance

Cleaning the Remote Control

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these may damage the remote.

Battery Replacement

Replace batteries when the remote control's range decreases or if the display becomes dim. Always replace both batteries simultaneously with new 1.5V AAA alkaline batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Confirm the remote is pointed directly at the air conditioner unit.

- **Air conditioner not responding to specific functions:**
  - Verify that your Midea Duo model supports the specific function you are trying to use.
  - Some functions may require specific operating conditions (e.g., a "Clean" cycle might only run when the unit is off).
- **Temperature displays in Celsius only:**
  - This remote control is designed to display temperature in Celsius only. There is no option to switch to Fahrenheit.

Specifications

Feature	Detail
Brand	ZdalaMit
Model Compatibility	Midea Duo Inverter Portable Air Conditioners (8,000 BTU, 8,500 BTU, 10,000 BTU, 12,000 BTU, 14,000 BTU)
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Display Unit	Celsius only
Dimensions (L x W x H)	7.74 x 1.99 x 0.55 inches (approx. 19.66 x 5.05 x 1.40 cm)
Item Weight	1.41 ounces (approx. 40 grams)
Special Feature	Pre-programmed, no setup required

© 2025 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question