

BoxWave FineTouch Capacitive Stylus

BoxWave FineTouch Capacitive Stylus Instruction Manual

Model: FineTouch Capacitive Stylus | Brand: BoxWave

1. INTRODUCTION


Thank you for choosing the BoxWave FineTouch Capacitive Stylus. This manual provides essential information for the proper setup, operation, and maintenance of your stylus, ensuring optimal performance and longevity. Designed for precision and ease of use, this stylus enhances your interaction with compatible capacitive touchscreens.

2. PRODUCT OVERVIEW

The BoxWave FineTouch Capacitive Stylus is a versatile and precise tool for navigating, writing, and drawing on capacitive touchscreens. Its innovative design focuses on accuracy and user comfort.

Key Features:

- **Versatile and Universal Compatibility:** Works with a wide range of capacitive touchscreens, including Displays2Go DW032TLB (32 in).
- **Innovative Clear Tip:** The transparent disc tip allows for enhanced precision, enabling you to see exactly where your input is being registered.
- **Effortless Operation:** No Bluetooth pairing or complex setup required. Simply touch the tip to the screen to begin use.
- **Integrated Metal Clip:** Conveniently attach the stylus to your clothing, case, or notebook for easy portability.
- **Compact and Ergonomic Design:** Designed in a pen form factor, it fits comfortably in hand and is easy to carry.
- **Lightweight Construction:** Made with sturdy aluminum, providing a natural and comfortable writing experience.



BOXWAVE

Clear Disc Tip

See every detail unobscured
and with full clarity.

Image: Visual representation of the stylus emphasizing its key attributes: clear disc tip, accuracy, and lightweight design.

Ultra Accurate & Responsive



Image: Detailed view of the stylus's clear disc tip, designed for precise interaction with touchscreens.

3. SETUP

The BoxWave FineTouch Capacitive Stylus is designed for immediate use with no complicated setup procedures.

1. **Uncap the Stylus:** Gently remove the threaded cap from the stylus tip.
2. **No Pairing Required:** The stylus does not require Bluetooth pairing or any software installation. It functions directly upon contact with a capacitive touchscreen.

Feather Light

FineTouch Capacitive Stylus is lightweight and feels natural to write with.



Image: The stylus with its protective threaded cap removed, illustrating the simple preparation for use.

4. OPERATING INSTRUCTIONS

Using your BoxWave FineTouch Capacitive Stylus is intuitive and similar to using your finger, but with enhanced precision.

1. **Hold the Stylus:** Hold the stylus as you would a regular pen or pencil.
2. **Touch the Screen:** Gently touch the clear disc tip against the capacitive touchscreen surface. The stylus will register your input.
3. **Navigate and Interact:** Use the stylus to tap, swipe, draw, or write on your device's screen. The clear disc allows you to see precisely where your input is being made.




Image: A user demonstrating the natural and precise interaction with a tablet using the BoxWave FineTouch Capacitive Stylus.



Threaded Cap

Protects FinePoint Stylus Tip

Image: The stylus in action, illustrating how the clear disc tip provides an unobstructed view of the contact point for accurate drawing and writing.

Important Note: The FineTouch Capacitive Stylus does not support advanced features such as Palm Rejection or Pressure Sensitivity. It simulates a finger touch for universal compatibility.

5. MAINTENANCE

To ensure the longevity and optimal performance of your BoxWave FineTouch Capacitive Stylus, follow these simple maintenance guidelines:

- **Keep the Tip Clean:** Periodically wipe the clear disc tip with a soft, lint-free cloth to remove any dust or smudges that may affect responsiveness.
- **Protect the Tip:** Always replace the threaded cap when the stylus is not in use to protect the delicate clear disc tip from damage.
- **Avoid Extreme Conditions:** Do not expose the stylus to extreme temperatures, direct sunlight for prolonged periods, or harsh chemicals.
- **Store Safely:** Store the stylus in a safe place where it will not be bent, dropped, or come into contact with sharp

objects.

6. TROUBLESHOOTING

If you experience issues with your BoxWave FineTouch Capacitive Stylus, please refer to the following common solutions:

Problem	Possible Cause	Solution
Stylus not responding or inconsistent response.	Dirty or damaged clear disc tip; screen protector interference; device screen issue.	Clean the clear disc tip with a soft, lint-free cloth. Ensure the clear disc tip is not bent or damaged. Test the stylus on another compatible device to rule out device-specific issues. Ensure your device's screen is clean and free of smudges.
Stylus feels "sticky" or drags on screen.	Screen or stylus tip is dirty.	Clean both the device screen and the stylus clear disc tip.
Stylus does not support palm rejection or pressure sensitivity.	This is an inherent design characteristic.	The FineTouch Capacitive Stylus is designed to simulate a finger touch and does not include these advanced features. Adjust your grip or software settings accordingly if available.

7. SPECIFICATIONS

Attribute	Detail
Model Name	FineTouch Capacitive Stylus
Brand	BoxWave
Item Weight	1 ounces
ASIN	B0DYBPQY94
Date First Available	March 27, 2024
Manufacturer	BoxWave
Compatibility	Universal for capacitive touchscreens (e.g., Displays2Go DW032TLB)
Tip Type	Clear Disc Tip
Material	Aluminum (body), Plastic (disc tip)

8. WARRANTY AND SUPPORT

BoxWave Corporation stands behind its products. For support regarding your FineTouch Capacitive Stylus, please note the following:

- **Technical Support:** Purchase includes limited third-party technical support for Displays2Go DW032TLB (32 in) (up to 3 inquiries via electronic messaging). This support is not affiliated with or endorsed by Displays2Go.
- **Contact:** For general inquiries or support, please refer to the contact information provided with your purchase or visit the official BoxWave website.

Please retain your proof of purchase for any warranty claims or support requests.

© 2024 BoxWave Corporation. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page
<https://manuals.plus/asin/B0DYBPQY94>
More documents and user manuals: <https://manuals.plus/>