



Manuals.plus /

› Dephet /

› Dephet White Malm 7 Drawer Dresser User Manual

Dephet 7 Drawer Dresser-9050

Dephet White Malm 7 Drawer Dresser User Manual

Model: 7 Drawer Dresser-9050

1. INTRODUCTION

Thank you for choosing the Dephet White Malm 7 Drawer Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read it thoroughly before beginning assembly and retain it for future reference.

This dresser is designed to offer spacious and organized storage with its seven drawers, featuring a modern high-gloss, handle-free design. It is suitable for various rooms including bedrooms, living rooms, entryways, and nurseries.

2. SAFETY INFORMATION

WARNING: Furniture tip-over can cause serious or fatal crushing injuries. To prevent tip-over, this furniture must be permanently attached to the wall using the anti-tip device provided.

- Always use the anti-tip buckles provided to secure the dresser to a wall.
- Do not allow children to climb on drawers or shelves.
- Place heavier items in the lowest drawers.
- Do not open more than one drawer at a time.
- Ensure all parts are securely fastened before use.



Image: Illustration demonstrating the importance of anti-tipping devices for child safety. The left side shows a dresser tipping over when a child climbs on it without the device, while the right side shows a dresser securely attached to the wall with an anti-tip device, preventing tip-over.

3. PARTS LIST

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Part	Description	Quantity
A	Top Panel	1
B	Side Panels	2
C	Bottom Panel	1
D	Back Panel	1
E	Drawer Fronts (Small)	3
F	Drawer Fronts (Large)	4
G	Drawer Sides	14
H	Drawer Backs	7
I	Drawer Bottoms	7
J	Drawer Slides (Pairs)	7
K	Anti-tip Kit	1
L	Hardware Pack (Screws, Dowels, Cam Locks, etc.)	1



Image: Detailed product dimensions, including overall dresser measurements (55.1" W x 15.7" D x 31.5" H) and internal dimensions for both small and large drawers, illustrating the storage capacity.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Estimated Assembly Time: 2-3 hours (2 people recommended)

4.1 Tools Required (Not Included)

- Phillips Head Screwdriver
- Hammer
- Measuring Tape
- Pencil
- Drill (for anti-tip device installation)

4.2 Assembly Steps

1. **Prepare the Area:** Clear a spacious, clean, and flat area for assembly. Lay down a blanket or cardboard to protect the furniture pieces and your floor.
2. **Identify Parts:** Unpack all components and identify them using the Parts List. Group similar parts together.
3. **Assemble the Frame:**
 - Attach the side panels (B) to the bottom panel (C) using the provided hardware (L). Ensure cam locks are tightened securely.
 - Slide the back panel (D) into the grooves of the side panels.
 - Attach the top panel (A) to the assembled frame, securing it with cam locks.
4. **Install Drawer Slides:** Attach the drawer slides (J) to the inside of the dresser frame according to the pre-drilled holes. Ensure they are level and aligned.
5. **Assemble Drawers:** For each of the seven drawers:
 - Attach the drawer sides (G) and back (H) to the drawer front (E or F).
 - Slide the drawer bottom (I) into the grooves.
 - Attach the remaining drawer side.
 - Install the corresponding drawer slides to the sides of the assembled drawer.



Image: A close-up view of an open drawer, highlighting the smooth metal slides for easy operation and the elegant, handle-free design with a hidden curved pull-out mechanism.

6. **Insert Drawers:** Carefully slide each assembled drawer into its respective slot in the dresser frame.

7. **Install Anti-Tip Device:**

- Position the dresser in its desired location.
- Using the anti-tip kit (K), follow the instructions provided with the kit to secure the dresser to a wall stud. This is a critical safety step.



Image: A visual guide illustrating the correct method for installing the anti-tipping device, showing how it securely fastens the dresser to the wall to prevent accidental tip-overs.

5. OPERATING INSTRUCTIONS

5.1 Using the Drawers

- To open a drawer, gently pull from the hidden curved handle located at the top edge of the drawer front.
- To close, push the drawer firmly until it is fully seated.
- Avoid overloading drawers to ensure smooth operation and prevent damage to the slides.
- Distribute weight evenly within drawers.



Image: The Dephet White Malm 7 Drawer Dresser, showcasing its sleek, handle-free design and high-gloss finish, positioned in a modern bedroom setting.

5.2 Placement and Usage

- This dresser is suitable for various rooms including bedrooms, living rooms, entryways, and nurseries.
- The spacious top surface can accommodate items such as televisions (up to 65 inches), books, and decorative items.
- Utilize the seven drawers for categorized storage of clothing, accessories, linens, or other household items.




Image: The dresser serving as a media console, with a 65-inch television placed on its wide top surface, illustrating its versatility in a living room or bedroom.

6. CARE AND MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as they may damage the high-gloss finish. The surface is waterproof and easy to clean.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Humidity:** Maintain a stable room temperature and humidity level to prevent warping or cracking of the wood.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.

Protect Your Kids and Pets



With Anti-toppling Devices

VS



Without Anti-toppling Devices



Image: A detailed view of the dresser's surface, emphasizing its wide, thickened tabletop and the waterproof, easy-to-clean finish, along with smooth metal drawer slides and a sturdy pedestal base.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides or overloaded drawer.	Check alignment of drawer slides and ensure they are securely fastened. Reduce the weight in the drawer.
Dresser feels wobbly or unstable.	Loose hardware or uneven floor.	Tighten all assembly screws. Ensure the dresser is on a level surface. Verify anti-tip device is securely installed.
Gap between drawer front and frame.	Drawer not fully inserted or misaligned.	Push drawer firmly until it clicks into place. Re-check drawer slide installation.
Missing parts during assembly.	Packaging error.	Contact Dephet customer support with your purchase details and the specific missing parts.

8. PRODUCT SPECIFICATIONS

- **Model Name:** Dephet White Malm 7 Drawer Dresser
- **Model Number:** 7 Drawer Dresser-9050
- **Brand:** Dephet
- **Product Dimensions:** 15.7"D x 55.1"W x 31.1"H
- **Item Weight:** 112.4 Pounds
- **Number of Drawers:** 7
- **Material:** High quality thickened material with wood grain finish
- **Finish:** High Gloss
- **Assembly Required:** Yes
- **Special Feature:** Handle-free design, Anti-tip buckles, Waterproof & Scratch-resistant surface
- **Room Type:** Entryway, Living Room, Bedroom, Hallway, Nursery
- **Country of Origin:** China

9. WARRANTY AND SUPPORT

For any questions, missing parts, or assistance with assembly, please contact Dephet customer support. Refer to your purchase documentation for specific warranty details.

Customer Support: Refer to the contact information provided at the point of purchase or on the Dephet official website.

Returns: This product is eligible for 30-day easy returns. Please refer to the retailer's return policy for details.

