

AONIMI T3

AONIMI 40800mAh Portable Charger Power Bank (Model T3) User Manual

Model: T3

1. INTRODUCTION

The AONIMI 40800mAh Portable Charger Power Bank (Model T3) is designed to provide reliable and fast charging for a wide range of electronic devices. Featuring a high-capacity battery, multiple output ports, and built-in cables, this power bank offers a convenient solution for charging on the go. It incorporates advanced safety features to protect your devices during charging. This manual provides essential information for the safe and efficient use of your AONIMI power bank. Please read it thoroughly before operation.

2. PRODUCT OVERVIEW

The AONIMI T3 power bank is equipped with a 40800mAh battery, offering substantial power for multiple device charges. It includes two built-in cables (Type-C and for iPhone devices), a USB-A port, and a USB-C port, allowing for up to five devices to be charged simultaneously. The integrated LCD display shows the remaining battery percentage.

5 Outputs & 2 Inputs

Built in 2 Cables and iWatch Charger, No need to carry any extra cables



Figure 2.1: Overview of the AONIMI T3 Power Bank showing its 5 outputs and 2 inputs, including built-in cables and ports. The LCD display indicates battery percentage.

Key Features:

- **High Capacity:** 40800mAh battery for extended use.
- **Built-in Cables:** Includes Type-C and for iPhone cables for convenience.
- **Multiple Outputs:** 5 output options (built-in Type-C, built-in for iPhone, USB-A, USB-C, and wireless charging for Apple Watch).
- **Dual Inputs:** Recharge via built-in Type-C cable or USB-C port.
- **Fast Charging:** Supports 25W PD and QC4.0 for rapid device charging.
- **LCD Display:** Digital screen shows precise battery percentage.
- **Safety Protections:** Built-in safeguards against over-charge, over-discharge, short circuit, and high temperature.

3. SETUP AND RECHARGING THE POWER BANK

Before initial use, fully charge your AONIMI power bank. The LCD display will show "100%" when fully charged.

Recharging Methods:

1. Using the Built-in USB-C Cable:

Connect the built-in USB-C cable to a compatible USB wall adapter (not included) or a computer's USB port. The LCD display will show the charging progress.

2. Using the USB-C Port:

Connect a USB-C to USB-C cable (included) from a wall adapter to the power bank's USB-C input/output port. The LCD display will show the charging progress.

A full charge typically takes approximately 6 hours.



Figure 3.1: Illustration of recharging the power bank using either the built-in USB-C cable or an external USB-C cable connected to the USB-C port.

4. OPERATING INSTRUCTIONS

The AONIMI T3 power bank allows you to charge up to five devices simultaneously.

Charging Devices:

1. **Power On:** Press the power button once to activate the power bank and view the battery percentage on the LCD display.

2. **Using Built-in Cables:**

- For iPhone devices: Pull out the built-in for iPhone cable and connect it to your device.
- For USB-C devices: Pull out the built-in Type-C cable and connect it to your device.

3. **Using USB Ports:**

- Connect a standard USB-A cable to the USB-A output port and your device.
- Connect a USB-C cable to the USB-C input/output port and your device.

4. **Wireless Charging for Apple Watch:**

Place your Apple Watch on the designated wireless charging pad on the power bank. Ensure proper alignment for charging to begin.

The power bank supports 25W Power Delivery (PD) and Quick Charge 4.0 (QC4.0) for compatible devices, enabling faster charging times.

5-in-1 Portable Charger Built-in 2 Cables

Charge 5 Devices Simultaneously



Type-C Cable
25W/25W
(Input/Output)



iOS Cable
12W Output



USB-C PD
25W/25W
(Input/Output)



USB-A
Output **20W**



Wireless Charge
5W



Figure 4.1: The power bank demonstrating its ability to charge multiple devices, including phones and tablets, using its various outputs and built-in cables.

25W PD + QC4.0 Full Speed Fast Charging

Wired Charging for All iPhone/iPad/ Android Devices



Figure 4.2: Visual representation of the 25W PD + QC4.0 fast charging capability, showing an iPhone charging rapidly.

5. MAINTENANCE AND SAFETY

Proper maintenance ensures the longevity and safe operation of your power bank.

General Care:

- Keep the power bank away from extreme temperatures, direct sunlight, and moisture.
- Avoid dropping or subjecting the power bank to strong impacts.
- Clean the exterior with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store in a cool, dry place when not in use for extended periods.

Safety Precautions:

- Do not disassemble, modify, or attempt to repair the power bank.
- Avoid exposing the power bank to fire or water.

- Do not use if the power bank is damaged, swollen, or leaking.
- Keep out of reach of children.
- Ensure adequate ventilation during charging and discharging.
- The power bank features multiple protection systems including over-voltage, over-current, over-charge, over-power, short-circuit, high temperature, and anti-interference protection.



Figure 5.1: Diagram illustrating the various safety protections integrated into the power bank, such as over-voltage, over-charge, and short-circuit protection.

6. TROUBLESHOOTING

If you encounter issues with your AONIMI power bank, refer to the following common solutions:

Common Issues and Solutions:

- **Power bank not charging:**
 - Ensure the charging cable is securely connected to both the power bank and the power source.

- Verify the wall adapter or USB port is functional.
- Try a different charging cable or power source.
- Check the LCD display for any error indicators.

• **Device not charging from power bank:**

- Press the power button on the power bank to ensure it is active.
- Check if the power bank has sufficient charge (refer to the LCD display).
- Ensure the charging cable is securely connected to both the power bank and your device.
- Try a different output port or built-in cable.
- Confirm your device is compatible with the power bank's output specifications.

• **Slow charging:**

- Ensure you are using a fast-charging compatible cable and device to utilize PD/QC4.0 features.
- Charging multiple devices simultaneously may reduce the charging speed for each device.
- If recharging the power bank, ensure the wall adapter provides sufficient wattage (e.g., over 25W if charging devices simultaneously through the power bank).

• **Power bank feels warm during use:**

It is normal for the power bank to generate some heat during charging or discharging. If it becomes excessively hot, disconnect it immediately and contact support.

• **Buzzing sound when plugged into wall (if applicable):**

Some units with integrated wall prongs may emit a slight buzzing sound if the contact with the electrical outlet is not firm. Ensure a secure connection. If the sound is loud or persistent, use the USB-C port for recharging instead.

7. SPECIFICATIONS

Feature	Detail
Model Number	T3
Battery Capacity	40800mAh
Battery Cell Type	Lithium Polymer
Input (USB-C Port)	25W PD (Power Delivery)
Output (Built-in Type-C Cable)	25W PD (Input/Output)
Output (Built-in for iPhone Cable)	12W
Output (USB-A Port)	20W
Output (Wireless Charging)	5W (for Apple Watch)
Number of Outputs	5 (Built-in Type-C, Built-in for iPhone, USB-A, USB-C, Wireless)
Number of Inputs	2 (Built-in Type-C, USB-C Port)
Dimensions (L x W x Thickness)	5.8" x 2.75" x 1.06"
Weight	0.4 kg (0.98 lb)
Battery Charge Time	Approx. 6 hours

Feature	Detail
Color	Black

8. WARRANTY AND SUPPORT

Warranty Information:

The AONIMI 40800mAh Portable Charger Power Bank (Model T3) comes with a **2-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or natural disasters.

Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, warranty claims, or any questions regarding your AONIMI power bank, please contact our customer support team. Refer to the product packaging or the retailer's website for specific contact details.

When contacting support, please provide your product model number (T3) and a detailed description of the issue.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question