Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mtsige B0DYD2D3NC

Mtsige 360° Rotating Vibrating Butt Plug Instruction Manual

Model: B0DYD2D3NC

Introduction

This manual provides essential information for the safe and effective use of your Mtsige 360° Rotating Vibrating Butt Plug. Please read it thoroughly before first use and retain it for future reference.

Safety Information

- This product is intended for adult use only (18+). Keep out of reach of children.
- Use caution when inserting or removing the product to prevent injury.
- Always apply a generous amount of water-based lubricant before and during use for comfort and safety. Do not use silicone-based lubricants as they can damage the silicone material of the product.
- Crafted from 100% body-safe liquid silicone. If you experience any irritation, discontinue use immediately.
- The product is rated IPX5 waterproof. It can withstand splashes of water but should not be submerged for extended periods.
- Fully charge the device before its first use.
- Due to safety and hygiene reasons, this product is generally non-returnable once opened.

Product Components

Your Mtsige 360° Rotating Vibrating Butt Plug package includes:

- 1 x Mtsige 360° Rotating Vibrating Butt Plug
- 1 x USB Charging Cable
- 1 x User Manual (this document)



Image: The Mtsige 360° Rotating Vibrating Butt Plug, showcasing its ergonomic design and T-shaped base.



Image: Detailed view of the product's ergonomic design, highlighting realistic glans, texture, fat body, narrow closing, and T-shaped base for safety.

Setup

1. Charging the Device

Before first use, fully charge your device. The charging port is located on the T-shaped base.

- Connect the provided USB charging cable to the device's charging port.
- Plug the USB end into a compatible power source (e.g., computer, power bank, USB wall adapter).
- Charging time is approximately 85 minutes for a full charge.
- A full charge provides approximately 45 minutes of continuous use.



Image: The Mtsige butt plug connected to its USB charging cable, illustrating compatibility with car chargers, wall adapters, power banks, and computers.

2. App Installation and Connection

The device can be controlled via a smartphone application for enhanced functionality.

1. Scan the QR code provided in the product packaging or on the product detail page, or visit https://dl.szweibutech.com/download/0384 to download and install the "Love Spouse" app from your device's app store (App Store for iOS or Google Play for Android).
2. Register an account and log in to the app.
3. Ensure your device's Bluetooth is enabled.
4. Turn on the Mtsige device by long-pressing the power button on its base.
5. Within the app, scan the product QR code or enter the product code "0384" to bind the device.
6. Once connected, you can explore various modes, including classic, game, video, music, draw something, shake, and interactive modes.



Image: Screenshot of the 'Love Spouse' app interface, showing various control modes and options for the Mtsige device.

Operating Instructions

1. Manual Control

- **Power On/Off:** Long press the power button located on the T-shaped base to turn the device on or off.
- **Change Modes:** Once powered on, short press the power button to cycle through the 10 different rotation and vibration frequencies.



Image: The Mtsige butt plug illustrating its 360° rotation and 10 unique powerful combination modes.

2. App Control

Once connected via the "Love Spouse" app, you can control the device remotely and access advanced features:

- **Classic Mode:** Select from 10 pre-set vibration and rotation patterns.
- **Custom Modes:** Create and save your own unique patterns.
- **Interactive Modes:** Explore game mode, video mode (sync with media), music mode (sync with audio), draw something (control patterns with finger gestures), shake mode (control patterns by shaking your phone), and interactive mode for partner play.



Image: The Mtsige butt plug with app control, illustrating diverse usage scenarios for individuals and couples.

Your browser does not support the video tag.

Video: A demonstration of the Mtsige Rotating Vibrating Butt Plug, highlighting its features and operation.

Your browser does not support the video tag.

Video: A detailed overview of the Mtsige Butt Plug, covering its design, features, and functionality.

Maintenance

1. Cleaning

Proper cleaning ensures hygiene and prolongs the product's lifespan.

- Clean the device thoroughly before and after each use.
- Wash with warm water and a mild, toy-safe soap.
- Rinse thoroughly to remove all soap residue.
- Pat dry with a lint-free cloth or allow to air dry completely before storing.

- Do not use harsh chemicals, alcohol-based cleaners, or petroleum-based products, as these can damage the silicone.



Image: The Mtsige butt plug being rinsed, demonstrating its IPX5 waterproof rating and ease of cleaning.

2. Storage

- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep it separate from other toys made of different materials to prevent material degradation.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Low battery.	Charge the device fully (approx. 85 minutes).

Problem	Possible Cause	Solution
Device does not vibrate/rotate.	Not powered on; incorrect mode selected.	Long press power button to turn on. Short press to cycle modes. Check app connection if using app control.
App connection issues.	Bluetooth off; device not paired; app permissions.	Ensure Bluetooth is on. Re-pair device in app. Check app permissions (location, photo, microphone).
Device feels too intense.	High intensity mode selected.	Cycle through modes to find a lower intensity. Use app for finer control.

Specifications

- **Brand:** Mtsige
- **Model:** B0DYD2D3NC
- **Material:** 100% Body-Safe Liquid Silicone
- **Color:** Black
- **Dimensions:** Approximately 3.9 inches (total length) x 1.3 inches (insertable diameter), widest diameter: 1.48 inches.
- **Functions:** 360° Rotation, 10 Vibration Frequencies, APP Control
- **Charging:** USB Rechargeable
- **Charging Time:** Approximately 85 minutes
- **Working Time:** Approximately 45 minutes
- **Water Resistance:** IPX5 (Splash-proof)
- **Noise Level:** Under 40dB



Image: Visual representation of the Mtsige butt plug's dimensions.

Warranty and Support

While this product is generally non-returnable due to safety reasons, Mtsige is committed to customer satisfaction.

- If you encounter any problems with your device, please contact the Mtsige customer service team.
- Our professional service team will assist you in resolving any issues promptly.

© 2025 Mtsige. All rights reserved.
Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DYD2D3NC

More documents and user manuals: **https://manuals.plus/**