SICOTAS SIC-ND122

SICOTAS SIC-ND122 Light Oak 3-Drawer Nightstand Instruction Manual

Model: SIC-ND122 | Brand: SICOTAS

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your SICOTAS SIC-ND122 Light Oak 3-Drawer Nightstand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

2. Important Safety Information

- Always assemble the product according to the provided instructions.
- Ensure the product is stable and secure before use.
- Do not overload the product beyond its maximum weight recommendation to prevent tipping or damage.
- Maximum Weight Recommendation: Top surface 55 lbs, each drawer 16 lbs.
- Keep small parts and packaging materials away from children to prevent choking hazards.

3. Parts List

Before assembly, please verify that all components and hardware listed in the included assembly instructions booklet are present and undamaged. Refer to the detailed diagrams in your physical manual for specific part identification.



Figure 3.1: Exploded view of nightstand components and hardware. Please cross-reference with your included manual.

4. Assembly Instructions

Follow these steps carefully for proper assembly. An electric drill can assist with screw installation, but a manual screwdriver is sufficient. Ensure you have a hammer and screwdriver as recommended tools.

4.1. Step-by-Step Assembly Video

Video 4.1: Official SICOTAS installation video for the nightstand. This video provides a visual guide for each assembly step.

4.2. General Assembly Overview

The nightstand is designed for straightforward assembly. It involves attaching the side panels, back panel, and top panel using cam locks and screws. The drawer slides are then installed, followed by the assembly of the three drawers. Ensure all connections are tight for stability.



Figure 4.2: A fully assembled SICOTAS Light Oak Nightstand, showcasing its three drawers and elegant design.

5. Operating Instructions

The SICOTAS nightstand features three smooth-sliding drawers for convenient storage of your bedside essentials.

- **Opening Drawers:** Gently pull the golden handle of the desired drawer outwards.
- **Closing Drawers:** Push the drawer firmly until it is fully seated within the nightstand frame.
- **Storage:** Utilize the ample space within each drawer for organizing clothes, books, gadgets, and personal items. The spacious top surface is ideal for lamps, alarm clocks, or decorative pieces.
- Avoid forcing drawers open or closed to prevent damage to the slides.



Figure 5.1: A close-up of the nightstand with its three drawers open, revealing ample storage space for various items.

6. Care and Maintenance

- **Cleaning:** Clean surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Wipe up spills immediately to prevent water damage or staining.
- **Fasteners:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Heat Protection:** Do not place hot items directly on the surface; always use coasters or protective pads.
- **Sunlight Exposure:** Avoid direct sunlight exposure for prolonged periods to prevent fading or discoloration of the wood finish.
- **Color Variation:** Slight color variations may occur due to material batches, manufacturing processes, or display settings. These are normal and do not impact quality.

7. Troubleshooting Common Issues

- **Drawers not sliding smoothly:** Check that the drawer slides are correctly installed and free of obstructions. Ensure all screws securing the slides are tightened.
- **Nightstand wobbling:** Verify that all assembly screws and cam locks are securely fastened. Ensure the nightstand is placed on a level surface. Adjust any leveling feet if applicable.
- **Missing or damaged parts:** Refer to the parts list in your assembly manual. If any parts are missing or damaged upon arrival, please contact SICOTAS customer service for assistance.

8. Product Specifications

Feature	Detail
Brand	SICOTAS
Model Name	SIC-ND122
Product Dimensions (per unit)	Approx. 31.3"W x 16.3"D x 26.6"H
Drawer Dimensions (internal)	30.1"W x 11.4"D x 7.5"H
Item Weight (per unit)	Approx. 63.6 Pounds
Maximum Weight Recommendation (Top)	55 Pounds
Maximum Weight Recommendation (per Drawer)	16 Pounds
Frame Material	Engineered Wood
Color	Light Oak
Number of Drawers	3
Assembly Required	Yes
Tools Recommended	Hammer, Screw Driver

9. Warranty and Customer Support

SICOTAS is dedicated to providing professional customer service before and after your purchase. For any questions, concerns, or assistance with missing/damaged parts, please feel free to contact SICOTAS customer service. Refer to your purchase documentation for specific warranty details and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question