

Marsail B0DYDC5ZHB

Marsail Electric Standing Desk Frame User Manual

Model: B0DYDC5ZHB

- [Introduction](#) [Safety Information](#) [Package](#)  
[Contents](#) [Setup](#) [Operating](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential instructions for the assembly, operation, and maintenance of your Marsail Electric Standing Desk Frame. Please read this manual thoroughly before installation and use to ensure proper function and safety. This product is designed to provide a height-adjustable workstation, promoting ergonomic comfort and flexibility.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure all components are securely fastened before use.
- Do not exceed the maximum load capacity of**176 lbs (80 kg)**.
- Keep children and pets away from the desk during operation.
- Ensure there are no obstructions in the desk's path during height adjustment.
- Do not disassemble or modify the motor or control unit. Contact support for service.
- Use only the provided power adapter.
- Avoid spilling liquids on the control panel or electrical components.

3. PACKAGE CONTENTS

Verify that all parts are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Left Leg Assembly

- Right Leg Assembly
- Crossbar (Adjustable)
- Control Panel
- Motor and Power Adapter
- Headphone Hook
- All necessary screws and tools for assembly



**Image 3.1:** Overview of the Marsail Electric Standing Desk Frame components, including legs, crossbar, control panel, and accessories.

## 4. SETUP AND ASSEMBLY

---

Follow these steps to assemble your Marsail Electric Standing Desk Frame. A desktop (not included) is required for full functionality.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Legs and Crossbar:** Attach the leg assemblies to the adjustable crossbar using the provided screws. Ensure the crossbar is set to the desired width to accommodate your desktop. The frame supports desktops from 39.4" to 62.9" in length and 19.7" to 31.5" in width.
3. **Attach Control Panel and Motor:** Securely mount the control panel and motor unit to the designated locations on the frame. Connect all cables as instructed in the detailed assembly guide (not provided in this summary).
4. **Install Desktop:** Carefully place your chosen desktop onto the assembled frame. Align the desktop and secure it to the frame using appropriate screws (ensure screw length is suitable for your desktop thickness to avoid damage).
5. **Cable Management:** Organize and secure all cables using the integrated cable management system or provided ties to prevent tangles and ensure smooth operation.

# Fits Larger Desktops



**Image 4.1:** Illustration of the adjustable frame accommodating various desktop sizes, with dimensions for length (39.4" to 62.9") and width (19.7" to 31.5").

# Clean Cable Management



**Image 4.2:** Example of effective cable management, showing how to keep cables tidy and out of the way for a clean workspace.

## 5. OPERATING INSTRUCTIONS

The Marsail Electric Standing Desk Frame features a powerful and quiet motor for smooth height adjustments and a convenient control panel with memory presets.

### 5.1. Control Panel Functions



**Image 5.1:** The control panel features an LED display, up/down keys, and four memory preset buttons (1, 2, 3, 4).

- **Up (▲) / Down (▼) Buttons:** Press and hold to manually adjust the desk height. Release the button to stop at the desired height.
- **LED Display:** Shows the current desk height in inches or centimeters.
- **Memory Presets (1, 2, 3, 4):** These buttons allow you to save and recall preferred desk heights.

## 5.2. Setting Memory Presets

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the 'M' or 'Set' button (if available, otherwise proceed to step 3).
3. Press one of the number buttons (1, 2, 3, or 4) within 3 seconds. The LED display will show 'S-' followed by the number, indicating the height is saved.

### 5.3. Recalling Memory Presets

- Simply press the desired memory preset button (1, 2, 3, or 4). The desk will automatically move to the saved height.

### 5.4. Height Adjustment Range

The desk frame offers a wide height adjustment range to accommodate various user preferences and ergonomic needs, from sitting to standing positions.



**Image 5.2:** The desk adjusts from a minimum height of 28.3" to a maximum height of 46.5", suitable for various ergonomic postures.

# High-Performance Motor

**176 lbs**

Max Load

**20 mm/s**

Lifting Speed

**<55 dB**

Quiet Operation



⚠ Desktop not included

**Image 5.3:** The desk features a high-performance motor with a 176 lbs max load, 20 mm/s lifting speed, and quiet operation (<55 dB).

The integrated motor provides smooth and stable height transitions with minimal noise, ensuring a quiet working environment.

## 6. MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your standing desk frame.

- **Cleaning:** Wipe the frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cable Management:** Periodically check and reorganize cables to prevent snagging or damage during height adjustments.
- **Fasteners:** Occasionally check all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Obstructions:** Ensure the area around the desk legs is clear of obstructions that could impede movement.

## 7. TROUBLESHOOTING

If you encounter issues with your Marsail Electric Standing Desk Frame, refer to the following common problems and solutions:

| Problem                  | Possible Cause                                     | Solution                                                                                       |
|--------------------------|----------------------------------------------------|------------------------------------------------------------------------------------------------|
| Desk does not move       | Power cable disconnected;<br>Overload; Motor error | Check power connection; Reduce load on desk; Unplug for 10 seconds and replug.                 |
| Uneven height adjustment | Uneven load; Loose connections                     | Distribute weight evenly; Check all screws and connections.                                    |
| Error code on display    | Specific system fault                              | Refer to the full product manual for specific error code meanings or contact customer support. |
| Desk stops mid-movement  | Overheat protection;<br>Obstruction detected       | Allow motor to cool down for 20 minutes; Remove any obstructions.                              |

## 8. SPECIFICATIONS

| Feature                   | Detail                             |
|---------------------------|------------------------------------|
| Brand                     | Marsail                            |
| Model                     | B0DYDC5ZHB                         |
| Item Weight               | 27.56 Pounds                       |
| Maximum Recommended Load  | 176 Pounds (80 kg)                 |
| Height Adjustment Range   | 28.3" - 46.5" (71.9 cm - 118.1 cm) |
| Lifting Speed             | 20 mm/s                            |
| Noise Level               | <55 dB                             |
| Compatible Desktop Length | 39.4" - 62.9" (100 cm - 160 cm)    |
| Compatible Desktop Width  | 19.7" - 31.5" (50 cm - 80 cm)      |

| Feature             | Detail         |
|---------------------|----------------|
| Base Material       | Carbon Steel   |
| Assembly Required   | Yes            |
| Included Components | Headphone Hook |
|                     |                |

## 9. WARRANTY & SUPPORT

For warranty information, technical support, or to report missing/damaged parts, please contact Marsail customer service through your retailer or the official Marsail website. Please have your model number (B0DYDC5ZHB) and purchase date ready when contacting support.

© 2025 Marsail. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0DYDC5ZHB>

More documents and user manuals: <https://manuals.plus/>