

[Manuals.plus](#) /

› [MZROT](#) /

› MZROT 95kPa Vacuum Sealer Machine User Manual

MZROT 618

MZROT 95kPa Vacuum Sealer Machine

Model: 618

INTRODUCTION

This user manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your MZROT 95kPa Vacuum Sealer Machine. Please read this manual thoroughly before using the appliance and retain it for future reference.



The MZROT 95kPa Vacuum Sealer Machine, designed for efficient food preservation.


SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Do not operate the appliance with a damaged power cord or plug.
- Do not immerse the appliance in water or other liquids.
- Keep the appliance out of reach of children.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Use only accessories and attachments recommended by the manufacturer.
- Do not use the appliance for purposes other than its intended use.

PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the main components of your vacuum sealer machine.



Detailed view of the vacuum sealer's components, including the built-in bag storage, cutter, double silicone seal strip, bag positioning clamp, and vacuum chamber.

- **Control Panel:** Features various buttons and a display for operation.
- **Lid/Handle:** Used to open and close the machine and engage the sealing mechanism.
- **Vacuum Chamber:** Area where air is extracted from the bag.
- **Sealing Strip:** Heats to create an airtight seal on the bag.
- **Detachable Drip Tray/Sink:** Collects excess liquids and is removable for cleaning.
- **Built-in Cutter:** For custom-sizing vacuum bags from rolls.
- **Bag Storage:** Internal compartment for storing a roll of vacuum bags.
- **Accessory Port:** For connecting the accessory hose for external vacuuming.

SETUP

1. **Unpacking:** Carefully remove the vacuum sealer and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Wipe down the exterior of the machine with a damp cloth. Clean the detachable drip tray and sealing area as described in the Maintenance section.
3. **Placement:** Place the appliance on a flat, stable, and dry surface. Ensure there is sufficient space around the unit for proper ventilation.

4. **Power Connection:** Plug the power cord into a standard electrical outlet. The machine is now ready for operation.

OPERATING INSTRUCTIONS

General Operation

The MZROT vacuum sealer features a user-friendly control panel with various modes for different food types and sealing needs.



The intuitive control panel allows for easy selection of sealing modes.

Vacuum Sealing Bags

1. **Prepare the Bag:** Use MZROT vacuum sealer bags or rolls. If using a roll, pull out the desired length and use the built-in cutter to create a straight cut. Ensure one end of the bag is already sealed.
2. **Fill the Bag:** Place the food item into the bag, leaving at least 3 inches of space from the open end to the contents. This space is crucial for proper vacuuming and sealing.
3. **Position the Bag:** Open the lid of the vacuum sealer. Place the open end of the bag into the vacuum channel, ensuring it lies flat and smooth across the sealing strip. The bag positioning clamp helps prevent shifting.
4. **Close the Lid:** Firmly press down on the lid until it clicks into place, indicating it is locked.
5. **Select Mode:** Choose the appropriate mode based on your food type:
 - **Dry:** For solid, dry food items.
 - **Moist:** For food items with some moisture.
 - **Gentle:** For delicate items that might be crushed by full vacuum pressure.
 - **Normal:** Standard vacuum pressure.
6. **Start Sealing:** Press the 'Vac&Seal' button. The machine will automatically vacuum the air out of the bag and then seal it. The progress display will show the status.
7. **Release:** Once the process is complete, the machine will release the lid automatically or indicate completion. Open the lid and remove the sealed bag.

MULTI-SCENARIO APPLICATION



Visual guide to the vacuum sealing operation procedure.

Seal Only Function

To create a seal without vacuuming, simply place the bag in the machine, close the lid, and press the 'Seal Only' button. This is useful for making bags from rolls or resealing snack bags.

Pulse Vacuum Function

For delicate items that require precise control over vacuum pressure, use the 'Pulse Vacuum' function. Press and hold the 'Pulse Vacuum' button to vacuum, and release to stop. Once the desired vacuum level is reached, press the 'Seal' button to seal the bag.

External Vacuum Extraction (Canister Mode)

Your MZROT vacuum sealer can also be used to vacuum seal canisters and other compatible containers.

1. Insert the smaller end of the vacuum hose into the accessory port on the machine.
2. Connect the other end of the hose to the port on your vacuum-sealable canister.
3. Select 'Canister' mode on the control panel, then press the 'Enter' button to begin the external vacuum process.



1
Pull out the sealed bag



2
The built-in blade cuts through the sealed bag



3
Put in ingredients that need to be sealed



4
Select the mode according to the food type



5
Enjoy healthy ingredients

SMART LIQUID REMINDER

Instructions for connecting and using the external vacuum hose with a canister.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your vacuum sealer.

Cleaning the Detachable Drip Tray/Sink

The detachable drip tray collects any excess liquids during the vacuum sealing process, making cleanup easy.

1. Ensure the machine is unplugged from the power outlet.
2. Pull out the drip tray in the direction of the arrow.
3. Lift the tray upwards to remove it completely.
4. Empty any collected liquids and wash the tray with warm, soapy water. Rinse thoroughly and dry completely before reinserting.



Visual guide for cleaning the detachable drip tray.

Cleaning the Sealing Strip and Vacuum Channel

- Always unplug the appliance before cleaning.
- Wipe the sealing strip and the vacuum channel with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure all parts are completely dry before closing the lid or using the machine again.

Storage

Store the vacuum sealer in a cool, dry place with the lid unlatched to prevent compression of the sealing gaskets, which can affect performance over time.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not power on.	Not plugged in; power outlet issue.	Ensure power cord is securely plugged into a working outlet.
Machine vacuums but does not seal.	Sealing strip dirty/damaged; bag not positioned correctly; lid not fully latched.	Clean sealing strip; reposition bag; ensure lid is fully closed and latched.
Machine seals but does not vacuum.	Bag not in vacuum channel; vacuum chamber dirty; bag has holes.	Ensure bag opening is fully inside vacuum channel; clean vacuum chamber; check bag for damage.

Problem	Possible Cause	Solution
Vacuum is weak or incomplete.	Bag too full; moisture in vacuum channel; sealing gaskets dirty/worn.	Leave more space in bag; clean vacuum channel and drip tray; clean or replace sealing gaskets.
Bag melts during sealing.	Sealing time too long; bag material not suitable.	Allow machine to cool between seals; ensure you are using appropriate vacuum sealer bags.

SPECIFICATIONS

Feature	Detail
Brand	MZROT
Model Number	618
Color	silver
Material	Acrylonitrile Butadiene Styrene (ABS)
Product Dimensions (L x W x H)	8.7" x 4.69" x 16.14"
Item Weight	6.74 pounds (3.06 Kilograms)
Power Source	AC
Operation Mode	Automatic
Wattage	230 watts
Voltage	120V
UPC	780748229627
Manufacture Year	2025

WARRANTY AND SUPPORT

Warranty Information

MZROT offers a 30-day free replacement for quality issues from the date of purchase. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or support, please contact MZROT customer service:

- **Email:** Zhangrun012@outlook.com
- **Online Store:** Visit the official MZROT store on Amazon for more products and information:[MZROT Amazon Store](#)

Our support team is available 24/7 to provide professional and prompt assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DYDTDRG1>

More documents and user manuals: **<https://manuals.plus/>**