

SLM-50S

Generic 50" Full HD Smart ISTAR TV SLM-50S User Manual

Model: SLM-50S

1. INTRODUCTION

Thank you for purchasing the Generic 50" Full HD Smart ISTAR TV, model SLM-50S. This manual provides essential information for setting up, operating, and maintaining your new television. Please read this manual thoroughly before using the TV and retain it for future reference.

2. SAFETY INFORMATION

Always follow basic safety precautions when using this television to reduce the risk of fire, electric shock, and injury.

- Do not expose the TV to rain or moisture.
- Do not block ventilation openings.
- Ensure the power cord is not walked on or pinched.
- Unplug the TV during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items are present in the box:

- Generic 50" Full HD Smart ISTAR TV (SLM-50S)
- Remote Control
- TV Stand (2 pieces)
- User Manual (this document)
- Power Cord

4. SETUP

4.1. Unpacking

Carefully remove the TV from its packaging. It is recommended to keep the packaging materials for future transport.

4.2. Installing the TV Stand

1. Place the TV face down on a soft, flat surface to prevent screen damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are firmly attached.

4.3. Connecting External Devices

Connect your devices to the appropriate ports on the back or side of the TV.

- **HDMI (x2):** For high-definition audio and video from Blu-ray players, game consoles, or set-top boxes.
- **USB (x2):** For connecting USB storage devices to play media files.
- **RF Input (x1):** For connecting an antenna or cable TV.
- **COAX Input (x1):** For digital audio output.
- **PC Audio (AUX) (x1):** For audio input from a PC.
- **AUX Input (x1):** General auxiliary audio input.
- **RCA Input (x1):** For standard definition video and stereo audio (yellow, white, red cables).
- **YPB & PR (x1):** For component video input (green, blue, red cables).

4.4. Power Connection

After all connections are made, plug the power cord into the TV's power inlet and then into a wall outlet.

5. OPERATING THE TV

5.1. Power On/Off

Press the **Power** button on the remote control or on the TV to turn the TV on or off.

5.2. Initial Setup

The first time you turn on the TV, an on-screen guide will assist you with initial settings such as language selection, network connection (Wi-Fi), and channel scanning.

5.3. Remote Control Overview

The remote control allows you to navigate menus, change channels, adjust volume, and access smart features. Familiarize yourself with its buttons for optimal use.

5.4. Input Source Selection

Press the **Source** or **Input** button on your remote to switch between connected devices (e.g., HDMI 1, USB, TV).

5.5. Smart TV Features

Your ISTAR TV is equipped with smart functionality, providing access to a variety of streaming services and applications. The main screen displays a user-friendly interface with icons for popular apps.



Image: The Smart TV home screen displaying applications such as Netflix, Disney+, Prime Video, YouTube TV, Hulu, and content recommendations like 'The Avengers', 'Star Trek: Picard', and 'Trolls World Tour'.

To navigate the smart interface, use the arrow keys on your remote control to highlight desired applications or content, then press **OK** or **Enter** to select. Ensure your TV is connected to the internet for full smart TV functionality.

5.6. Picture and Sound Settings

Access the TV's menu to adjust picture modes (e.g., Standard, Dynamic, Movie), brightness, contrast, color, and sound settings (e.g., sound mode, equalizer).

6. MAINTENANCE

6.1. Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner. Do not spray liquid directly onto the screen.

6.2. Cleaning the Cabinet

Use a soft, dry cloth to clean the TV cabinet. Avoid using abrasive cleaners or solvents.

6.3. Software Updates

Periodically check for software updates through the TV's settings menu to ensure optimal performance and access to the latest features.

7. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

- **No Power:** Ensure the power cord is securely plugged into both the TV and the wall outlet. Try a different outlet.
- **No Picture/Sound:** Verify the correct input source is selected. Check all cable connections. For no sound, ensure volume is not muted or too low.

- **Remote Control Not Working:** Check the batteries and ensure there are no obstructions between the remote and the TV's IR sensor.
- **Network Connection Issues:** Restart your router and modem. Reconnect the TV to your Wi-Fi network through the settings menu.
- **Smart Features Not Loading:** Ensure a stable internet connection. Try restarting the TV.

8. SPECIFICATIONS

Feature	Specification
Brand	Generic
Model Name	ISTAR50S
Item Model Number	SLM-50S
Screen Size	50 Inches
Display Technology	LED
Resolution	1080p (Full HD)
Aspect Ratio	16:9
Refresh Rate	50/60 Hz
Connections	2x HDMI, 2x USB, 1x RF Input, 1x COAX Input, 1x PC Audio (AUX), 1x AUX Input, 1x RCA Input, 1x YPB & PR
Product Dimensions	11D x 77W x 49H centimetres
Model Year	2023

9. WARRANTY INFORMATION

This Generic 50" Full HD Smart ISTAR TV (SLM-50S) comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

10. CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact your retailer or the manufacturer's customer support. Refer to your purchase documentation for specific contact details.