

sisolos Si-A2GY

sisolos TV Chair Massage Recliner (Model Si-A2GY) User Manual

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- **Weight Limit:** Do not exceed the maximum weight recommendation of 136 kilograms (300 lbs).
- **Electrical Safety:** Ensure the power cord for the massage and heat functions is not pinched or damaged. Disconnect from power when not in use or before cleaning.
- **Children and Pets:** Keep children and pets away from the chair during assembly and operation.
- **Stable Surface:** Always place the chair on a flat, stable, and level surface.
- **Moving Parts:** Keep hands and feet clear of the reclining mechanism when adjusting the chair.
- **Proper Use:** This chair is designed for personal relaxation. Do not stand on the chair or use it for purposes other than its intended design.

For any concerns, contact sisolos customer support.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Chair Base (Box A)
- Chair Armrests (2 pieces, Box B)
- Chair Backrest (Box B)
- Power Adapter and Remote Control for Massage/Heat

No Tools Needed

Delivered In 2 Boxes & Easy Assembly



BOX A Chair Base

BOX B Chair Armrest*2 Chair Backrest



Step 1

Step 2

Image: The chair components are delivered in two boxes, simplifying the unpacking process.

3. ASSEMBLY INSTRUCTIONS

The sisolos TV Chair is designed for tool-free assembly. Follow these steps:

1. **Step 1: Attach Chair Backrest to Base.** Align the metal brackets on the backrest with the corresponding slots on the chair base. Slide the backrest down firmly until it clicks into place.
2. **Step 2: Attach Armrests.** Slide each armrest onto the side brackets of the chair base, ensuring they are securely seated.
3. **Connect Power (for Massage/Heat):** Locate the power cable from the chair and connect it to the provided power adapter. Plug the adapter into a standard electrical outlet.

No Tools Needed

Delivered In 2 Boxes & Easy Assembly



BOX A Chair Base

BOX B Chair Armrest*2 Chair Backrest



Image: Visual guide for the two-step assembly process, demonstrating how the backrest and armrests connect to the chair base.

4. OPERATING INSTRUCTIONS

4.1 Reclining Function

To recline the chair, locate the side pull tab on the inner side of one armrest. Pull the tab to release the footrest and lean back to adjust the recline angle. The chair can be adjusted from an upright position (approximately 110°) to a relaxed recline (up to 135°). To return to the upright position, push down on the footrest with your legs while leaning forward.

Premium Materials

Selected materials just for you



Ultra Soft Cotton



Thickened Steel



Durable Hardwood



Image: This diagram shows the side pull tab mechanism and the range of recline angles, from reading to taking a break.

4.2 Massage and Heat Functions

The chair features an 8-point vibration massage system and lumbar heating. Use the wired remote control to operate these functions:

- **Power Button:** Turn the massage and heat functions on/off.
- **Massage Areas:** Select specific massage zones (e.g., back, lumbar, thighs, calves). The chair has 4 massage areas and 8 massage points.
- **Vibration Intensity:** Adjust the intensity of the vibration massage (2 intensities available).
- **Heat Function:** Activate lumbar heating for added comfort.
- **Timed Massage:** Set a timer for the massage duration.

8-Point Vibration Massage

Enjoy a cosy massage and lumbar heating



Image: This graphic illustrates the 8-point vibration massage system, highlighting the lumbar heating and the various settings available on the remote control.

4.3 360° Swivel and Rocking Function

The chair is equipped with a 360° swivel base, allowing you to rotate freely without moving the entire chair. It also features a gentle rocking function for added relaxation. Simply lean back and forth to engage the rocking motion.

360° Swivel Function

Enjoy every moment of your daily life



Image: This visual shows the chair's 360-degree swivel capability, emphasizing its versatility for different activities.

5. MAINTENANCE AND CARE

- **Cleaning:** For general cleaning, use a soft, damp cloth with mild soap. Do not use harsh chemicals or abrasive cleaners. Spot clean spills immediately.
- **Fabric Care:** Vacuum the fabric regularly to remove dust and debris.
- **Inspection:** Periodically check all connections and moving parts to ensure they are secure. Tighten any loose screws if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading.

6. TROUBLESHOOTING

- **Chair does not recline:** Ensure the side pull tab is fully engaged. Check for any obstructions under the footrest or behind the backrest.
- **Massage/Heat functions not working:** Verify that the power adapter is securely plugged into both the chair and

a working electrical outlet. Check the power button on the remote control.

- **Chair feels unstable:** Ensure the chair is placed on a flat, level surface. Check that all assembly connections are secure.
- **Unusual noises:** If you hear unusual noises during operation, discontinue use and inspect the chair for any loose parts or damage. Contact customer support if the issue persists.

7. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	sisolos
Model Number	Si-A2GY
Color	Grey
Product Dimensions (D x W x H)	33.46"D x 26.38"W x 39.76"H (85cm x 67cm x 101cm)
Item Weight	30 Kilograms (66 lbs)
Maximum Weight Recommendation	136 Kilograms (300 lbs)
Included Components	Arm Pad
Assembly Required	Yes (Tool-free)
Massage Function	8-Point Vibration Massage (4 areas, 2 intensities)
Heat Function	Lumbar Heating
Swivel Function	360° Rotation
Recline Angle	Adjustable from 110° to 135°

8. WARRANTY AND CUSTOMER SUPPORT

For warranty information or to obtain customer support, please refer to the documentation included with your purchase or contact sisolos directly through their official website or the retailer where the product was purchased. Please have your model number (Si-A2GY) and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question