

[manuals.plus](#) /› [realme](#) /› [Realme P3 Pro 5G Smartphone User Manual](#)**realme P3 Pro**

# Realme P3 Pro 5G Smartphone User Manual

## 1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Realme P3 Pro 5G smartphone. Please read this guide thoroughly to ensure optimal performance and longevity of your device. The Realme P3 Pro 5G features a Snapdragon 7s Gen 3 chipset, a 1.5K Quad-Curved AMOLED display, a 50 MP Sony IMX896 OIS camera, and a 6000 mAh battery with 80W SuperVOOC fast charging.



Image 1.1: Realme P3 Pro 5G highlighting key features.

## 2. SETUP

### 2.1. What's in the Box

Verify that all items are present in your product packaging:

- Realme P3 Pro 5G Handset
- Charger (80W SuperVOOC)
- USB Data Cable (Type-C)
- SIM Ejector Tool

- Protective Case
- Quick Guide

## 2.2. SIM Card Installation

To install your Nano-SIM cards:

1. Locate the SIM card tray on the side of the device.
2. Insert the SIM ejector tool into the small hole next to the tray and press gently until the tray pops out.
3. Place your Nano-SIM cards into the designated slots on the tray, ensuring the gold contacts face downwards. The device supports Dual Nano-SIM.
4. Carefully reinsert the SIM tray into the phone until it clicks into place.




Image 2.1: Bottom view of the device, showing the SIM tray location.

## 2.3. Initial Power On and Setup Wizard

Press and hold the Power button (located on the right side of the device) until the Realme logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, Google account setup, and security settings.



## 2.4. Charging the Device

Connect the USB Type-C cable to the phone's charging port and the 80W SuperVOOC charger. Plug the charger into a power outlet. The device supports fast charging, allowing for quick replenishment of the 6000 mAh battery.

## 3. OPERATING INSTRUCTIONS

---

### 3.1. Basic Navigation

The Realme P3 Pro 5G utilizes a touchscreen interface. Use gestures such as tapping, swiping, pinching, and spreading to navigate the system. The power button controls screen on/off and device power, while the volume buttons adjust audio levels.

### 3.2. Display Features

The device features a 6.83-inch Quad-Curved 1.5K AMOLED display with a 120 Hz refresh rate. This display offers vibrant colors, deep blacks, and smooth scrolling. Adjust display settings such as brightness, color mode, and refresh rate in the 'Settings' menu under 'Display & Brightness'.

### 3.3. Camera Usage

The Realme P3 Pro 5G is equipped with a 50 MP Sony IMX896 OIS camera. To access the camera, tap the camera icon on your home screen or lock screen. Key features include:

- **Optical Image Stabilization (OIS):** Reduces blur from handshakes for clearer photos and videos.
- **AI Snap Mode:** Automatically optimizes settings for fast-moving subjects, ensuring sharp, blur-free shots.
- Various modes: Photo, Video, Portrait, Night, Pro, Panorama, etc.

# realme P3 Pro (5G)

BORN TO **SLAY**

**Segment's 1<sup>st</sup>**  
**Snapdragon 7s Gen 3**  
5G Chipset



**Segment's Leading**  
Sony **IMX896**  
OIS Camera



**BGMI Tournament** Device Standard

**Segment's Best**  
**Fast Charge** and  
**Battery** Combo



**Segment's Best**  
Dust and Water Resistance  
**IP69**



Image 3.1: Device highlighting camera and display features.

## 3.4. Performance and Connectivity

Powered by the Snapdragon 7s Gen 3 5G chipset, the device offers efficient performance for multitasking, gaming, and streaming. It supports 5G connectivity for faster mobile data speeds. Manage network settings in 'Settings' under 'Mobile Network' or 'Wi-Fi'.

## 3.5. Battery Management

The 6000 mAh battery provides extended usage. To optimize battery life, adjust screen brightness, close unused applications, and enable power-saving modes. The 80W SuperVOOC charging allows for rapid recharging.

## 3.6. Operating System

The Realme P3 Pro 5G runs on Android 14. Regular software updates will be provided to enhance security, add new features, and improve system stability. Ensure your device is connected to Wi-Fi and has sufficient battery before

performing updates.

## 4. MAINTENANCE

---

### 4.1. Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials, as these can damage the display and finish. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner specifically designed for electronics.

### 4.2. Water and Dust Resistance

The Realme P3 Pro 5G features an IP69 rating for water and dust resistance. This means it is protected against high-pressure, high-temperature water jets and dust ingress. While resistant, it is not waterproof. Avoid intentional submersion in water, exposure to seawater, chlorinated water, or liquids other than fresh water. Ensure all ports are dry before charging.

### 4.3. Software Updates

Periodically check for system updates to ensure your device has the latest features and security patches. Navigate to 'Settings' > 'About device' > 'Realme UI version' to check for and install available updates. A stable Wi-Fi connection is recommended for downloads.

### 4.4. Storage Management

Regularly manage your device's storage to maintain optimal performance. Delete unnecessary files, uninstall unused applications, and clear cache data. You can check storage usage in 'Settings' > 'Storage'.

## 5. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your Realme P3 Pro 5G.

- Device not turning on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, press and hold the Power button for 10-15 seconds to force a restart.
- Screen unresponsive:** If the screen freezes, force restart the device by holding the Power button. If the issue persists, consider a factory reset (backup data first).
- Poor battery life:** Check background app usage, reduce screen brightness, disable unnecessary features like GPS or Bluetooth when not in use, and ensure no apps are draining power excessively.
- Network connectivity issues:** Toggle Airplane Mode on and off. Restart the device. Check SIM card installation. Verify network settings and contact your service provider if problems persist.
- Apps crashing:** Clear the cache and data for the problematic app in 'Settings' > 'Apps'. If the issue continues, uninstall and reinstall the app. Ensure the app is updated to its latest version.

## 6. SPECIFICATIONS

---

Detailed technical specifications for the Realme P3 Pro 5G:

Operating System	Android 14
Processor	Snapdragon 7s Gen 3

<b>RAM</b>	8 GB
<b>Display</b>	6.83-inch Quad-Curved 1.5K AMOLED, 120 Hz refresh rate
<b>Resolution</b>	1080 x 2392
<b>Rear Camera</b>	50 MP Sony IMX896 OIS
<b>Front Camera</b>	Not specified (Front)
<b>Battery Capacity</b>	6000 mAh
<b>Charging</b>	80W SuperVOOC Fast Charging
<b>Connectivity</b>	5G, Wi-Fi, Bluetooth, GPS
<b>SIM Type</b>	Dual Nano-SIM
<b>Audio Jack</b>	Type-C
<b>Water &amp; Dust Resistance</b>	IP69
<b>Dimensions (LxWxH)</b>	7.73 x 0.8 x 16.35 cm
<b>Weight</b>	520 g
<b>Model Number</b>	P3 Pro


## 7. WARRANTY AND SUPPORT

Your Realme P3 Pro 5G is covered by a standard manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Realme support website. For technical assistance, troubleshooting, or service requests, please contact Realme customer support.

For further information, you may visit the official [realme Store](#).

© 2025 Realme. All rights reserved.

### Related Documents - P3 Pro



### [Realme RMX3630 Quick Guide and Specifications](#)

Comprehensive quick start guide and detailed technical specifications for the Realme RMX3630 smartphone, covering device layout, camera features, connectivity, package contents, and safety information.




### [Realme GT 2 User Manual - Comprehensive Guide](#)

Official user manual for the Realme GT 2 smartphone (RMX3311), covering setup, features, safety, and specifications. Get the most out of your device.




### [realme UI 2.0 User Guide](#)

Explore the comprehensive features of realme UI 2.0 with this official user guide. Learn about customization options, enhanced performance, advanced privacy settings, and seamless user experience for realme smartphones.




### [Realme GT Neo 3T Smartphone Quick Guide](#)

Concise quick start guide for the Realme GT Neo 3T (RMX3371) smartphone, covering setup, safety, and key specifications. Learn how to use your device efficiently.



### [Realme 14 Pro 5G \(RMX5056\) Quick Start Guide](#)

Concise and accessible HTML guide for the Realme 14 Pro 5G smartphone (RMX5056), covering setup, features, specifications, and safety information.



### [realme 14x 5G Quick Start Guide and Specifications](#)

A concise guide for the realme 14x 5G smartphone, covering device overview, setup instructions, technical specifications, and essential safety and regulatory information. Features include a 120Hz AMOLED display, Dimensity 6300 5G chipset, 50MP camera, and 5000mAh battery with 33W SuperVOOC charging.