

OPPO OPPO A60 CPH2683

OPPO A60 Smartphone User Manual

Model: OPPO A60 CPH2683

INTRODUCTION

Welcome to the user manual for your new OPPO A60 Dual-SIM 5G Smartphone. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance and user experience. Please read this manual thoroughly before using your smartphone.

The OPPO A60 is a powerful and versatile smartphone featuring a 2.4 GHz Octa-core processor, 4GB RAM, 128GB internal storage (expandable via microSDXC), a 6.67-inch IPS LCD display, and a 50 MP main camera. It runs on Android 14 with ColorOS 14 and is equipped with a 5100 mAh non-removable battery.

1. SETUP

1.1. What's in the Box

Upon unboxing your OPPO A60, please verify that the following items are included:

- OPPO A60 Smartphone
- USB Cable
- Quick Start Guide (may vary by region)
- SIM Ejector Tool (may vary by region)

1.2. Device Overview



Figure 1.1: Front and back view of the OPPO A60 smartphone, showcasing the display and rear camera module.



Figure 1.2: Rear view of the OPPO A60, highlighting the dual camera setup and OPPO branding.



Figure 1.3: Right side view of the OPPO A60, showing the power button and volume rocker.



Figure 1.4: Bottom view of the OPPO A60, featuring the USB Type-C port, speaker grille, and 3.5mm headphone jack.



Figure 1.5: Left side view of the OPPO A60, showing the SIM card tray slot.

1.3. Inserting SIM Cards and microSD Card

The OPPO A60 supports Dual-SIM functionality and a microSDXC card for expandable storage. Use the provided SIM ejector tool to open the SIM tray.

1. Locate the SIM tray slot on the left side of the device.
2. Insert the SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM cards into the designated slots (SIM1 and SIM2) with the gold contacts facing down.
4. If using a microSD card, place it into the dedicated microSD slot.
5. Carefully push the tray back into the slot until it is flush with the device.

Important Note:

- This smartphone is designed for GSM networks only and will not work with CDMA networks (e.g., Verizon, Sprint, US Cellular).
- Verify network compatibility with your service provider before use. Refer to the specifications section for supported frequencies.

1.4. Initial Charging and Power On

Before first use, it is recommended to fully charge your OPPO A60.

1. Connect the USB cable to the USB Type-C port at the bottom of the phone.
2. Connect the other end of the USB cable to a compatible power adapter and plug it into a wall outlet.
3. Once sufficiently charged, press and hold the Power button (located on the right side) until the OPPO logo appears.

4. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

2. OPERATING YOUR DEVICE

2.1. Basic Navigation (Android 14 with ColorOS 14)

Your OPPO A60 runs on Android 14 with OPPO's custom ColorOS 14 interface, offering a user-friendly experience.

- **Home Screen:** Swipe left or right to navigate between home screens. Add widgets and app shortcuts by long-pressing on an empty area.
- **Notifications and Quick Settings:** Swipe down from the top of the screen to access notifications and quick settings toggles (Wi-Fi, Bluetooth, etc.).
- **App Drawer:** Swipe up from the bottom of the screen to access all installed applications.
- **Recent Apps:** Swipe up from the bottom and hold (if using gesture navigation) or tap the square navigation button to view recently used applications.
- **Back:** Swipe from the left or right edge of the screen (if using gesture navigation) or tap the back navigation button to go back to the previous screen.

2.2. Camera Usage

The OPPO A60 features a 50 MP main camera for high-quality photos and videos.

1. Open the "Camera" application from your home screen or app drawer.
2. Select your desired mode (Photo, Video, Portrait, Night, etc.) by swiping across the mode selector.
3. Tap on the screen to focus on a specific object.
4. Tap the Shutter button to capture a photo or start/stop video recording.
5. Access settings within the camera app to adjust resolution, aspect ratio, and other parameters.

2.3. Storage Management

Your device comes with 128GB of internal storage, expandable via microSDXC.

- To check storage usage, go to **Settings > About device > Storage**.
- Regularly clear cache and unnecessary files to maintain optimal performance.
- Utilize cloud storage services for backing up photos and videos to free up local space.

3. MAINTENANCE

3.1. Battery Care

The OPPO A60 is equipped with a 5100 mAh non-removable battery. Proper battery care can extend its lifespan.

- Avoid extreme temperatures (hot or cold) as they can degrade battery performance.
- Do not let the battery drain completely to 0% frequently.
- Avoid overcharging; disconnect the charger once the battery reaches 100%.

- Use the original or certified charging accessories.

3.2. Cleaning Your Device

To keep your smartphone clean and functional:

- Use a soft, lint-free cloth to wipe the screen and back panel.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner.
- Avoid using harsh chemicals, abrasive materials, or aerosol sprays.
- Keep liquids away from ports and openings.

3.3. Software Updates

Regular software updates provide new features, security patches, and performance improvements.

- Ensure your device is connected to Wi-Fi and has sufficient battery life before performing an update.
- To check for updates, go to **Settings > About device > Up to date**(or similar option).
- Follow the on-screen prompts to download and install any available updates.

4. TROUBLESHOOTING

This section addresses common issues you might encounter with your OPPO A60.

4.1. Common Issues and Solutions

Problem	Solution
Device not turning on	Ensure the battery is charged. Press and hold the Power button for at least 10-15 seconds.
Poor network signal	Check SIM card insertion. Move to an area with better network coverage. Restart the device. Verify network compatibility with your carrier.
Apps crashing or freezing	Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). Update the app. If the issue persists, uninstall and reinstall the app.
Battery drains quickly	Reduce screen brightness. Close background apps. Disable unnecessary features like GPS, Bluetooth, or Wi-Fi when not in use. Check battery usage in settings to identify power-hungry apps.
Device is slow or unresponsive	Restart the device. Clear unnecessary files and cache. Ensure sufficient free storage space. Consider a factory reset as a last resort (back up data first).

4.2. Factory Reset (Last Resort)

Warning: A factory reset will erase all data on your phone, including apps, photos, and settings. Back up all important data before proceeding.

To perform a factory reset:

1. Go to **Settings > System settings > Back up and reset > Reset phone**
2. Select **Erase all data**.
3. Confirm your decision and enter your lock screen password if prompted.

4. The phone will restart and begin the reset process.

5. SPECIFICATIONS

Detailed technical specifications for the OPPO A60 CPH2683:

- **Model Name:** OPPO A60 CPH2683
- **Operating System:** Android 14, ColorOS 14
- **Processor:** Mediatek Dimensity 6300 (6 nm), Octa-core (2x2.4 GHz Cortex-A76 & 6x2.0 GHz Cortex-A55)
- **Display:** 6.67 inches, IPS LCD, 720 x 1604 pixels, Panda glass
- **RAM:** 4GB
- **Internal Storage:** 128GB (expandable via microSDXC)
- **Main Camera:** 50 MP, f/1.8, (wide), PDAF, Auxiliary lens
- **Front Camera:** 5 MP, f/2.2, (wide)
- **Battery:** Li-Po 5100 mAh, non-removable
- **SIM:** Dual-SIM (Nano-SIM, dual stand-by)
- **Network Compatibility (SIM 1 & SIM 2):**
 - **2G GSM:** 850/ 900/ 1800/ 1900
 - **3G WCDMA:** 900(B8) / 2100(B1)
 - **4G LTE:** 700(B28) / 850(B5) / 900(B8) / 1800(B3) / 2100(B1) / 2300(B40) / 2500(B41)
 - **5G NR:** N1/N3/N5/N8/N28/N41/N77/N78
- **Connectivity:** Wi-Fi, Bluetooth, USB Type-C, 3.5mm headphone jack
- **Color:** Nebula Red
- **Dimensions:** 3.94 x 3.94 x 3.94 inches (Package Dimensions)
- **Item Weight:** 2.2 pounds

6. WARRANTY AND SUPPORT

6.1. Warranty Information

Your OPPO A60 smartphone is covered by a limited manufacturer's warranty. The terms and conditions of the warranty may vary by region and point of purchase. Please refer to the warranty card included with your product or visit the official OPPO website for detailed warranty information.

The warranty typically covers defects in materials and workmanship under normal use. It does not cover damage caused by accidents, misuse, unauthorized repairs, or normal wear and tear.

6.2. Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact OPPO customer support through one of the following methods:

- **Official OPPO Website:** Visit www.oppo.com/en/support/ for FAQs, support articles, and contact options.

- **Service Hotline:** Refer to your regional OPPO website or product packaging for local service hotline numbers.
- **Authorized Service Centers:** Locate the nearest authorized service center via the OPPO website for in-person assistance.

When contacting support, please have your device's model number (OPPO A60 CPH2683) and serial number ready.

© 2025 OPPO. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question