

## AKORD S100

# AKORD S100 Corner Wardrobe Instruction Manual

Model: S100 | Brand: AKORD

### 1. PRODUCT OVERVIEW

The AKORD S100 Corner Wardrobe is designed to maximize storage efficiency in small or narrow spaces. Its compact corner design provides ample storage with a well-thought-out interior featuring 4 doors, 6 shelves, and a hanging rail. This furniture piece is ideal for bedrooms, youth rooms, and hallways, helping to keep your space organized and elegant.

Constructed from 16 mm laminated panel with ABS reinforced edges, the S100 wardrobe offers durability and resistance to abrasion, ensuring a long-lasting and impeccable appearance. Its Craft Oak finish provides a warm and sophisticated touch suitable for various interior styles.



*Image 1.1: The AKORD S100 Corner Wardrobe integrated into a bedroom, showcasing its space-saving design and Craft Oak finish.*

## 2. SAFETY INFORMATION

---

**Warning:** This furniture must be assembled by an adult. Follow the provided assembly instructions carefully to prevent injuries. Ensure the furniture is firmly secured to the floor or wall to prevent accidents and tipping.

## 3. SETUP AND ASSEMBLY

---

The AKORD S100 Corner Wardrobe is delivered disassembled and includes a complete installation kit. For a quick and straightforward setup, please follow these general guidelines:

- 1. Unpack Components:** Carefully unpack all parts and hardware from the packaging. Verify that all components listed in the assembly manual are present.
- 2. Identify Parts:** Lay out all panels and hardware. While some parts may not be explicitly marked, refer to the diagrams in the assembly instructions to identify each piece.
- 3. Follow Instructions:** Assemble the wardrobe step-by-step according to the provided assembly manual. Pay close attention to the orientation of panels and the correct placement of fasteners.
- 4. Secure the Structure:** Once assembled, ensure all screws and connectors are tightened securely. For added

stability and safety, it is highly recommended to anchor the wardrobe to a wall using the provided anti-tip hardware.

**Note:** If the assembly instructions are missing or if you encounter difficulties due to unmarked parts, please contact AKORD customer support for assistance.




Image 3.1: Dimensional drawing of the AKORD S100 Corner Wardrobe, showing overall dimensions and internal measurements.

## 4. OPERATING AND USAGE

---

The AKORD S100 Corner Wardrobe is designed for versatile storage of clothing and personal items. Utilize its features as follows:

- **Shelves:** The 6 internal shelves are perfect for folded garments, accessories, linens, or storage boxes. Distribute weight evenly across the shelves.
- **Hanging Rail:** The integrated hanging rail allows for wrinkle-free storage of shirts, jackets, dresses, and other hanging clothes.
- **Doors:** The 4 doors provide easy access to the wardrobe's contents while keeping items neatly concealed and protected from dust.

This wardrobe is suitable for various rooms, including bedrooms, children's rooms, and entrance halls, offering a practical and aesthetic storage solution.



*Image 4.1: Interior view of the wardrobe, demonstrating the arrangement of shelves and the hanging rail for organized storage.*



*Image 4.2: Detailed view of the wardrobe's interior, highlighting the sturdy shelves and hanging space.*

## 5. MAINTENANCE

To ensure the longevity and appearance of your AKORD S100 Corner Wardrobe, follow these maintenance tips:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the laminated finish. Dry immediately with a clean cloth.
- **Hardware Check:** Periodically check all screws, bolts, and fittings to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.

- **Avoid Overloading:** Do not exceed the weight capacity of the shelves or hanging rail. Distribute weight evenly to prevent warping or damage.
- **Sunlight Exposure:** Avoid prolonged direct exposure to sunlight, which can cause fading or discoloration of the finish over time.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your wardrobe, consider the following common solutions:

- **Wobbly Structure:** This often indicates loose connections. Re-check all assembly points and tighten screws. Ensure the wardrobe is placed on a level surface. If applicable, verify wall anchoring.
- **Doors Not Closing Properly:** Check the hinges. They may need adjustment. Most hinges allow for minor adjustments to align the doors. Ensure no items inside the wardrobe are obstructing the doors.
- **Missing or Unmarked Parts:** If you find parts are missing or difficult to identify during assembly, refer to the assembly manual's parts list and diagrams. If issues persist, contact customer support for replacement parts or clarification.
- **Surface Damage:** For minor scratches or chips, touch-up pens or furniture repair kits matching the Craft Oak finish may be used.

## 7. SPECIFICATIONS

---

Brand	AKORD
Model	S100
Color	Craft Oak
Dimensions (W x D x H)	100 cm x 50 cm x 180 cm
Mounting Type	Floor Mount (Wall anchoring recommended)
Style	Craft Oak
Door Style	Plain Panel
Number of Doors	4
Number of Shelves	6
Included Components	Installation kit

## 8. WARRANTY INFORMATION

---

Specific warranty details for the AKORD S100 Corner Wardrobe may vary depending on your region and the retailer from whom the product was purchased. Please refer to the warranty documentation included with your product or contact your retailer or the manufacturer directly for comprehensive warranty terms and conditions.

## 9. CUSTOMER SUPPORT

---

For further assistance, technical support, or inquiries regarding your AKORD S100 Corner Wardrobe, please contact:

- **Manufacturer:** AKORD
- **Retailer:** [Refer to your purchase receipt for retailer contact information, e.g., Furniture-Akord on Amazon.es]

When contacting support, please have your product model (S100) and purchase details readily available.