

EWEADN X7S

EWEADN X7S Wireless Keyboard User Manual

Model: X7S

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your EWEADN X7S Wireless Keyboard. Designed for versatility, the X7S offers dual-mode connectivity (Bluetooth 5.0 and 2.4GHz wireless), a durable metal panel, and a comfortable typing experience with its unique water drop keycaps and yellow backlighting. Please read this manual thoroughly to ensure optimal performance and longevity of your device.



Image 1.1: The EWEADN X7S Wireless Keyboard, showcasing its full layout and yellow backlighting.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- EWEADN X7S Wireless Keyboard
- USB 2.4GHz Receiver
- Type-C Charging Cable
- User Manual (this document)

3. PRODUCT FEATURES

- **Dual-Mode Connectivity:** Supports both Bluetooth 5.0 and 2.4GHz wireless connections.
- **Rechargeable Battery:** Built-in battery with Type-C charging, allowing use while charging.
- **Premium Construction:** Durable thickened metal panel with a frosted matte finish.
- **Yellow Backlight:** Single warm yellow backlight with 5 brightness levels and a breathing light mode (5 speed settings).

- **Quiet Typing:** Upgraded 'water drop' pudding keycaps and membrane structure for reduced noise (approximately 95% quieter).
- **Ergonomic Design:** Concave and convex keycaps, adjustable feet for a 7° tilt, and 4 non-slip pads for comfortable typing.
- **Anti-Ghosting:** 26-key anti-ghosting technology for simultaneous keystrokes without conflict.
- **Wide Compatibility:** Compatible with Windows, Linux, Chrome OS, and Mac operating systems.



Image 3.1: Overview of the keyboard's dual-mode connectivity and rechargeable feature.

4. SETUP INSTRUCTIONS

4.1 Charging the Keyboard

Before first use, or when the battery is low, connect the keyboard to a power source using the provided Type-C charging cable. A full charge typically takes approximately 3 hours. The keyboard can be used normally while charging.



Image 4.1: The keyboard connected via its Type-C charging cable.

4.2 Power On/Off

Locate the power switch on the bottom of the keyboard. Slide it to the 'ON' position to power on the device. Slide it to 'OFF' to power off.

4.3 Connecting via 2.4GHz Wireless

1. Insert the USB 2.4GHz receiver into an available USB port on your computer.
2. Ensure the keyboard is powered on.
3. Press the **Fn + 1** keys simultaneously to switch to 2.4G mode. The indicator light will confirm the connection.

4.4 Connecting via Bluetooth

The keyboard supports two separate Bluetooth connections (BT1 and BT2).

1. Ensure the keyboard is powered on.
2. Press the **Fn + 2** (for BT1) or **Fn + 3** (for BT2) keys simultaneously. The indicator light will flash, indicating pairing mode.
3. On your device (computer, tablet, smartphone), navigate to Bluetooth settings.
4. Search for available devices and select "X7S__" (or similar name) to pair.
5. Once paired, the indicator light on the keyboard will stop flashing and remain solid.




Image 4.2: Visual representation of 2.4G USB receiver and Bluetooth connectivity.

5. OPERATING INSTRUCTIONS

5.1 Switching Between Modes

To switch between connected devices or modes:

- Press **Fn + 1** for 2.4GHz wireless mode.
- Press **Fn + 2** for Bluetooth 1 mode.
- Press **Fn + 3** for Bluetooth 2 mode.

5.2 Backlight Control

The keyboard features a single yellow backlight with adjustable settings:

- Press **Fn + SL** to turn the backlight ON or OFF.
- Press **Fn + PU** to increase backlight brightness (5 levels).
- Press **Fn + PD** to decrease backlight brightness (5 levels).
- The backlight also supports a breathing light mode; refer to the quick start guide for specific key combinations to activate and adjust breathing speed.



5.3 Ergonomic Design

The keyboard is designed for comfort. Utilize the adjustable feet on the bottom to set a 7° tilt angle for an optimal typing posture. The non-slip pads ensure stability during use.



Image 5.2: Details of the keyboard's ergonomic design, including the foldable stand and anti-slip feet.

6. MAINTENANCE

6.1 Cleaning

To clean your keyboard, power it off and disconnect any cables. Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution. Avoid harsh chemicals or abrasive materials. For dust between keys, use compressed air.

6.2 Battery Care

To prolong battery life, avoid fully discharging the keyboard frequently. Charge it regularly, and if storing for an extended period, ensure it has a partial charge (around 50%).

7. TROUBLESHOOTING

- **Keyboard not responding:**
 - Ensure the keyboard is powered on.
 - Check battery level and charge if necessary.
 - Verify correct mode selection (Fn+1 for 2.4G, Fn+2/3 for Bluetooth).
 - For 2.4G, ensure the USB receiver is securely plugged in.
 - For Bluetooth, re-pair the keyboard with your device.
- **Backlight not working:**
 - Press Fn+SL to toggle the backlight.
 - Adjust brightness using Fn+PU and Fn+PD.
 - Ensure the keyboard has sufficient battery charge.
- **Connectivity issues (lag, disconnections):**

- Ensure the keyboard is within the 33-foot (10-meter) operating range.
- Minimize interference from other wireless devices.
- Recharge the keyboard battery.
- Try connecting to a different USB port for the 2.4G receiver.

8. SPECIFICATIONS

Feature	Detail
Model Number	X7S-03
Connectivity	Bluetooth 5.0, 2.4GHz Wireless
Keyboard Type	Membrane
Backlight	Single Yellow (5 brightness levels, breathing mode)
Keycaps	Water Drop Pudding Keycaps
Anti-Ghosting	26-Key
Power Source	Rechargeable Battery (Type-C)
Material	Metal, Plastic
Item Weight	1.57 pounds
Package Dimensions	19.17 x 6.97 x 2.05 inches
Compatible OS	Windows, Linux, Chrome OS, Mac





9. WARRANTY AND SUPPORT

The EWEADN X7S Wireless Keyboard comes with 24-month brand support. For any questions, technical assistance, or warranty claims, please contact EWEADN customer service. Refer to the product packaging or the official EWEADN website for contact information.



Image 9.1: EWEADN support details, indicating 24-hour reply and 360 days manufacturer support.

Related Documents - X7S

	<p>EWEADN S9 Wireless Mouse User Manual</p> <p>User manual for the EWEADN S9 wireless mouse, providing detailed information on its features, ergonomic design, DPI adjustment, wireless connectivity, setup instructions, and technical specifications. Includes guidance on battery installation and USB receiver usage.</p>
	<p>EWEADN K75 Multi-Mode Wireless Keyboard User Manual and Specifications</p> <p>Detailed guide for the EWEADN K75 keyboard, covering setup, connectivity (2.4G, Bluetooth, Wired), FN key functions, and warranty information. Learn how to use your K75 keyboard with Windows, macOS, iOS, and Android.</p>
	<p>EWEADN X99 Mechanical Keyboard: User Manual and Specifications</p> <p>Comprehensive guide to the EWEADN X99 mechanical keyboard, detailing its features, specifications, setup, and support information. Includes multilingual content overview.</p>
	<p>EWEADN Q9 Transparent Wireless Mouse User Guide</p> <p>This guide provides instructions for setting up and using the EWEADN Q9 Transparent Wireless Mouse, including connection methods (2.4G and Bluetooth), DPI settings, and charging information.</p>
	<p>EWEADN V98 Wireless Keyboard User Manual and Features</p> <p>Comprehensive guide to the EWEADN V98 wireless keyboard, detailing its dual-mode (2.4G and Bluetooth 5.0) connectivity, customizable RGB lighting, multimedia controls, and setup instructions.</p>
	<p>EWEADN TK950 Keyboard User Guide and Features</p> <p>Comprehensive guide to the EWEADN TK950 keyboard, detailing its features, connectivity options (wired, 2.4G, Bluetooth 5.0), lighting effects, and key combinations for gaming and general use. Includes hardware requirements and product specifications.</p>