MIKUSO c039

MIKUSO Wired Keyboard and Mouse User Manual

Model: c039

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your MIKUSO Wired Keyboard and Mouse combo. Designed for comfort and reliability, this set features both Arabic and English characters, making it suitable for a wide range of users. Its durable construction ensures long-lasting performance for daily use.



Figure 1: MIKUSO Wired Keyboard and Mouse Combo. This image displays the full keyboard and mouse set, highlighting their wired connection and ergonomic design.

Package Contents

Please check the package contents upon unboxing to ensure all items are present:

- 1 x MIKUSO Wired Keyboard (Arabic/English Layout)
- 1 x MIKUSO Wired Mouse
- 1 x User Manual (this document)

Setup

Setting up your MIKUSO Wired Keyboard and Mouse is straightforward. No drivers are typically required for basic functionality, as they are plug-and-play devices.

1. **Connect the Keyboard:** Locate an available USB port on your computer (desktop, laptop, or tablet with USB support). Insert the USB connector of the MIKUSO keyboard firmly into the USB port.
2. **Connect the Mouse:** Locate another available USB port on your computer. Insert the USB connector of the MIKUSO mouse firmly into the USB port.
3. **System Recognition:** Your operating system should automatically detect and install the necessary drivers for the keyboard and mouse. This process usually takes a few seconds.
4. **Test Functionality:** Once recognized, test the keyboard by typing in a text editor and test the mouse by moving the cursor and clicking.



Figure 2: MIKUSO Wired Keyboard Layout. This image provides a clear top-down view of the keyboard, showcasing its full layout with both Arabic and English characters on the keys.

Operating Instructions

Keyboard Usage

The MIKUSO keyboard features a standard QWERTY layout with additional Arabic characters. It includes a full numeric keypad and function keys (F1-F12).

- **Typing:** Simply press the desired keys to input text. The dual-language layout allows for easy switching between English and Arabic input methods via your operating system's language settings.
- **Function Keys:** F1-F12 keys perform various functions depending on the application or operating system.
- **Numeric Keypad:** Use the dedicated numeric keypad for efficient data entry. Ensure 'Num Lock' is active (indicated by an LED light, if present).

Mouse Usage

The MIKUSO mouse is a standard 3-button optical mouse, providing precise tracking and comfortable use.

- **Left Click:** Primary button for selecting items, opening files, and confirming actions.
- **Right Click:** Secondary button for opening context menus and accessing additional options.
- **Scroll Wheel:** Roll the wheel up or down to scroll through documents and web pages. The scroll wheel can also be pressed as a middle click button for specific functions (e.g., opening links in new tabs).

Maintenance

Proper care and maintenance will extend the lifespan of your MIKUSO keyboard and mouse.

- **Cleaning:**
  - **Keyboard:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface. For dust and debris between keys, use compressed air. Do not immerse the keyboard in liquid.
  - **Mouse:** Wipe the surface with a soft, damp cloth. Clean the optical sensor area on the bottom of the mouse with a dry cotton swab if tracking issues occur.
- **Storage:** When not in use for extended periods, store the keyboard and mouse in a dry, cool place away from direct sunlight and extreme temperatures.
- **Avoid Spills:** Keep liquids away from the devices to prevent damage. In case of a spill, immediately disconnect the device from the computer and allow it to dry completely before reconnecting.



Figure 3: MIKUSO Wired Keyboard Underside. This image shows the bottom of the keyboard, highlighting its sturdy construction and any drainage features.

Troubleshooting

If you encounter issues with your MIKUSO keyboard or mouse, try the following troubleshooting steps:

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Loose USB connection, faulty USB port, driver issue.	Ensure USB cables are securely plugged into the computer. Try plugging into a different USB port. Restart your computer. Check Device Manager (Windows) or System Information (macOS) for driver status.
Mouse cursor erratic or not moving smoothly	Dirty optical sensor, unsuitable surface.	Clean the optical sensor on the bottom of the mouse with a dry cotton swab. Use the mouse on a clean, non-reflective, opaque surface (e.g., a mouse pad).
Keys not registering or stuck	Debris under keys, physical damage.	Use compressed air to clear debris from under the keys. If a key is physically stuck, gently try to dislodge any visible obstruction.

Specifications

Below are the technical specifications for the MIKUSO Wired Keyboard and Mouse combo:

Feature	Detail
Brand	MIKUSO
Model Number	c039
Connectivity Technology	USB Wired
Keyboard Layout	QWERTY (Arabic/English)
Color	Black
Power Source	Corded Electric (USB powered)
Compatible Devices	Desktop, Laptop, Tablet (with USB support)
Item Weight	540 g
Package Dimensions	51.6 x 14.9 x 4.6 cm



Figure 4: MIKUSO Wired Keyboard Dimensions. This image illustrates the approximate dimensions of the keyboard, indicating its compact design.

Warranty and Support

MIKUSO products are manufactured to high-quality standards. For warranty information or technical support, please refer to the retailer where you purchased the product or visit the official MIKUSO website for contact details.
Please retain your proof of purchase for any warranty claims.

© 2025 MIKUSO. All rights reserved.