

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [WINNY POOL CLEANER](#) /

› [Cordless Robotic Pool Cleaner for Above Ground Pools, 130-Mins Runtime Pool Cleaner with Self-Parking & 1300 Sq. Ft Coverage, Powerful Suction & 6600mAh Battery for Longer Lifespan \(White&Green\)](#)

WINNY POOL CLEANER HJ1103SK

WINNY POOL CLEANER

CORDLESS ROBOTIC POOL CLEANER

Model: HJ1103SK

Introduction

Thank you for choosing the WINNY POOL CLEANER Cordless Robotic Pool Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new pool cleaner. Designed for above-ground pools, this robotic cleaner offers powerful, hassle-free cleaning with its advanced features and cordless design.



The WINNY Cordless Robotic Pool Cleaner, featuring a sleek white and green design, ready for operation.

Packing List

Please verify that all items are present in the package:

- Pool cleaner x 1
- Power adapter x 1
- Flippers & handle x 1
- Scraper x 2
- Retrieving hook x 1
- User manual x 1
- Quick Guide x 1





Visual representation of the items included in the WINNY Pool Cleaner package.

Setup

1. **Charge the Cleaner:** Before first use, fully charge the pool cleaner using the provided power adapter. The LED indicator will show charging status.
2. **Attach Components:** Securely attach the flippers and handle to the cleaner. Ensure the scraper is properly installed if needed for specific debris.
3. **Placement:** Gently lower the cleaner into your pool. Ensure it is fully submerged before activation.
4. **Activate:** Press the one-click start button. The LED indicator will illuminate, signaling that the cleaner is active and beginning its cleaning cycle.

Fits All Pools Of Different Shapes



The simple one-click start mechanism and LED indicator for operational status.

Operating the Cleaner

The WINNY Robotic Pool Cleaner is designed for autonomous operation, providing efficient cleaning for your above-ground pool.

- **Runtime:** Enjoy up to 130 minutes of continuous cleaning on a single charge, sufficient for pools up to 1300 sq. ft.
- **Powerful Suction:** Equipped with an upgraded motor, it delivers a powerful 2640 GPH suction rate, effectively

collecting leaves, debris, and fine dirt.

- **Dual-Layer Filtration:** Features a 180µm fine mesh and a foam filter to capture ultra-fine particles, ensuring visibly clearer water.
- **Smart Self-Parking:** When the battery is low, the cleaner automatically navigates to the pool edge for easy retrieval.
- **Cycle Timer:** Utilize the built-in scheduling feature for automatic daily cleaning, eliminating the need for manual resets for up to 7 days.

Efficient Cleaning

Strong suction & Superior mobility



Leaves



Hair



Floating Algae



Sand



Max.15-degree
slope



The cleaner efficiently removing leaves and debris from the pool floor.

Smart Sensor Technology

Stop near the pool side when battery is low



The smart sensor technology allows the cleaner to detect low battery and self-park near the pool edge.

Maintenance

Regular maintenance ensures optimal performance and longevity of your WINNY Pool Cleaner.

- **Clean Debris Compartment:** The high-capacity debris compartment should be emptied and rinsed regularly. This reduces the frequency of emptying and ensures uninterrupted cleaning.
- **Rinse Filter:** After each use, remove the filter and rinse it thoroughly with a hose to remove trapped dirt, sand, and other particles.
- **Water Release:** The cleaner features 'Lock Dirt and Debris Technology 3.0' allowing water to drain in 5 seconds with no leakage, making it easy to lift and clean.



Lock Dirt and Debris Technology 3.0

Drain water in 5 seconds with No leakage

The cleaner's design allows for quick water drainage and easy debris removal.

Easy to Retrieve & Lightweight

Faster-water Release for portability



The lightweight design and retrieving hook make it easy to lift the cleaner from the pool.

Troubleshooting

If you encounter issues with your pool cleaner, please refer to the following common solutions:

- **Cleaner not moving or stopping prematurely:** Ensure the battery is fully charged. Check for any obstructions in the wheels or suction port.
- **Poor suction or cleaning performance:** Clean the debris compartment and filters thoroughly. Ensure the cleaner is fully submerged and operating on a flat surface.
- **Cleaner not parking at pool edge:** Verify that the water depth is within the specified range (less than 8.2 ft) and there are no large obstructions preventing it from reaching the wall.

For persistent issues, please contact customer support.

Specifications

Feature	Detail
Model Name	HJ1103SK
Brand	WINNY POOL CLEANER
Power Source	AC (for charging)
Special Features	Cycle Timer, High-Suction Motor, Auto-Park at Pool Edge, 180µm Filter
Battery Type	Lithium Battery (6600mAh)
Runtime	130 Minutes
Coverage Area	Up to 1300 sq. ft.
Product Dimensions	15.35"L x 12.2"W x 17.72"H
Item Weight	16.57 pounds
Material	Plastic
Color	White&Green

Warranty and Support

This product comes with a Manufacturer Warranty. For warranty claims, technical support, or any inquiries, please contact WINNY POOL CLEANER customer service through the retailer where you purchased the product or visit the official WINNY POOL CLEANER website for contact information.

Please retain your proof of purchase for warranty purposes.