

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Walfront](#) /

› [Walfront 48V Cordless Leaf Blower User Manual](#)

Walfront WALFRONT0vyos4zi9g-11

Walfront 48V Cordless Leaf Blower User Manual

Model: WALFRONT0vyos4zi9g-11

1. INTRODUCTION

Thank you for choosing the Walfront 48V Cordless Leaf Blower. This manual provides essential information for the safe operation, assembly, maintenance, and troubleshooting of your new leaf blower. Please read this manual thoroughly before first use and keep it for future reference.



Figure 1: Walfront 48V Cordless Leaf Blower, fully assembled.

2. SAFETY INSTRUCTIONS

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- **Read All Instructions:** Familiarize yourself with the controls and proper use of the appliance.
- **Wear Eye Protection:** Always wear safety glasses or goggles when operating the blower.
- **Wear Hearing Protection:** Prolonged use may require ear protection.
- **Dress Properly:** Do not wear loose clothing or jewelry that could get caught in moving parts. Wear sturdy footwear.
- **Keep Area Clear:** Ensure children, bystanders, and pets are at a safe distance from the operating area.
- **Avoid Unintentional Starting:** Ensure the switch is in the off position before inserting the battery pack.
- **Use Correct Battery and Charger:** Only use the battery and charger specified by the manufacturer.
- **Do Not Operate in Explosive Atmospheres:** Do not use the blower in the presence of flammable liquids, gases, or dust.
- **Maintain Appliance:** Keep handles dry, clean, and free from oil and grease. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the appliance's operation.
- **Disconnect Battery:** Remove the battery pack before making any adjustments, changing accessories, or storing the appliance.
- **Do Not Abuse the Cord:** Never carry the charger by its cord or yank it to disconnect from an outlet.
- **Store Idle Appliances:** When not in use, store the blower in a dry, high, or locked-up place out of reach of children.

3. PRODUCT COMPONENTS

The Walfront 48V Cordless Leaf Blower kit includes the following components:

- Blower Unit
- 48VH Battery (12000mAh)
- Battery Charger (Adapter)
- Vacuum Hose
- Dust Bag
- Air Duct
- Wide Nozzle
- Narrow Nozzle
- Adapter Parts (3 pieces)



Figure 2: All included components of the Walfront 48V Cordless Leaf Blower kit.

4. SPECIFICATIONS

Feature	Specification
Item Type	Cordless Leaf Blower
Brand	Walfront
Model Number	WALFRONT0vyos4zi9g-11
Material	ABS
Battery Type	48VH Lithium-ion Battery
Battery Capacity	12000mAh
Approximate Size (L x W)	500 x 200mm / 19.7 x 7.9in

5. SETUP AND ASSEMBLY

Follow these steps to assemble your Walfront Cordless Leaf Blower:

1. **Charge the Battery:** Before first use, fully charge the 48VH battery using the provided charger. Connect the charger to a standard power outlet and then to the battery. The charging indicator on the battery or charger will show when charging is complete.
2. **Attach the Nozzle/Air Duct:** Select the desired nozzle (wide or narrow) or the air duct for vacuuming. Align

the nozzle/duct with the blower's outlet and twist or push firmly until it locks into place.



Figure 3: Detail of the nozzle connection point.

3. **Install the Battery:** Slide the fully charged battery pack into the battery slot on the bottom of the blower unit until it clicks securely into place. Ensure it is firmly seated to prevent accidental disconnection during operation.
4. **For Vacuum Function (Optional):** If using as a vacuum, attach the vacuum hose to the intake port (usually on the side of the blower unit) and secure the dust bag to the exhaust port.

6. OPERATING INSTRUCTIONS

Once assembled and the battery is charged, your leaf blower is ready for use.

1. **Starting the Blower:** Hold the blower firmly with one hand on the handle. Press the power switch (trigger) to start the motor. The blower will begin to operate.
2. **Controlling Airflow:** The blower may have a variable speed trigger or a speed selector switch. Adjust the speed as needed for the task. Lower speeds are suitable for delicate areas, while higher speeds are for stubborn debris.
3. **Blowing Technique:**
 - Sweep debris into piles using a side-to-side motion.

- Work away from buildings, fences, and other obstacles.
- Use the narrow nozzle for concentrated airflow and the wide nozzle for broader coverage.

4. Vacuuming Technique (if applicable):

- Ensure the vacuum hose and dust bag are correctly installed.
- Move the vacuum hose over the debris to collect it into the dust bag.
- Empty the dust bag regularly to maintain suction efficiency.

5. **Stopping the Blower:** Release the power switch (trigger) to turn off the blower.

6. **After Use:** Remove the battery pack from the blower after each use.

Versatile and Efficient

This handheld leaf blower is suitable for blowing lawns, lanes, terraces, and various other places, easily and quickly removing leaves and debris, greatly improving work efficiency



Figure 4: Example of the leaf blower in operation, demonstrating its versatile and efficient use.

7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your leaf blower. Always disconnect the battery before performing any maintenance.

• Cleaning:

- Wipe the exterior of the blower with a damp cloth. Do not use strong detergents or solvents.

- Clear any debris from the air intake and exhaust vents to prevent overheating.
 - If using the vacuum function, empty and clean the dust bag after each use.
- **Battery Care:**
 - Store the battery in a cool, dry place away from direct sunlight and extreme temperatures.
 - Do not store the battery fully discharged for extended periods. Charge it periodically if not in use.
 - Do not expose the battery to water or moisture.
 - **Storage:** Store the blower and its accessories in a dry, secure location, out of reach of children.

8. TROUBLESHOOTING

If you encounter issues with your leaf blower, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blower does not start	Battery not charged or improperly installed.	Ensure battery is fully charged and securely inserted.
Reduced airflow/suction	Nozzle/duct blocked, dust bag full (for vacuum), or air vents obstructed.	Clear any blockages, empty dust bag, and clean air vents.
Blower stops during operation	Battery is depleted or overheating.	Recharge battery. Allow blower to cool down if it feels hot.
Unusual noise or vibration	Loose parts or foreign object inside.	Turn off and remove battery. Inspect for loose parts or obstructions. Do not operate if problem persists.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Walfront customer service. Keep your purchase receipt as proof of purchase.

Online Support: Visit the Walfront official website for FAQs and support resources.