

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Ruitoo](#) /

› Ruitoo Electric Scooter T2 Max User Manual

Ruitoo T2 Max (27 Mph 28 Miles)

Ruitoo Electric Scooter User Manual

Model: T2 Max (27 Mph 28 Miles)

Brand: Ruitoo

INTRODUCTION

This user manual provides essential information for the safe operation, maintenance, and troubleshooting of your Ruitoo T2 Max Electric Scooter. Please read this manual thoroughly before your first ride to ensure proper use and to maximize the lifespan of your scooter.



Figure 1: Ruitoo T2 Max Electric Scooter

The Ruitoo T2 Max Electric Scooter is designed for urban commuting and off-road adventures, featuring a powerful motor, long-range battery, and robust suspension system.

Safety Information

Your safety is paramount. Always adhere to the following safety guidelines:

- Always wear a helmet and appropriate safety gear (knee pads, elbow pads) when riding.
- Do not ride under the influence of alcohol or drugs.
- Obey all local traffic laws and regulations.
- Avoid riding in heavy rain, snow, or icy conditions. The scooter has IPX5 water resistance, but it is not fully submersible.
- Maintain a safe distance from other vehicles and pedestrians.
- Check brakes, tires, and battery level before each ride.
- Do not perform stunts or sudden maneuvers.

- The maximum load capacity is 265 lbs. Do not exceed this limit.
- Ensure the folding mechanism is securely locked before riding.

PACKAGE CONTENTS

Upon opening the package, verify that all items are present and in good condition:

- 1 x Ruitoo Electric Scooter (T2 Max)
- 1 x Charger
- 1 x Installation Tools
- 1 x User Manual




Figure 2: Included components: Electric Scooter, Charger, Installation Tools, and Manual.

SETUP AND ASSEMBLY

The Ruitoo T2 Max Electric Scooter comes largely pre-assembled. Follow these steps for final setup:

1. **Unfolding the Scooter:** Carefully lift the handlebar stem until it clicks into place. Secure the locking mechanism.
2. **Handlebar Installation:** Attach the handlebars to the stem, ensuring they are firmly secured. Use the provided tools if necessary.
3. **Initial Charge:** Before first use, fully charge the scooter's battery. Connect the charger to the charging port and plug it into a power outlet. The indicator light on the charger will change when fully charged.
4. **Tire Pressure Check:** Ensure tires are inflated to the recommended pressure for optimal performance and safety.

OPERATING INSTRUCTIONS

A. Controls and Display

Comfort & Control

Ergonomic Design for Smooth Riding




Figure 3: Handlebar controls and Smart LCD Display.

The intuitive LCD display provides real-time data such as speed, battery level, and riding mode. Key controls include the power button, turn ON/OFF switch, brake handles, horn key, and acceleration pointer.

- **Power On/Off:** Press and hold the power button to turn the scooter on or off.
- **Acceleration:** Use the acceleration pointer on the right handlebar to control speed.
- **Braking:** The scooter features a dual brake system (front and rear). Apply both brake levers for effective stopping.
- **Lighting:** The 360° lighting system includes a front light, brake light, and turn signals for enhanced visibility. Activate

lights via the control panel.

- **Riding Modes:** The scooter may offer multiple riding modes (e.g., Eco, Standard, Sport) accessible via the display or a dedicated button. Refer to the display for current mode.

B. Riding Your Scooter

1. **Starting:** Place one foot on the deck and push off with the other foot to gain initial momentum. Once moving, gently press the acceleration pointer.
2. **Steering:** Lean slightly in the direction you wish to turn and gently turn the handlebars.
3. **Braking:** Release the acceleration and gently squeeze the brake levers. Apply both brakes simultaneously for emergency stops.
4. **Folding:** To fold the scooter for storage or transport, disengage the locking mechanism on the stem and fold the handlebar stem down towards the deck. Ensure it latches securely.



Figure 4: The scooter's foldable design allows for easy storage and transport.

The Ruitoo T2 Max is designed for quick folding, making it convenient for storage in car trunks or other compact spaces.



Figure 5: The 1000W motor provides strong hill-climbing capability.

The powerful 1000W motor allows the T2 Max to conquer inclines of up to 30%.

MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your scooter.

- **Cleaning:** Wipe the scooter with a damp cloth. Do not use high-pressure water jets or immerse the scooter in water.
- **Battery Care:**
 - Charge the battery fully before long-term storage.
 - Recharge the battery at least once every 30 days, even if not in use, to prevent deep discharge.
 - Avoid exposing the battery to extreme temperatures.
- **Tires:** Regularly check tire pressure and inspect for wear or damage. Replace worn tires promptly.
- **Brakes:** Inspect brake pads and cables periodically. Adjust or replace as needed to ensure responsive braking.
- **Fasteners:** Check all screws and bolts regularly and tighten any that are loose.

TROUBLESHOOTING

This section addresses common issues you might encounter:

Problem	Possible Cause	Solution
Scooter does not turn on	Low battery; Power button not pressed correctly; Loose connections.	Charge the battery; Press and hold the power button firmly; Check all visible cable connections.
Reduced range or speed	Under-inflated tires; Low battery charge; Riding uphill frequently; Heavy load.	Inflate tires to recommended pressure; Fully charge battery; Adjust riding style; Reduce load.
Brakes feel loose or ineffective	Brake cable needs adjustment; Worn brake pads.	Adjust brake cable tension; Inspect and replace brake pads if worn.
Unusual noises during operation	Loose components; Debris in wheels; Motor issue.	Check all fasteners; Inspect wheels for obstructions; Contact customer support if motor noise persists.

SPECIFICATIONS

Feature	Detail
Model	T2 Max
Motor Power	1000W
Top Speed	Up to 27 mph
Max Range	Up to 28 miles
Battery	48V/15.6Ah
Wheel Size	10 Inches (Pneumatic Off-Road Tires)
Max Load	265 lbs
Frame Material	Aluminum Alloy Steel
Brake System	Dual Brake System (Front & Rear)

Feature	Detail
Special Features	Adjustable Handlebar Height, Digital Display, Foldable, 360° Safety Lighting, Dual Suspension, IPX5 Waterproof

WARRANTY AND SUPPORT

Ruitoo offers a 365-day warranty for different components of your electric scooter. For warranty claims, technical support, or any inquiries, please contact Ruitoo customer service. Refer to the contact information provided with your purchase documentation or visit the official Ruitoo website.

We are committed to providing reliable customer support and ensuring your satisfaction.

© 2025 Ruitoo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What are the values for the P3 and P4 settings on the Ruitoo T2 Max electric scooter?

The provided manual for the Ruitoo T2 Max describes the Smart LCD Display and riding modes but does not explicitly list the full "P-setting" (parameter) menu values such as P3 and P4. In most...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0DYN73LYQ>

More documents and user manuals: <https://manuals.plus/>