Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- AMEIFU /
- > AMEIFU F2 Air Purifier User Manual

AMEIFU F2

AMEIFU F2 Air Purifier User Manual

Model: F2

Safety Instructions Product

Components Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your AMEIFU F2 Air Purifier. Please read it thoroughly before use and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before operating the appliance.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.
- Unplug the air purifier before moving, cleaning, or performing any maintenance.
- Keep the air purifier away from water or other liquids.
- Do not block air inlets or outlets.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

• Children should be supervised to ensure that they do not play with the appliance.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your AMEIFU F2 Air Purifier:

- Air Purifier Unit (Main Body)
- H13 HEPA Filter (Pre-installed)
- · Power Cord
- Aromatherapy Pad (inside the unit)



Image: The AMEIFU F2 Air Purifier, showing its compact design and the top opening for aromatherapy oil application.

SETUP GUIDE

- 1. Unpack the Air Purifier: Carefully remove the unit from its packaging.
- 2. Remove Filter Packaging: The power cord and filter are placed inside the product for shipping.
 - Turn the unit upside down and twist the base cover counter-clockwise to unlock.

- Remove the base cover and take out the H13 HEPA filter.
- Remove all plastic packaging from the filter.
- Place the unwrapped filter back into the unit.
- · Replace the base cover and twist clockwise to lock it securely.
- 3. **Position the Unit:** Place the air purifier on a flat, stable surface. Ensure there is at least 6 inches (15 cm) of space around all sides for optimal airflow.
- 4. Connect Power: Plug the power cord into a standard electrical outlet.



Image: An exploded view illustrating the 3-stage filtration system: Pre-Filter, H13 HEPA Filter, and Activated Carbon Filter.

OPERATING INSTRUCTIONS

Control Panel Overview

The AMEIFU F2 Air Purifier features a smart touch control panel with the following functions:

- Power Button: Turns the unit on/off.
- Light Button: Controls the display light.
- Mode Button: Cycles through fan speeds (L1, L2, L3, Auto) and Sleep Mode.

- **Timer Button:** Sets the operating timer (2h, 4h, 8h, 12h).
- Child Lock Button: Activates/deactivates the child lock.
- Filter Reset Indicator: Lights up when filter replacement is needed.



Image: Close-up of the air purifier's smart touch control panel, highlighting the various function buttons.

Initial Power On

After plugging in, the air purifier will enter a preheating state. The indicator light will flash for approximately one minute as it calibrates the air quality sensor.

Air Quality Indicator

The unit features a real-time air quality sensor. The light color indicates current air quality:

- Green: Good air quality.
- Blue: Minor pollution detected.
- Red: Severe pollution detected.

Fan Speed Settings

Press the "Mode" button to cycle through the following fan speeds:

- L1 (Low): Quiet operation, suitable for sleeping.
- L2 (Medium): Balanced performance for daily use.
- L3 (High): Maximum purification for quick cleaning.
- Auto Mode: Adjusts fan speed automatically based on detected air quality.

Sleep Mode

Activate Sleep Mode by pressing the "Mode" button until it is selected. In this mode, the fan operates at a low noise level (less than 15dB), and the display screen turns off automatically after one minute to ensure an undisturbed environment. L1 or Auto speed is recommended for sleeping.



Image: A child sleeping, with the air purifier nearby, demonstrating its low noise level (15dB) in sleep mode.

Timer Function

Press the "Timer" button to set the operating duration. Available settings are 2 hours, 4 hours, 8 hours, and 12 hours. The unit will automatically turn off after the set time.

Child Lock

To activate the Child Lock, press and hold the "Child Lock" button for a few seconds. This prevents accidental changes to settings. Repeat the action to deactivate the Child Lock.



Image: A child and a dog playing near the air purifier, highlighting the child lock feature for safety.

Aromatherapy Function

To use the aromatherapy function:

- 1. Locate the aroma pad on the top of the unit.
- 2. Add a few drops of your preferred essential oil (not included) onto the aroma pad.
- 3. The fragrance will be diffused with the purified air.



Image: A woman adding essential oil to the top of the air purifier, demonstrating the aromatherapy feature.

MAINTENANCE

Filter Replacement

The filter reset indicator light will flash after approximately 2160 hours of use, prompting you to replace the filter. For optimal performance, replace the filter every 3-6 months, depending on usage and air quality.

- 1. Unplug the air purifier from the power outlet.
- 2. Turn the unit upside down and twist the base cover counter-clockwise to unlock.
- 3. Remove the old filter and dispose of it properly.
- 4. Insert a new AMEIFU H13 HEPA replacement filter (search B0DK574MDG on Amazon). Ensure it is correctly seated.
- 5. Replace the base cover and twist clockwise to lock it securely.
- 6. Plug the unit back in. Press and hold the "Filter Reset" button for 3-5 seconds until the indicator light turns off to reset the filter timer.

Note: Do not wash the filter. The filter is not reusable.

Cleaning the Unit

- Always unplug the air purifier before cleaning.
- Wipe the exterior of the unit with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- Periodically vacuum the air inlet vents to remove dust and debris.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	Power cord not securely plugged in. No power from outlet. Filter not installed correctly or packaging not removed.	Check power cord connection. Test outlet with another device. Ensure filter packaging is removed and filter is correctly seated, then base cover is locked.
Airflow is weak or noise is excessive.	Air inlets/outlets blocked. Filter is dirty or clogged. Unit is on a low fan speed.	Clear any obstructions. Replace the filter if the filter reset indicator is on or if it appears visibly dirty. Increase fan speed.
Air quality indicator always red/blue despite clean environment.	Sensor may be dirty. Unit is in preheating state.	Gently clean the sensor area (refer to manual for location). Wait one minute after power on for calibration.
Filter reset light remains on after filter change.	Filter timer not reset.	Press and hold the "Filter Reset" button for 3-5 seconds until the light turns off.

SPECIFICATIONS

Feature	Detail
Model Number	F2
Brand	AMEIFU
Product Dimensions	7.3"D x 7.3"W x 11.2"H
Weight	3.24 Pounds
Coverage Area	Up to 1200 Sq Ft
Filtration Type	H13 HEPA 3-Stage Filtration (Pre-filter, H13 HEPA, Activated Carbon)
Fan Speeds	3 (L1, L2, L3) + Auto Mode
Timer Settings	2h, 4h, 8h, 12h

Feature	Detail
Noise Level (Sleep Mode)	Less than 15dB
Special Features	Real-Time Air Quality Sensor, Child Lock, Aromatherapy Function, Filter Reset Reminder
Wattage	6 watts
Certifications	CARB Certified, CE Certified, EPA Certified, ETL Certified, FCC Certified

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact AMEIFU customer service directly. Keep your purchase receipt as proof of purchase.

Replacement Filter: The official replacement filter can be purchased on Amazon by searching for ASIN B0DK574MDG.

© 2025 AMEIFU. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.

Related Documents - F2

ANEIFU AIR PURIFIER USER MANUAL WWW. mysmedia com	AMEIFU AP01 Air Purifier User Manual Comprehensive user manual for the AMEIFU AP01 air purifier, detailing product overview, operation, safety, maintenance, and troubleshooting. Learn how to effectively use and care for your AMEIFU air purifier.
PA-PANENEEE	Ameifu FXAP2W Air Purifier User Manual User manual for the Ameifu FXAP2W Air Purifier, providing instructions on setup, operation, maintenance, and troubleshooting for optimal home air quality.
ANEIFU AIR PURIFIER USER MANUAL (AIT SOST INTERNALLAL (AIT SOST	AMEIFU Air Purifier User Manual Comprehensive user manual for the AMEIFU Air Purifier, detailing product features, specifications, operation, maintenance, safety precautions, and troubleshooting.
GDAPW世界书, 於1326年246年 村京 20mg學教養更要	AMEIFU FXAP2W Air Purifier User Manual Comprehensive user manual for the AMEIFU FXAP2W Air Purifier, covering product introduction, overview, operation, maintenance, troubleshooting, and safety guidelines.



AMEIFU Air Purifier User Manual H2078G-W

User manual for the AMEIFU Air Purifier, model H2078G-W. Provides instructions on operation, maintenance, safety precautions, and technical specifications.



AMEIFU F1 Air Purifier User Manual: Features, Operation & Maintenance

Comprehensive user manual for the AMEIFU F1 Air Purifier. Learn about its 3-stage filtration system, operation modes, installation, maintenance, and troubleshooting. Features quiet operation and 100% ozone-free air purification.