

## FOHERE BW609

# FOHERE Food Warming Mat

MODEL: BW609

User Manual

## 1. Safety Information

---

Please read all instructions carefully before using the FOHERE Food Warming Mat. Retain this manual for future reference.

- **Electrical Safety:** Ensure the power cord is fully inserted into a grounded outlet. Do not use if the cord or plug is damaged. Keep away from water to prevent electric shock.
- **Heat Warning:** The mat surface becomes hot during operation. Avoid direct contact with bare skin. Always use heat-resistant cookware.
- **Placement:** Place the mat on a stable, heat-resistant surface. Do not place on flammable materials. Ensure adequate ventilation around the mat.
- **Child Safety:** This appliance is not intended for use by children. Use the child lock function to prevent accidental operation.
- **Overheating Protection:** The mat features an automatic shut-off function after 3 hours of no operation to prevent overheating.

## 2. Product Overview

---

The FOHERE Food Warming Mat is designed to keep your food warm and fresh. It features dual-zone heating, adjustable temperature settings, and a convenient timer function. Its foldable design and durable silicone material make it ideal for various uses.

- **Dual-Zone Heating:** Independently set temperatures for the left and right zones (100°F, 140°F, 180°F, 212°F).
- **4 Temperature Levels:** Select from 100°F, 140°F, 180°F, or 212°F to suit different food types.

- **3 Timer Settings:** Keep food warm for 1, 2, or 4 hours.
- **Large & Foldable Design:** Measures 24.2 x 16.5 inches, providing ample space for multiple dishes, and folds for easy storage.
- **Child Lock:** Prevents accidental changes to settings.
- **Automatic Shut-off:** Turns off after 3 hours of inactivity.
- **Premium Silicone Material:** Durable, easy to clean, splash-proof, water-resistant, and compatible with various cookware.

### 3. Setup

---

1. **Unpack:** Carefully remove the warming mat and all accessories from the packaging.
2. **Unroll:** Unroll the mat completely and place it on a flat, stable, and heat-resistant countertop or table.
3. **Connect Power:** Insert the detachable power cord into the designated port on the mat and then plug it into a standard electrical outlet.

# Customise Zone Temperature

Maintain the great flavours of different foods



\*Temperature control range from 100°F to 212°F.

Image: The FOHERE Food Warming Mat unrolled and ready for use on a kitchen counter.

## 4. Operating Instructions

### 4.1 Power On/Off

- Press and hold the power button (U) for 2 seconds to turn the mat on or off.

## 4.2 Temperature Settings

The mat offers four temperature levels: 100°F, 140°F, 180°F, and 212°F.

- After powering on, press the temperature button (F) to cycle through the available temperature settings. The selected temperature will be indicated by an LED light.



## 4 Temperature Settings

Touch to switch between different temperature levels

*Image: Close-up of the control panel showing temperature selection.*

## 4.3 Dual-Zone Heating

The mat features two independent heating zones (left and right) that can be set to different temperatures.

- To adjust the temperature for each zone, use the dedicated zone selection buttons (A/B or similar, if present on your model) and then the temperature button. Refer to the on-screen indicators for current zone settings.



*Image: The warming mat with food on both zones, illustrating independent temperature control.*

#### **4.4 Timer Function**

Set a timer to maintain food warmth for a specific duration.

- Press the timer button (**T**) to select 1, 2, or 4 hours. The timer indicator will light up accordingly.

# Easy to Clean and Storage



Image: The warming mat with food and the timer function active.

## 4.5 Child Lock

- To activate or deactivate the child lock, press and hold the child lock button (often indicated by a lock icon) for 2 seconds.

## 4.6 Automatic Shut-off

- The mat will automatically shut off if there is no operation for 3 hours. This is a safety feature to prevent prolonged heating.

## 4.7 Compatible Cookware

The FOHERE Food Warming Mat is compatible with various types of heat-resistant tableware.

- Suitable materials include glass, enamel-coated pots, ceramic, frying pans, stainless steel, and even baby bottles.

# Compatible with Various Tableware



Glass



Enamel-coated pot



Ceramic



Frying pan



Stainless steel



Milk bottle

*Image: Examples of compatible tableware for the warming mat.*

## 4.8 Versatile Uses

Beyond keeping meals warm, the mat can be used for:

- Warming drinks (coffee, tea, milk)
- Thawing frozen foods
- Dough fermentation
- Melting chocolate

## More than A Simple Warming Tray

This warming tray is a great helper for your household life



Warm Drinks



Warm Foods



Dough Fermentation



Thawing



Melting Chocolate

*Image: The warming mat demonstrating its versatility for different kitchen tasks.*

## 5. Maintenance

---

### 5.1 Cleaning

- Always unplug the mat and allow it to cool completely before cleaning.
- Wipe the surface with a damp cloth. The silicone material is splash-proof, water-resistant, and stain-resistant.
- Do not immerse the mat in water or use abrasive cleaners.

### 5.2 Storage

- The mat is foldable for convenient storage. Roll it up and secure it with the included strap or place it in the storage bag.
- Store in a dry place away from direct sunlight.

# Keep Dishes Warm without Effort

Keep your food tasty and flavorful



*Image: Demonstrating the easy cleaning and rollable storage of the warming mat.*

## 6. Troubleshooting

- **Mat not heating:** Ensure the power cord is securely plugged into both the mat and the electrical outlet. Check if the power button is pressed and the desired temperature is selected.

- **Food not staying warm:** Verify that the correct temperature setting is selected for the food type. Ensure the mat is not overloaded and that dishes are heat-resistant.
- **Mat automatically shut off:** This is a safety feature. The mat will turn off after 3 hours of no user interaction. Simply turn it back on if needed.
- **Error codes on display:** If an error code appears, unplug the mat, wait a few minutes, and plug it back in. If the error persists, contact customer support.

## 7. Specifications

| Feature                     | Detail  |
|-----------------------------|---|
| Brand                       | FOHERE  |
| Model Number                | BW609   |
| Colour                      | White   |
| Material                    | Silicone  |
| Special Features            | Dual-Zone Heating, Adjustable Temperature, Timer Function, Child Lock, Auto-Shutoff |
| Number of Heating Elements  | 2   |
| Controls Type               | Push Button   |
| Heating Element             | Radiant   |
| Power Source Type           | AC  |
| Item Dimensions (D x W x H) | 41.8D x 61W x 2H Centimetres  |
| Included Components         | 1* FOOD WARM MAT  |
| Country of Origin           | China   |

## 8. Warranty and Support

FOHERE products are manufactured with quality and care. For warranty information or technical support, please contact the manufacturer directly.

- **Manufacturer:** FOHERE
- **Manufacturer Contact Information:** FOHERE (Please refer to product packaging or official website for

specific contact details.)

## 9. Product Videos

---

Watch these official videos for additional product information and usage demonstrations:

### **Food Warming Mat with Insulating Pad Raised Feet**

Your browser does not support the video tag.

This video demonstrates the FOHERE Food Warming Mat, highlighting its insulating pad and raised feet design for surface protection and efficient warming. It shows the mat's portability and ease of use for various meals.

### **iTRUSOU Electric Warming Tray for Pizza, Dishes, and More**

Your browser does not support the video tag.

This video showcases the electric warming tray's functionality for keeping various dishes, including pizza, warm. It illustrates the control panel and the mat's ability to accommodate different food items for parties and everyday use.

### **Warming Mat for Food**

Your browser does not support the video tag.

This video provides a general overview of a food warming mat, demonstrating its use for keeping food warm during meals. It highlights the convenience and practical application of the product in a home setting.