

[Manuals.plus](#) /

› [HOOTEK](#) /

› HOOTEK S42 Wireless Earbuds User Manual

## HOOTEK S42

# HOOTEK S42 Wireless Earbuds User Manual

Model: S42 | Brand: HOOTEK

## 1. INTRODUCTION

---

Thank you for choosing the HOOTEK S42 Wireless Earbuds. This manual provides detailed instructions for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before use.



*Image 1.1: HOOTEK S42 Wireless Earbuds in their charging case.*


## 2. PACKAGE CONTENTS

---

Ensure all items are present in the package:

- HOOTEK S42 Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- Multiple Sizes of Ear Tips (S, M, L)
- User Manual

## Customizable Fit



### Tiny Portable Case



### Auto Reconnect



### Decent Package



Image 2.1: Contents of the HOOTEK S42 package.

## 3. PRODUCT OVERVIEW

The HOOTEK S42 earbuds feature an ergonomic design for comfortable wear and intuitive touch controls. The charging case includes an LED display to show battery levels.

### 3.1 Earbud Diagram

# Smart Touch Control



Image 3.1: Illustration of the earbud with touch control areas highlighted.

## 3.2 Charging Case Display

# Digital Power Display

Dual digital display to show the power of the charging case and earbuds



Image 3.2: The charging case's LED display indicating battery levels for the case and each earbud.

## 4. SETUP

### 4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case.
2. Connect the USB Type-C charging cable to the charging port on the case and to a power source.
3. The LED display on the case will show the charging status. A full charge is indicated by '100' on the display.

A full charge provides approximately 6-8 hours of earbud usage, and the charging case extends total playback to about 40 hours.

### 4.2 Bluetooth Pairing

The earbuds feature one-step auto-pairing for convenience.

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.

3. On your device (phone, laptop, tablet), enable Bluetooth and search for available devices.
4. Select "S42" from the list of devices to connect.
5. Once connected, the earbuds will automatically reconnect to your device when the case is opened, provided Bluetooth is enabled on your device.




Image 4.1: Illustrates the one-step auto-pairing process with a smartphone.

## 5. OPERATING INSTRUCTIONS

### 5.1 Power On/Off

- **Power On:** Open the charging case, and the earbuds will power on automatically.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off and begin charging.

### 5.2 Smart Touch Controls

The HOOTEK S42 earbuds feature intuitive touch controls on each earbud. Refer to the diagram below for specific functions:




Image 5.1: Comprehensive guide to earbud touch controls.

- **Play/Pause:** Single tap on either L/R earbud.
- **Previous Track:** Double tap on the Left earbud.
- **Next Track:** Double tap on the Right earbud.
- **Volume Up:** Long tap on the Right earbud.
- **Volume Down:** Long tap on the Left earbud.
- **Answer/End Call:** Single tap on either L/R earbud.
- **Reject Call:** Double tap on either L/R earbud.
- **Activate Voice Assistant (Siri/Google Assistant):** Triple tap on either L/R earbud.

### 5.3 Wearing the Earbuds

Select the ear tips that provide the most comfortable and secure fit for optimal sound quality and noise isolation. Gently insert the earbuds into your ear canal and rotate slightly to secure them.

## 6. MAINTENANCE

### 6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Clean the ear tips with a damp cloth and mild soap if necessary, ensuring they are completely dry before reattaching.
- Ensure charging contacts on both earbuds and case are clean and free of debris.

### 6.2 Storage

When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from extreme temperatures.

## 7. TROUBLESHOOTING

If you encounter issues with your HOOOTEK S42 earbuds, try the following solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "S42" from your device's Bluetooth list and re-pair. Place earbuds back in case, close, then open to reset.
Only one earbud working	Ensure both earbuds are charged. Place both earbuds back in the charging case, close the lid, then open it again. Check if the earbud's charging contact is clean.
Low volume or poor sound quality	Adjust volume on both your device and using earbud touch controls. Ensure ear tips provide a secure seal in your ear. Try different sizes. Clean ear tips and earbud mesh to remove any wax or debris.
Charging case not charging	Ensure the USB Type-C cable is properly connected to both the case and the power source. Try a different charging cable or power adapter.

## 8. SPECIFICATIONS

Feature	Detail
Model Name	S42
Bluetooth Version	5.3
Bluetooth Range	Up to 10 meters (32 feet)
Battery Life (Earbuds)	6-8 hours (single charge)
Total Playback Time	Up to 40 hours (with charging case)
Charging Port	USB Type-C
Water Resistance	IPX7 Waterproof
Noise Control	Hybrid Noise Cancellation (ENC for calls)
Audio Driver Type	Dynamic Driver (13mm)
Frequency Response	20 KHz
Sensitivity	33 dB
Material	Acrylonitrile Butadiene Styrene (ABS), Plastic
Control Type	Touch Control

Feature	Detail
Compatibility	Cellphones, Laptops, Tablets (iOS, Android, Windows)

## 9. SAFETY INFORMATION

---

- Do not disassemble or modify the product.
- Keep away from extreme temperatures and direct sunlight.
- Avoid exposing the product to fire or high heat.
- Do not immerse the charging case in water. Earbuds are IPX7 waterproof, but the charging case is not.
- Use only the provided charging cable or a certified equivalent.
- Avoid listening at high volumes for extended periods to prevent hearing damage.

## 10. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official HOOTEK website. If you have any questions or require assistance, please contact HOOTEK customer service.