

**QOXEZY A60S84D82S4W2D1436859**

# QOXEZY Non-Woven Replacement Dust Bags for Conga Vacuum Cleaners Instruction Manual

Comprehensive guide for installation and usage of your replacement dust bags.

## 1. INTRODUCTION

This instruction manual provides essential information for the proper installation and use of your QOXEZY non-woven replacement dust bags. These bags are designed to maintain the cleaning efficiency of your compatible Conga vacuum cleaner models.

## 2. PRODUCT OVERVIEW AND FEATURES

The QOXEZY replacement dust bags are crafted from durable non-woven fabric, engineered for effective dust collection and improved air filtration. They are designed for easy installation and reliable performance.

- **Efficient Dust Collection:** High-quality material effectively captures and retains dust particles, ensuring thorough cleaning.
- **Easy Installation:** Designed for a user-friendly replacement process, allowing quick and hassle-free bag changes.
- **Durable Construction:** Made from robust non-woven fabric for regular use and long-lasting performance.
- **Enhanced Air Filtration:** Improves air quality by trapping even the smallest particles, contributing to a cleaner and healthier living environment.



*Image 1: A pack of QOXEZY non-woven replacement dust bags, showing multiple bags neatly stacked. These bags are designed for efficient dust collection in compatible vacuum cleaners.*

### 3. COMPATIBILITY

---

These replacement dust bags are compatible with the following Conga vacuum cleaner models:

- Conga 9590 Spinfoor Ultra Power
- Conga 9590 Spinfoor Ultra Power Home
- Conga 9990 AI Spinfoor Ultra Power Home
- Conga 10090 AI Spinfoor Ultra Power Home Lifestyle

### 4. INSTALLATION INSTRUCTIONS

---

Follow these steps to correctly install or replace a dust bag in your compatible Conga vacuum cleaner:

1. **Power Off:** Ensure your vacuum cleaner is turned off and unplugged from the power outlet before beginning the installation process.
2. **Access Dust Compartment:** Locate and open the dust compartment or bag housing on your vacuum cleaner. Refer to your vacuum cleaner's specific manual if you are unsure.

3. **Remove Old Bag (if applicable):** Carefully remove the full or old dust bag. Dispose of it properly according to local waste disposal guidelines.
4. **Insert New Bag:** Take a new QOXEZY replacement dust bag. Align the bag's collar with the bag inlet in the vacuum cleaner's compartment. Push firmly until the bag is securely seated. Ensure there are no gaps for dust to escape.
5. **Close Compartment:** Close the dust compartment cover securely. Ensure it clicks into place to prevent any leaks during operation.
6. **Resume Operation:** Plug in your vacuum cleaner and turn it on. It is now ready for use with the new dust bag.



*Image 2: A close-up view of a single QOXEZY replacement dust bag, showing its front and back. This illustrates the design for proper fitting into the vacuum cleaner's dust compartment.*

## 5. USAGE AND REPLACEMENT FREQUENCY

---

The QOXEZY replacement dust bags are designed for single use. For optimal cleaning performance and air filtration, it is recommended to replace the dust bag when it is approximately two-thirds full, or when you notice a decrease in suction power. Regular replacement helps maintain the efficiency and longevity of your vacuum cleaner.



*Image 3: An angled view of a single QOXEZY replacement dust bag, highlighting its non-woven material and structural integrity. This design ensures effective containment of dust and debris.*

## 6. SPECIFICATIONS

Attribute	Detail
Brand	QOXEZY
Model Number	A60S84D82S4W2D1436859
Material	Non-woven fabric
Color	As pictured (White)
Product Dimensions	10 x 9 x 3 cm
Package Quantity	Available in 6-pack or 12-pack

## 7. WARRANTY AND SUPPORT

Specific warranty information and direct customer support details for QOXEZY replacement dust bags are not provided in the product description. For any product-related inquiries, please refer to the retailer or platform where the purchase was made.

