

AECOJOY 16002DBU

AECOJOY 7-Piece Outdoor Patio Furniture Set

Model: 16002DBU

1. IMPORTANT SAFETY INFORMATION

Please read and understand all safety warnings before assembly and use of this product. Failure to follow these instructions may result in injury or product damage.

- Exercise caution around sharp edges during unpacking and assembly.
- This product is heavy. Assembly requires at least two people to prevent injury.
- Always follow the detailed assembly instructions provided to ensure proper and safe construction.
- Do not exceed the maximum weight limit of 160 pounds per seating unit.
- Keep children and pets away from the assembly area.

2. PRODUCT OVERVIEW

The AECOJOY 7-Piece Outdoor Patio Furniture Set is a versatile and comfortable conversation set designed for various outdoor environments. Its modular components allow for flexible arrangements to suit your space and needs.

Components Included:

- 4 x Armless Chairs
- 2 x Corner Chairs
- 1 x Coffee Table with Tempered Glass Top
- 6 x Soft Cushions and Backrests (Peacock Blue)



Figure 2.1: Complete 7-piece patio furniture set.

3. SETUP & ASSEMBLY

Your AECOJOY patio furniture set arrives in multiple boxes, containing all necessary hardware and a detailed instruction manual. Follow the step-by-step guide for efficient assembly. It is recommended to assemble the furniture on a soft, clean surface to prevent scratches.

Assembly Tips:


- Unpack all components and verify against the parts list in your manual.
- Do not fully tighten screws until all parts are loosely assembled.
- Use the provided tools or your own appropriate tools for assembly.
- For the coffee table, carefully place the tempered glass top onto the frame, ensuring it is securely seated.

Product Details

*Note Rain-Proof so please not
expose to rainy days*




STRAP CUSHION



WEATHER
RESISTANT PE RATTAN



ANTI-SKIDDING FEET



ALUMINUM FRAME



Figure 3.1: Key structural components and materials.

Furniture Set Size

There will be a total of two boxes delivered together, may not be delivered on the same day, please wait patiently.







Figure 3.2: Furniture set dimensions and layout options.

4. OPERATING INSTRUCTIONS

The modular design of this patio set offers exceptional flexibility. You can arrange the individual seating units in various configurations to best suit your outdoor space and social needs.

Configuration Options:

- **L-Shape Sectional:** Combine corner chairs and armless chairs to form a cohesive L-shaped sofa, ideal for corner spaces.
- **Straight Sofa:** Arrange all seating units in a straight line for a long, continuous seating area.
- **Individual Seating:** Separate the chairs to create multiple individual seating arrangements for smaller gatherings.
- **Coffee Table Placement:** Position the coffee table centrally or to the side, depending on your preferred layout.

The cushions are designed for comfort and can be easily placed on the seating units. The backrests provide additional support for optimal relaxation.



Freely Recombine into Different Combinations



Figure 4.1: Examples of flexible furniture arrangements.

5. MAINTENANCE & CARE

Proper care and maintenance will extend the life and appearance of your AECOJOY patio furniture set.

Cushion Care:

- The cushion covers are zippered and washable. Remove covers and machine wash on a gentle cycle with cold water, or hand wash. Air dry only; do not tumble dry.
- The cushions feature a water-repellent polyester cover, which helps to bead off light rain. However, they are not fully waterproof. Bring cushions indoors during heavy rain or prolonged wet conditions.
- Store cushions in a dry place when not in use for extended periods.

Frame and Table Care:

- Wipe down the PE rattan and aluminum frame with a soft, damp cloth and mild soap as needed. Rinse thoroughly and dry completely.
- Clean the tempered glass tabletop with a glass cleaner and a soft cloth.
- Avoid using harsh chemicals, abrasive cleaners, or stiff brushes, as these can damage the materials.
- To protect the furniture from harsh weather, consider using a weather-resistant patio furniture cover when the set is not in use, especially during winter months or prolonged periods of inclement weather.



Figure 5.1: Details of cushion construction for easy maintenance.

6. TROUBLESHOOTING

This section provides general guidance for common issues. For specific problems not addressed here, please contact customer support.

Loose Connections:

- If any part of the furniture feels wobbly, check all bolts and screws. Tighten them securely, but do not overtighten.

Cushion Flattening:

- Over time, cushions may compress. Fluff them regularly to maintain their shape and comfort.

Water Stains on Rattan:

- If water spots appear, clean immediately with a damp cloth and mild soap. Dry thoroughly to prevent mineral buildup.

7. SPECIFICATIONS

Feature	Detail
Brand	AECOJOY
Model Number	16002DBU
Color	Black Rattan & Peacock Blue Cushion
Material Type	Four-line Rattan (PE Wicker), Steel Frame, Tempered Glass
Item Weight	160 Pounds
Item Dimensions	110 x 56 x 26.2 inches (L-shape configuration)
Assembly Required	Yes
Included Components	4 Armless Chairs, 2 Corner Chairs, 1 Coffee Table

8. WARRANTY INFORMATION

For detailed warranty information regarding your AECOJOY 7-Piece Outdoor Patio Furniture Set, please refer to the warranty card included in your product packaging. This document outlines the terms, conditions, and duration of the manufacturer's warranty. Please retain your proof of purchase for any warranty claims.

9. CUSTOMER SUPPORT

Should you require further assistance, have questions about assembly, operation, maintenance, or need to report any issues with your AECOJOY 7-Piece Outdoor Patio Furniture Set, please contact our customer support team.

Please refer to the contact information provided in your product packaging or visit the official AECOJOY website for the most up-to-date support details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question