

- Manuals.plus /
- > [Hionly](#) /
- > Hionly AI Neck Fan Instruction Manual

Hionly

Hionly AI Neck Fan Instruction Manual

Model: Q3

1. PRODUCT OVERVIEW

The Hionly AI Neck Fan is a portable, rechargeable personal cooling device designed for ultimate comfort and convenience. Featuring advanced AI-powered dual turbine motors, it delivers 360° airflow around your face and neck, ensuring efficient cooling in various environments. Its lightweight and hands-free design, combined with a long-lasting 6000mAh battery, makes it ideal for both indoor and outdoor activities.



Figure 1.1: The Hionly AI Neck Fan, illustrating its wearable design and cooling airflow.

2. KEY FEATURES

- **360° Surround Cooling:** Equipped with dual turbine motors and scientifically designed air outlets, this fan provides comprehensive airflow around your face and neck for consistent cooling.

360° Airflow Surround Cooling

Feel the cool breeze on your face, refreshing and comfortable



Figure 2.1: The fan's 360° airflow design for full neck and face cooling.

- **6 Adjustable Wind Speeds:** Easily switch between six different fan speeds to customize your cooling experience, from a gentle breeze to a powerful airflow.
- **Long-Lasting 6000mAh Battery:** The high-capacity dual polymer lithium battery offers an impressive runtime of 6 to 20 hours, depending on the speed setting. Advanced lithium-ion technology and an AI chip optimize energy efficiency.

Next-Gen Neck Fan

Better power consumption control keeps you cool all day long



Designed
in the **USA**

100%

Battery life

2X

Energy consumption control

3X

Comfort

Figure 2.2: Internal components highlighting the AI chip and battery for efficient operation.

- **Type-C Fast Charging:** The fan supports Type-C fast charging for quick and convenient recharging.
- **Ultra High Speed Motor:** Provides rapid cooling and strong wind output.

Ultra High Speed Motor



Rapid Cooling



Strong Wind



Figure 2.3: Detail of the powerful motor for rapid cooling.

- **Hands-Free & Portable Design:** Lightweight and stylish, designed to comfortably rest around your neck, making it perfect for travel and on-the-go use.
- **Skin-Friendly Materials:** Constructed from durable ABS and soft silicone materials for a comfortable fit, even during extended wear.

Soft Silicone Pad & Back Neck Air Duct Design

Strong cool wind unimpeded, no sweat on neck

Soft Silicone

Food Grade



Can be widened freely

Easy to wear




Figure 2.4: Soft silicone pads ensure comfortable wear.

- **Versatile Use:** Ideal for both indoor activities (working, cooking, exercising) and outdoor adventures (gardening, hiking, cycling, concerts).



Lightweight neck fan, hanging without pressure
Surround airflow cools your face and neck directions

Figure 2.5: Demonstrating the fan's suitability for diverse indoor and outdoor activities.

3. SETUP

3.1 Charging the Device

Before first use, fully charge your Hionly AI Neck Fan. The device is equipped with a 6000mAh battery and supports Type-C fast charging. Use the provided USB-C charging cable to connect the fan to a compatible power source (e.g., wall adapter, power bank, computer USB port).

1. Locate the Type-C charging ports on the fan. There are two ports, one on each side.
2. Connect the provided USB-C cable to both charging ports on the fan and the USB-A end to your power source.
3. The charging indicator light will illuminate, indicating that the device is charging.
4. Once fully charged, the indicator light may change color or turn off (refer to specific light behavior in the Operating Instructions section if available).

3.2 Wearing the Neck Fan

The Hionly AI Neck Fan is designed for comfortable, hands-free wear.

1. Gently open the fan's flexible neckband to fit around your neck. The soft silicone pads at the back ensure a snug and comfortable fit.
2. Position the fan so that the air outlets are directed towards your face and neck for optimal cooling.
3. Ensure your hair or clothing does not obstruct the air intake or outlet vents.



Figure 3.1: Product dimensions for proper fit and wear.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

The Hionly AI Neck Fan features a simple touch control method.

1. To power on the fan, press and hold the power button located on the side of the device for approximately 2-3 seconds. The fan will start at the lowest speed setting.
2. To power off the fan, cycle through all speed settings until the fan turns off, or press and hold the power button again for 2-3 seconds.

4.2 Adjusting Wind Speeds

The fan offers 6 adjustable wind speeds.

1. While the fan is on, short press the power button to cycle through the 6 different speed settings. Each press will increase the fan speed.
2. After the 6th speed, pressing the button again will typically turn the fan off.



Figure 4.1: Visual representation of the 6-speed adjustment and airflow channels.

4.3 Battery Indicator

The fan may feature an LED indicator to show battery status. Consult the product packaging or manufacturer’s website for specific light patterns indicating battery levels and charging status.

5. MAINTENANCE

5.1 Cleaning

- Ensure the fan is powered off before cleaning.
- Use a soft, dry cloth to wipe the exterior of the fan.
- For dust accumulation in the air intake/outlet grilles, use a soft brush or compressed air to gently clear the debris.
- Do not use harsh chemicals, abrasive cleaners, or immerse the device in water.

5.2 Storage

- Store the fan in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, ensure the battery is partially charged (around 50%) to prolong its lifespan. Recharge every few months if not in use.

6. TROUBLESHOOTING

If you encounter issues with your Hionly AI Neck Fan, please refer to the following common solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan using the provided USB-C cable.
Weak or no airflow.	Air vents are obstructed; fan speed is too low.	Ensure vents are clear. Increase fan speed by pressing the power button.
Fan is making unusual noise.	Debris in fan blades; internal issue.	Power off and gently clean the fan grilles. If noise persists, contact customer support.
Fan not charging.	Cable or power source issue; charging ports are dirty.	Try a different USB-C cable or power adapter. Ensure charging ports are clean and free of debris.

7. SPECIFICATIONS

Attribute	Detail
Brand	Hionly
Model Name	Q3
Color	Pink
Electric Fan Design	Wearable Fan
Power Source	Battery Powered (2 Lithium Ion batteries included)
Battery Capacity	6000 mAh
Product Dimensions	1.69"D x 9.68"W x 8"H
Item Weight	1.01 pounds
Number of Power Levels	6
Control Method	Touch
Indoor/Outdoor Usage	Indoor & Outdoor

Attribute	Detail
Special Feature	Lightweight
UPC	803173645074
ASIN	B0DYP4XGTB
Country of Origin	China
Date First Available	February 27, 2025

8. WARRANTY AND SUPPORT

This product is subject to a 30-day return/replacement policy from the date of purchase. For detailed warranty information, product support, or to report any issues not covered in this manual, please contact Hionly customer service through the retailer's platform or the official brand website.

No official seller videos are available for this product. For visual demonstrations, please refer to the product page on the retailer's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DYP4XGTB>

More documents and user manuals: <https://manuals.plus/>