

Ejoyous Ejoyousfg7rge9t8p-4B

Ejoyous Foldable Camping Table Instruction Manual

Model: Ejoyousfg7rge9t8p-4B | Brand: Ejoyous

1. INTRODUCTION

Thank you for choosing the Ejoyous Foldable Camping Table. This lightweight and portable table is designed for outdoor activities such as camping, picnics, beach parties, and tailgating. Constructed from durable aluminum alloy and ABS material, it offers adjustable height and a stable surface for various uses. Please read this manual carefully before assembly and use to ensure proper operation and longevity of your product.

2. PRODUCT FEATURES

- **Sturdy yet Lightweight:** Constructed from aluminum alloy and ABS, providing durability without excessive weight.
- **Foldable Design:** Easily folds for compact storage and transport.
- **Adjustable Height:** Customize the table height to suit various needs and terrains.
- **Versatile Usage:** Ideal for camping, picnics, beach outings, and other outdoor adventures.
- **Integrated Handles/Hooks:** Features cut-outs and slots for easy carrying and hanging small items like cups.

3. PACKAGE CONTENTS

Please check the package to ensure all items are present and undamaged:

- 1 x Folding Table
- 1 x Storage Bag

4. SETUP INSTRUCTIONS

1. **Unpack the Table:** Remove the folding table from its storage bag. The table will be in a compact, folded state.
2. **Unfold the Legs:** Gently unfold the table legs from underneath the tabletop. Ensure each leg clicks securely into its locked position.

3. **Adjust Height (Optional):** Each leg features an adjustable section. Press the spring-loaded button on each leg and slide the lower section to your desired height. Ensure all four legs are adjusted to the same height for stability. Release the button to lock the leg in place.
4. **Position the Table:** Place the table on a flat, stable surface. If the ground is uneven, use the adjustable legs to level the table.



Figure 4.1: The table in its folded configuration, ready for transport or storage.



Figure 4.2: Fully assembled table with approximate dimensions. Note the adjustable leg sections.

5. OPERATING INSTRUCTIONS

Once assembled, your Ejoyous Foldable Camping Table is ready for use. Its versatile design makes it suitable for various outdoor activities.

- **Dining Surface:** Use the tabletop for meals, snacks, or drinks. The sturdy surface can hold various items securely.
- **Workstation:** Ideal for holding small cooking equipment, books, or other gear while camping.
- **Adjustable Height:** Re-adjust the table height as needed for different seating arrangements or tasks. Ensure all legs are locked at the same height for stability.
- **Accessory Hooks:** Utilize the integrated slots and cut-outs on the tabletop edges to hang lightweight items such as cups, utensils, or small bags.



Figure 5.1: The table in use as a personal dining or utility surface during an outdoor activity.



Figure 5.2: Table supporting a kettle and cups, demonstrating its use as a cooking or beverage station.



Figure 5.3: Detail of the integrated hooks for hanging accessories.

6. MAINTENANCE

Proper care and maintenance will extend the life of your Ejoyous Foldable Camping Table.

- **Cleaning:** Wipe the tabletop and legs with a damp cloth after each use. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Drying:** Ensure the table is completely dry before folding and storing to prevent corrosion or mildew.
- **Storage:** Fold the table according to the setup instructions in reverse. Store it in the provided storage bag in a cool, dry place away from direct sunlight and extreme temperatures.

- **Inspection:** Periodically check all joints and leg mechanisms for any signs of wear or damage. Ensure all locking mechanisms function correctly.

7. TROUBLESHOOTING

- **Table is Unstable:**
 - Ensure all four legs are fully extended and locked into place.
 - Verify that all legs are adjusted to the same height.
 - If on uneven ground, adjust individual leg heights to compensate for the terrain.
 - Check that the table is placed on as flat a surface as possible.
- **Legs Difficult to Adjust/Fold:**
 - Ensure the spring-loaded buttons are fully depressed when adjusting or folding.
 - Clean any dirt or debris from the leg mechanisms. A small amount of silicone lubricant can be applied if movement is stiff, but avoid oil-based lubricants.

8. SPECIFICATIONS

Feature	Detail
Brand	Ejoyous
Model Name	Ejoyousfg7rge9t8p-4B
Material	Aluminum alloy, ABS
Color	Black
Product Dimensions (L x W x H)	48cm x 28cm x 59cm (18.9"D x 11.02"W x 23.2"H)
Weight	1.4 kg (3.1 lbs)
Adjustable Height	Yes

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. If you require technical support or have questions regarding your Ejoyous Foldable Camping Table, please contact Ejoyous customer service through their official website or the platform where the product was purchased.