

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Desky](#) /

› [Desky Vanguard Gaming Chair Instruction Manual](#)

Desky 51741188260207

Desky Vanguard Gaming Chair Instruction Manual

Model: 51741188260207

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Desky Vanguard Gaming Chair. Please read this manual thoroughly before assembly and use to ensure proper function and safety.

SAFETY INFORMATION

- **Weight Capacity:** This chair has a maximum weight capacity of 330 lbs (150 kg). Do not exceed this limit.
- **Assembly:** Follow all assembly instructions carefully. Incorrect assembly can lead to instability and injury.
- **Adjustments:** Exercise caution when adjusting chair components to prevent pinching or other accidents.
- **Stability:** Do not stand on the chair. Ensure all casters are on a flat, stable surface before sitting.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact customer support.

- Chair Backrest
- Seat Base
- Headrest
- Armrests (2)
- Gas Lift Cylinder
- Gas Lift Cover
- Star Base
- Casters (5)
- Mechanism (Control Unit)
- Assembly Hardware (Screws, Washers, Allen Key)

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Desky Vanguard Gaming Chair. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

- 1. Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the star base. Push firmly until they click into place.
- 2. Install Gas Lift:** Place the gas lift cylinder into the center hole of the star base. Cover it with the gas lift cover.
- 3. Attach Mechanism to Seat:** Align the mechanism with the pre-drilled holes on the underside of the seat base. Ensure the front of the mechanism faces the front of the seat. Secure with screws and tighten using the provided Allen key.
- 4. Connect Backrest to Seat:** Attach the backrest to the seat base using the designated screws. Ensure a secure connection.
- 5. Mount Seat Assembly to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the tapered end of the gas lift fits securely into the mechanism.
- 6. Install Headrest:** Slide the headrest into the top of the backrest. Adjust its height and angle as desired.
- 7. Attach Armrests:** Secure the armrests to the sides of the seat base using the provided screws.




Figure 1: Visual guide for chair assembly, detailing each step from attaching casters to installing the headrest.

OPERATING INSTRUCTIONS AND ADJUSTMENTS

Your Desky Vanguard Gaming Chair offers multiple adjustment options for personalized comfort and ergonomic support.

1. Seat Height Adjustment

To adjust the seat height, locate the lever on the right side beneath the seat. While seated, pull the lever up to lower the seat. To raise the seat, stand up and pull the lever up. Release the lever to lock the height.

2. Recline Function and Lock

The chair features a 4-level reclining lock, allowing recline up to 135°. To recline, pull the recline lever (often on the left side) and lean back. Release the lever at your desired angle to lock it in place. To return to an upright position, lean forward slightly while pulling the lever.



Figure 2: Side view illustrating the chair's recline capability and the location of adjustment levers.

3. Dual-Axis Adjustable Headrest

The headrest can be adjusted for height, angle, and depth. Gently push or pull the headrest to change its angle and depth. To adjust the height, grasp both sides of the headrest and slide it up or down to your preferred position.



Figure 3: Front view of the chair, demonstrating the adjustable headrest for neck and head support.

4. Ergonomic Lumbar Support

The lumbar support features adjustable extension and adaptive rotation. To adjust the lumbar support, locate the controls on the backrest. These allow you to move the support in and out, and rotate it to align with your spine's natural curve.



Figure 4: Rear view of the chair, detailing the ergonomic lumbar support system.

5. 4D Mechanical Armrests

The armrests are fully adjustable for height, depth, width, and angle. Use the buttons or levers on the armrests to:

- **Height:** Press the button on the side and slide the armrest up or down.
- **Depth (Forward/Backward):** Slide the armrest pad forward or backward.
- **Width (In/Out):** Slide the armrest pad left or right.
- **Angle (Pivot):** Rotate the armrest pad inward or outward.



Figure 5: Close-up of the chair's 4D armrests, illustrating their multi-directional adjustment capabilities.

6. Seat Depth Adjustment

To adjust the seat depth (up to 18.1 inches), locate the lever or button typically on the left side beneath the seat. While seated, pull the lever/button and slide the seat forward or backward to your preferred depth. Release to lock.

MAINTENANCE

- Cleaning:** For the mesh fabric, use a soft cloth dampened with mild soap and water. Avoid harsh chemicals. For the frame, wipe with a dry or slightly damp cloth.
- Inspection:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- Casters:** Keep casters free of hair and debris to ensure smooth movement.
- Avoid Overloading:** Do not exceed the maximum weight capacity of 330 lbs.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift cylinder malfunction or lever not engaged.	Ensure the lever is fully pulled. If issue persists, contact customer support for gas lift replacement.
Chair wobbles	Loose screws or uneven floor.	Check and tighten all assembly screws. Ensure the chair is on a flat surface.
Casters not rolling smoothly	Debris caught in casters.	Remove any hair or debris from the caster wheels.
Recline function not locking	Recline mechanism not engaged or damaged.	Ensure the recline lever is fully released to lock. Avoid forcing the recline. If damaged, contact support.
Squeaking noises	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone lubricant to moving parts if necessary, avoiding fabric.

SPECIFICATIONS

Feature	Detail
Brand	Desky
Model Name	Vanguard Gaming Chair
Model Number	51741188260207
Color	Black
Product Dimensions (D x W x H)	35"D x 26"W x 37"H
Maximum Weight Capacity	330 lbs (150 kg)
Back Style	High Back
Armrests	4D Mechanical Armrests
Headrest	Dual-Axis Adjustable
Lumbar Support	Adjustable Extension and Rotation
Recline Angle	Up to 135° with 4-level lock
Seat Depth Adjustment	Up to 18.1 inches
Upholstery Material	Breathable Dragon Mesh Fabric
Base Material	Die-cast Aluminum Frame
Casters	Smooth Glide Casters
Item Weight	57.3 pounds
UPC	643985147621

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official Desky website or contact Desky customer service directly. Keep your purchase receipt for warranty claims.

Desky Customer Service: [Visit the Desky Store on Amazon](#)

© 2025 Desky. All rights reserved.

Related Documents - 51741188260207

	<p>Desky Arco Office Chair - Specification Sheet</p> <p>Detailed specifications for the Desky Arco Office Chair, including dimensions, capacity, seat specifications, features, and general information such as assembly requirements and warranty.</p>
	<p>DESKY Dual Mini Sit Stand Desk: Assembly, Operation & Programming Manual</p> <p>This is the official instruction manual for the DESKY Dual Mini Sit Stand Desk. It provides detailed guidance on assembly, operation, programming features like memory presets and height limits, safety precautions, troubleshooting common errors, and warranty information. Learn how to optimize your workspace with this electric height-adjustable desk.</p>
	<p>DESKY L-Shape Sit Stand Desk: Assembly, Operation & Programming Guide</p> <p>Comprehensive instruction manual for the DESKY L-Shape Sit Stand Desk, covering safety, assembly, controller operation, programming features, troubleshooting, and warranty information.</p>
	<p>DESKY DUAL MINI SIT STAND DESK Instruction Manual</p> <p>Official instruction manual for the DESKY DUAL MINI SIT STAND DESK. Learn about assembly, operation, programming, safety, and troubleshooting for your height-adjustable desk.</p>

DESKY®



 DESKY L-SHAPE SIT STAND DESK
INSTRUCTION MANUAL

©2020 DESKY. All Rights Reserved.

[DESKY L-SHAPE Sit Stand Desk Instruction Manual](#)

Comprehensive instruction manual for the DESKY L-SHAPE Sit Stand Desk, covering safety, unpacking, assembly, operation, programming, troubleshooting, and warranty information.

DESKY®



 DESKY DUAL MINI SIT STAND DESK
INSTRUCTION MANUAL

©2020 DESKY. All Rights Reserved.

[DESKY DUAL MINI SIT STAND DESK Instruction Manual](#)

Comprehensive instruction manual for the DESKY DUAL MINI SIT STAND DESK, covering safety, assembly, operation, programming, troubleshooting, and warranty information.