pnochoo SUCABINET-02

pnochoo Shoe Cabinet with 3 Flip Drawers Instruction Manual

Model: SUCABINET-02

1. Introduction

Thank you for choosing the pnochoo Shoe Cabinet. This freestanding shoe cabinet features 3 flip drawers, a neat and modern appearance, and is designed to save space in your entryway, hallway, living room, or porch. Its narrow design (7.1 inches deep) makes it ideal for compact areas, providing a tidy storage solution for your footwear.

Key features include:

- Space-saving flip drawers for easy access and organization.
- Durable high-grade MDF construction for long-term use.
- Anti-tipping design for enhanced safety.
- Rounded handles for safety and aesthetic appeal.
- Elevated base for convenient shoe placement and retrieval.



Figure 1: The pnochoo Shoe Cabinet with 3 flip drawers, showcasing its marble texture finish and compact design suitable for entryways.

2. Safety Information

For your safety and to prevent injuries from furniture tip-over, it is crucial to securely fix this item to the wall using the provided anti-tipping kits. Always ensure the cabinet is stable before loading shoes or allowing children near it. Do not allow children to climb on the cabinet or pull on shelves/drawers.




Figure 2: Detail of the anti-tipping device, which must be securely installed to the wall for stability and safety.

3. Parts List

Before assembly, please verify that all components and hardware are present and undamaged. Refer to the assembly video for visual identification of each part.

Main Components:

- Side Panels (Left & Right)
- Top Panel
- Bottom Panel
- Back Panels
- Flip Drawers (x3) with Marble Texture Fronts
- Internal Shoe Cubby Kits (L/R) (x3 sets)

Hardware:

- Cam Bolts
- Cam Locks
- Wood Dowels
- Screws (various sizes)
- Metal Handles (x3)
- Anti-Tipping Kit (brackets, screws, wall anchors)

If any parts are missing or damaged, please contact pnochoo customer support for assistance.

4. Setup and Assembly Instructions

Assembly is required for this shoe cabinet. Please follow the steps below carefully. A Phillips head screwdriver and a hammer are recommended tools for assembly.

Your browser does not support the video tag.

Video 1: Official pnochoo Shoe Cabinet Installation Display Video. This video provides a comprehensive visual guide for assembling your shoe cabinet.

Assembly Steps:

1. **Prepare Panels:** Lay out all black frame panels (side, top, bottom, back supports) and white marble-effect drawer panels on a clean, soft surface to prevent scratches.
2. **Install Hardware on Frame:** Insert cam bolts and shelf supports into the designated holes on the black frame panels as indicated in the instruction manual and assembly video. Use a hammer to gently tap in the shelf supports if needed.
3. **Assemble Main Frame:** Connect the side panels to the bottom and top panels using cam locks and screws. Ensure all connections are tight and secure. The interlocking system allows for a sturdy build.
4. **Assemble Flip Drawers:** For each of the three marble-effect drawer fronts, attach the internal shoe cubby kits (L/R) using screws. Ensure the particle board edge is facing down so it is not visible when the drawer is open. Install the metal handles onto the front of each drawer.
5. **Install Drawers into Frame:** Carefully align the assembled flip drawers with the openings in the main frame. The design allows the drawers to swing smoothly. Do not overtighten screws at this stage to allow for proper movement, then secure once aligned.
6. **Attach Anti-Tipping Device:** Secure the anti-tipping brackets to the top rear of the cabinet. Mark and drill holes in your wall, insert wall anchors, and then attach the cabinet to the wall using the provided screws. This step is critical for safety.

5. Operating Instructions

The pnochoo Shoe Cabinet features three flip-down drawers for easy access to your shoes. Simply pull the metal handle to open a drawer, revealing the internal shoe cubby. Push the drawer back up until it clicks into place to close it securely.



Figure 3: The shoe cabinet with all three flip drawers open, demonstrating its storage capacity and accessibility.

Each drawer is designed to hold multiple pairs of shoes. For women's shoes up to size 10, each drawer can typically accommodate about 4 pairs, depending on the shoe style (e.g., flats, sandals). Larger shoe sizes, such as men's athletic shoes, may require adjusting the internal divider or may fit fewer pairs per drawer. The semi-open design of the cubbies allows for air circulation, helping to prevent moisture buildup and odors.



Figure 4: Visual representation of the shoe cabinet in both closed and open states, highlighting its discreet storage.

6. Maintenance

To maintain the appearance and longevity of your pnochoo Shoe Cabinet, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the marble-effect finish and MDF material.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading of the finish.
- **Hardware:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.
- **Ventilation:** Ensure adequate air circulation around the cabinet, especially if storing damp shoes, to prevent mold or mildew.

7. Troubleshooting

If you encounter any issues with your shoe cabinet, refer to the following common troubleshooting tips:

- **Cabinet Wobbles:**
  - Ensure all cam locks and screws are fully tightened.
  - Verify that the cabinet is placed on a flat, level surface.
  - Confirm the anti-tipping device is correctly installed and securely anchored to the wall.
- **Drawers Do Not Close Smoothly:**
  - Check for any obstructions inside the drawer or along its mechanism.
  - Ensure shoes are properly placed within the cubbies and not protruding.
  - Verify that the internal shoe cubby kits are correctly assembled and not misaligned.
- **Shoes Do Not Fit:**
  - The cabinet is designed for various shoe types, but larger sizes (e.g., men's size 11+) or bulky footwear (e.g., boots, high-top sneakers) may not fit optimally or may reduce the capacity per drawer.
  - Consider storing larger shoes on the elevated base beneath the drawers or in other suitable storage.

For persistent issues or further assistance, please contact pnochoo customer support.

8. Specifications

Product Size



Figure 5: Product dimensions for the pnochoo Shoe Cabinet.

Specification	Detail
Brand	pnochoo
Model Number	SUCABINET-02
Color	White (Marble Texture)
Product Dimensions	7.1"D x 31.5"W x 41.5"H
Item Weight	36 Pounds
Material	High-grade MDF (Wood)
Number of Shelves/Drawers	3 Flip Drawers
Mounting Type	Floor Mount (with Anti-Tipping feature)
Assembly Required	Yes

Recommended Uses	Shoes, Keys, Wallets

9. Warranty and Support

pnochoo is committed to providing high-quality products. For any questions, concerns, or assistance with your shoe cabinet, please contact our customer support team. We recommend registering your product upon purchase to facilitate any future support needs.

Optional protection plans are available for this product, offering extended coverage beyond the standard manufacturer's warranty. Please refer to your purchase details for information on available protection plans and their terms.

Visit the pnochoo Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question