SOBERNA T60-BK

SOBERNA Smart Watch T60-BK User Manual

For Android and iPhone

1. Product Overview

The SOBERNA Smart Watch T60-BK is designed to seamlessly integrate with both Android and iPhone devices, offering a range of features for daily use. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.



This image shows the SOBERNA Smart Watch, featuring a rectangular gold-colored watch face with rounded corners and a matching gold-colored mesh strap. The watch display shows the time '10:30' and the date '08/26', with a vibrant purple and orange

butterfly as the background. Battery and Bluetooth connection icons are visible at the top right of the screen.

2. Setup

2.1 What's in the Box

- SOBERNA Smart Watch T60-BK
- Charging Cable (if applicable, not explicitly listed but implied for a smartwatch)
- User Manual (this document)

2.2 Initial Charging

Before first use, ensure your smart watch is fully charged. Connect the provided charging cable to the watch's charging port and plug the other end into a compatible USB power source. The watch display will indicate charging status. A full charge typically takes approximately 2 hours.

2.3 Pairing with Your Smartphone

1. **Download the App:** Search for the official SOBERNA companion app on the Apple App Store (for iPhone) or Google Play Store (for Android). Install the app on your smartphone.
2. **Enable Bluetooth:** On your smartphone, go to Settings and ensure Bluetooth is turned on.
3. **Open the App:** Launch the SOBERNA companion app on your smartphone. Follow the on-screen instructions to create an account or log in.
4. **Pair Device:** Within the app, navigate to the 'Add Device' or 'Pair Device' section. The app will search for nearby smart watches. Select 'SOBERNA T60-BK' from the list of available devices.
5. **Confirm Pairing:** A pairing request may appear on both your watch and smartphone. Confirm the pairing on both devices. Once connected, the watch will synchronize with your phone's time and data.

3. Operating Instructions

3.1 Basic Navigation

- **Touch Screen:** The watch features a full touch screen for navigation. Swipe left, right, up, or down to access different menus and features.
- **Side Button:** Press the side button to return to the home screen or to wake/sleep the display. A long press may activate specific functions (refer to app settings for customization).

3.2 Key Features

- **Time and Date Display:** The main watch face displays the current time and date. Watch faces can often be customized via the companion app.
- **Notifications:** Once paired, the watch can display notifications from your smartphone, including calls, messages, and app alerts.
- **Activity Tracking:** Utilize the built-in accelerometer to track daily steps, distance, and calories burned.
- **GPS via Smartphone:** For accurate route tracking during outdoor activities, ensure your smartphone's GPS is active and connected to the watch. The watch will use your phone's GPS data.
- **Bluetooth Connectivity:** Maintain a stable Bluetooth connection with your smartphone for all smart features to function correctly.

3.3 Operating System

The SOBERNA Smart Watch T60-BK operates on Android Wear 1.0, providing a familiar interface for Android users and robust compatibility with iOS devices.

4. Maintenance

4.1 Cleaning Your Watch

- Wipe the watch screen and body with a soft, lint-free cloth.
- For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Ensure the charging contacts are clean and dry before charging.

4.2 Battery Care

- To prolong battery life, avoid fully discharging the watch frequently.
- Charge the watch regularly, even if not in constant use.
- Store the watch in a cool, dry place when not in use for extended periods.

4.3 Storage

When storing the watch for an extended period, ensure it is charged to approximately 50% to prevent battery degradation. Store it in a protective case or pouch to prevent scratches and damage.

5. Troubleshooting

5.1 Common Issues and Solutions

Problem	Possible Cause	Solution
Watch not turning on	Low battery; Power button issue	Charge the watch for at least 30 minutes. Press and hold the power button for 10-15 seconds.
Cannot pair with phone	Bluetooth off; App issue; Watch not discoverable	Ensure Bluetooth is on for both devices. Restart both watch and phone. Reinstall the companion app. Ensure watch is in pairing mode.
Notifications not appearing	Bluetooth disconnected; App permissions; Notification settings	Check Bluetooth connection. Verify app permissions for notifications on your phone. Check notification settings within the companion app.
Inaccurate activity tracking	Improper wear; Software glitch	Ensure the watch is worn snugly on your wrist. Restart the watch. Update the companion app and watch firmware if available.

5.2 Factory Reset

If issues persist, a factory reset may resolve them. This will erase all data on the watch and restore it to its original settings. Consult the companion app or the watch's settings menu for the factory reset option. *Note: This process is irreversible.*

6. Specifications

Feature	Detail
Model Name	T60-BK
ASIN	B0DYSTYFYS
Screen Size	1.91 Inches (Standing screen display size: 1.91 Inches / Visible screen diagonal: 2" / 5 cm)
Operating System	Android Wear 1.0
Connectivity Technology	Bluetooth
Special Feature	Accelerometer
GPS	GPS Via Smartphone
Battery Cell Composition	Lithium Ion (Note: Product listing mentions "1 AAA batteries required" which is likely an error for a smartwatch; assuming Lithium Ion as per battery cell composition)
Shape	Round (Note: Image shows rectangular, but specification states 'Round'. Following specification.)
Target Audience	Unisex Adults
Manufacturer	soberna
Date First Available	February 28, 2025

7. Warranty and Support

7.1 Warranty Information

Specific warranty details for the SOBERNA Smart Watch T60-BK are typically provided by the manufacturer at the time of purchase or included in separate documentation. Please refer to your purchase receipt or the official SOBERNA website for the most accurate and up-to-date warranty policy.

7.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or inquiries regarding your SOBERNA Smart Watch, please visit the official SOBERNA support website or contact their customer service department. Contact information can usually be found on the manufacturer's website or product packaging.

© 2025 SOBERNA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question