

WLIVE ASNG133

WLIVE Tall Dresser (Model ASNG133) Instruction Manual

7-Drawer Fabric Storage Tower with Metal Frame and Wood Top

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your WLIVE Tall Dresser, Model ASNG133. This 7-drawer fabric storage tower is designed to offer ample storage in compact spaces, suitable for bedrooms, closets, and living rooms. Please read these instructions carefully before assembly and use to ensure safe and proper functionality.

Key features include:

- **Compact Size:** Designed to fit small spaces and expand closet storage.
- **Ample Storage:** Equipped with 7 detachable fabric drawers for organized storage of clothes and daily items. The wood top provides display space.
- **Durable Quality Material:** Drawers feature a three-layer construction of high-quality fiberboard, easy-to-clean PVC, and breathable non-woven fabric. The wood top is made of P2 grade artificial wood, scratch-resistant and easy to clean. Materials are tested by EPA&SGS for health and environmental safety.
- **Premium Details:** Features smooth slide tracks and curved handles for easy drawer operation. Four adjustable feet ensure stability on various surfaces and protect floors.
- **Stable Structure & Safety Assured:** Constructed with a 15mm thickened metal steel frame and cross support rods for durability. Includes an anti-tilt device for wall mounting to ensure safety.

2. IMPORTANT SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use.
- **Anti-Tilt Device:** It is crucial to install the included anti-tilt device to secure the dresser to the wall. This

prevents accidental tipping, especially important in households with children or pets.

- Do not overload drawers. Distribute weight evenly.
- Keep small parts and packaging materials away from children.



Image: Anti-tilt device installation for enhanced safety.

3. PACKAGE CONTENTS

Please verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

Hardware:

- A: Screws (x16)
- B: Screws (x16)
- C: Screws (x14)
- D: Handles (x7)
- E: Plastic Anchors (x8)

- F: Nuts (x4)
- G: Adjustable Feet (x4)
- H: Anti-tilt Device (x2)
- I: Wall Plugs (x2)
- J: Wrenches (x2)
- K: Allen Key (x1)
- L: Spanner (x1)

Components:

- 1: Wood Top Panel (x1)
- 2: Left Frame (x1)
- 3: Right Frame (x1)
- 4: Top Crossbar (x1)
- 5: Middle Crossbar (x1)
- 6: Bottom Crossbar (x1)
- 7: Back Crossbar (x1)
- 8: Side Support Bars (x3)
- 9: Back Support Bars (x1)
- 10: Fabric Drawers (x7)
- 11: Drawer Bottom Boards (x7)

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your WLIVE Tall Dresser. An assembly video is provided below for visual guidance.

1. **Prepare the Frame:** Attach the adjustable feet (G) to the bottom of the left (2) and right (3) frames. Secure the top (4), middle (5), and bottom (6) crossbars between the left and right frames using screws (A).
2. **Install Support Bars:** Fasten the side support bars (8) and back support bars (9) to the frame using screws (A) and wrenches (J, L). Ensure the frame is stable.
3. **Attach Wood Top:** Place the wood top panel (1) onto the assembled metal frame and secure it with screws (B).
4. **Assemble Drawers:** For each fabric drawer (10), insert the drawer bottom board (11) to create a sturdy base. Attach the curved handles (D) to the front of each drawer using screws (C).
5. **Insert Drawers:** Slide the assembled fabric drawers into the designated slots in the metal frame.
6. **Install Anti-Tilt Device:** Secure the anti-tilt device (H) to the top rear of the dresser frame and attach it to the wall using wall plugs (I) and screws (B) to prevent tipping.

Assembly Video

Your browser does not support the video tag.

Video: Step-by-step installation guide for the WLIVE Tall Dresser.

5. OPERATING INSTRUCTIONS

Your WLIVE Tall Dresser is designed for easy and efficient storage.

- **Using the Drawers:** Gently pull the curved handles to open the fabric drawers. Push them back in until they are fully closed.
- **Organizing Items:** Utilize the seven drawers to categorize and store various items such as clothing, accessories, books, or small household goods. The wood top can be used for decorative items or frequently accessed essentials.
- **Weight Distribution:** For optimal stability and longevity, distribute the weight of stored items evenly across the drawers. Avoid placing excessively heavy items in a single drawer.




Image: Visual representation of drawer capacity for different item types.

Product Overview Video

Your browser does not support the video tag.

Video: Overview of the WLIVE Tall Dresser's features and functionality.

6. MAINTENANCE

To keep your dresser in excellent condition, follow these maintenance guidelines:

- **Cleaning the Wood Top:** The P2 grade artificial wood top is scratch-resistant and easy to clean. Wipe with a soft, damp cloth and mild detergent if necessary. Avoid abrasive cleaners.
- **Cleaning Fabric Drawers:** The fabric drawers are made with easy-to-clean PVC. Spot clean with a damp cloth and mild soap. Do not machine wash or tumble dry.
- **Frame Care:** Wipe the metal frame with a soft, dry cloth to remove dust.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Adjust the feet as needed to maintain stability.

7 LARGE DRAWERS

KEEP YOUR ITEMS ORGANIZED



Clothes
80+



Pants
50+



Socks
100+



Diaper
80+



Toys
30+



Scarf
30+

Image: Detailed view of the drawer's durable 3-tier structure.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Loose Handles:** If the drawer handles feel loose after assembly, ensure the screws are fully tightened. Due to the plastic nature of the handles and the fabric material, overtightening can strip the threads. If issues persist, consider using a small amount of threadlocker or a stronger adhesive to secure the screws within the handle.
- **Dresser Wobbles:** Check that the adjustable feet (G) are properly installed and adjusted. Rotate each foot to ensure the dresser is level on uneven floors.
- **Drawers Don't Slide Smoothly:** Ensure no items are obstructing the drawer's path. Check that the fabric drawers are correctly inserted and not warped.
- **Missing Parts:** If any parts were missing upon delivery, please contact WLIVE customer service immediately for replacements.

8. SPECIFICATIONS

Brand	WLIVE
Model Name	ASNG133 Fabric dresser / WXF
Product Dimensions	11.73"D x 15.67"W x 45.28"H
Color	White
Room Type	Bedroom, Closet, Living Room
Assembly Required	Yes
Item Weight	16.3 Pounds

9. WARRANTY AND SUPPORT

WLIVE is committed to providing high-quality products and excellent customer service. Your dresser is backed by our professional after-sales team, ready to assist with any concerns or issues you may have.

For support, please refer to the contact information provided with your purchase or visit the official WLIVE website. Please have your model number (ASNG133) and purchase details ready when contacting support.