

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GAOMON](#) /

› [GAOMON Oversized Electric Power Recliner Chair with Heat & Massage \(Model PHO\\_3388NYBF-SYGMjZF42\) - User Manual](#)

## GAOMON PHO\_3388NYBF-SYGMjZF42

# GAOMON Oversized Electric Power Recliner Chair with Heat & Massage (Model PHO\_3388NYBF-SYGMjZF42) - User Manual

Model: PHO\_3388NYBF-SYGMjZF42 | Brand: GAOMON

## 1. INTRODUCTION

---

Thank you for choosing the GAOMON Oversized Electric Power Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read it thoroughly before use and retain it for future reference.

This versatile power recliner combines electric heating and 10-mode vibration massage functions for fatigue relief. It features a 270° smooth rotation with a 30° gentle rocking motion, creating comfort for various activities. Designed with comfort in mind, it includes a 50% extra-density natural sponge cushion wrapped in premium PU leather and a built-in USB charging port.



Image 1.1: The GAOMON Oversized Electric Power Recliner Chair in Cognac.

## 2. SAFETY INSTRUCTIONS

---

To ensure safe operation and prevent injury or damage, please adhere to the following safety guidelines:

- Always ensure the power cord is not pinched or damaged.
- Keep children and pets away from the moving parts of the recliner.
- Do not allow children to play on or operate the recliner.
- Avoid placing hands or feet near the reclining mechanism when operating.

- Do not stand on the footrest or armrests.
- Unplug the recliner from the power outlet before cleaning or maintenance.
- Do not use the recliner if any part is damaged or malfunctioning. Contact customer support immediately.
- Ensure the recliner is placed on a level surface.
- Do not expose the recliner to excessive moisture or direct sunlight.
- The maximum weight capacity for this recliner is 400 lbs (181 kg). Do not exceed this limit.

### 3. PACKAGE CONTENTS

---

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact GAOMON customer support.

- Backrest Section
- Seat Base with Footrest Mechanism
- Left Armrest
- Right Armrest (with cup holder and USB port)
- Power Adapter
- Remote Control
- Instruction Manual
- Arm Pads

# RELAX IN STYLE

YOUR COZY CORNER AWAITS




Image 3.1: Overview of recliner components before assembly.

## 4. ASSEMBLY INSTRUCTIONS

---

Assembly is designed to be tool-free and typically takes less than 30 minutes. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. The innovative retractable armrest design allows for single-box shipment.
2. **Attach Backrest:** Align the metal brackets on the backrest with the corresponding slots on the seat base. Push down firmly until the backrest locks securely into place. You should hear a click.
3. **Attach Armrests:** Slide the left and right armrests onto the designated metal receivers on the sides of the seat

base. Ensure they are fully seated and stable.

4. **Connect Power:** Locate the power cord from the recliner and connect it to the power adapter. Plug the power adapter into a standard wall outlet.
5. **Initial Test:** Sit in the chair and use the remote control to test the reclining, heat, and massage functions.



Image 4.1: Illustration of connecting the backrest to the seat base.

## 5. OPERATING INSTRUCTIONS

Your GAOMON recliner offers multiple comfort features controlled by the included remote.

## 5.1 Reclining Function

Use the buttons on the remote control to adjust the reclining angle. The chair supports a 135° full recline position for napping, a 120° position for watching TV, and a 90° upright position for reading.



Image 5.1: Different reclining modes for various activities.

## 5.2 Heat and Massage Functions

The recliner features electric heating and a 10-mode vibration massage system. Use the remote control to activate and adjust these functions. The massage targets areas such as the back, lumbar, thighs, and legs, with 8 vibrating nodes and 5 massage modes, including a timing function.



Image 5.2: Heat and massage zones on the recliner.



Image 5.3: Detailed features of the heat and massage system.

### 5.3 Swivel and Rocking Functions

The chair offers a 360° smooth swivel and a 30° gentle rocking motion for enhanced relaxation and versatility.



Image 5.4: Illustration of the 30° rocking and 360° swivel capabilities.

### 5.4 USB Charging Port and Cup Holders

A built-in USB charging port is located on the side of the chair to keep your devices powered. Two cup holders are integrated into the armrests for convenience.



Image 5.5: Integrated cup holder detail.



Image 5.6: USB charging port and control panel.

## 5.5 Product Demonstration Video

Your browser does not support the video tag.

Video 5.1: A demonstration of the GAOMON Oversized Electric Recliner Chair's features, including reclining, cup holders, and side pockets.

## 6. MAINTENANCE

---

Proper care will extend the life and appearance of your recliner.

- **Cleaning:** For general cleaning, wipe the PU leather surface with a soft, damp cloth. For stubborn stains, use a mild leather cleaner and follow the product instructions. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Dusting:** Regularly dust the chair with a soft, dry cloth.
- **Mechanism:** Periodically check all bolts and screws to ensure they are tight. Do not lubricate the reclining mechanism unless specifically instructed by the manufacturer.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading and material degradation.



Image 6.1: The recliner's PU leather is designed for easy cleaning.

## 7. TROUBLESHOOTING

If you encounter any issues with your recliner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Recliner does not operate (no movement, heat, or massage).	<ul style="list-style-type: none"> <li>Power cord unplugged.</li> <li>Power outlet not working.</li> <li>Remote control battery low or faulty.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure power cord is securely plugged into the chair and wall outlet.</li> <li>Test the outlet with another device.</li> <li>Replace remote control batteries or check connections.</li> </ul>
Recliner makes unusual noises during operation.	<ul style="list-style-type: none"> <li>Loose hardware.</li> <li>Obstruction in mechanism.</li> </ul>	<ul style="list-style-type: none"> <li>Check and tighten all visible bolts and screws.</li> <li>Inspect the reclining mechanism for any foreign objects and remove them.</li> </ul>
Footrest does not extend or retract fully.	<ul style="list-style-type: none"> <li>Obstruction.</li> <li>Mechanism issue.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure there are no objects blocking the footrest.</li> <li>If the issue persists, contact customer support.</li> </ul>

If the problem cannot be resolved using the above solutions, please contact GAOMON customer support for further assistance.

## 8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	GAOMON
Model Number	PHO_3388NYBF-SYGMjZF42
Color	Cognac
Material	Faux Leather
Product Dimensions (D x W x H)	29.92"D x 25.79"W x 20.28"H
Seat Width	22 inches
Seat Depth	21.6 inches
Maximum Weight Recommendation	400 Pounds
Reclining Position Count	2 (multiple angles supported)
Swivel	360°
Rocking Motion	30°
Heat Function	Yes (Lumbar Heat)
Massage Function	Yes (10-mode vibration, 8 vibrating nodes, 5 massage modes, timing function)
USB Charging Port	Yes
Included Components	Arm Pad
Required Assembly	Yes
Indoor/Outdoor Usage	Indoor
GTIN	199108507600



Image 8.1: The GAOMON recliner is designed for spacious seating and supports up to 400 lbs.

## 9. WARRANTY AND SUPPORT

---

GAOMON is committed to providing quality products and customer satisfaction. For any questions regarding assembly, operation, maintenance, or warranty claims, please contact our dedicated support team.

Please refer to your purchase documentation for specific warranty terms and contact information. When contacting support, please have your model number (PHO\_3388NYBF-SYGMjZF42) and proof of purchase readily available.

