

[Manuals.plus](#) /

> [ultramic](#) /

> ultramic Portable Bluetooth Karaoke Machine User Manual

ultramic K26

Karaoke Machine User Manual

Model: K26 | Brand: ultramic

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective operation of your ultramic Portable Bluetooth Karaoke Machine. Please read this manual thoroughly before use and retain it for future reference.

PACKAGE CONTENTS

- 1 x Karaoke Machine
- 2 x Wireless Microphones
- 2 x Type-C Charging Cables
- 1 x User Manual

PRODUCT OVERVIEW

The ultramic Portable Bluetooth Karaoke Machine is designed for versatile audio entertainment, featuring a powerful speaker, wireless microphones, and dynamic LED lighting. Its compact and portable design allows for use in various settings.

Key Features

- **8W HD Bluetooth Wireless Speaker:** Delivers 360° stereo sound for an immersive audio experience.
- **Dual Wireless Microphones:** Includes two Bluetooth wireless microphones with dedicated storage slots.
- **Multiple Connectivity Options:** Supports Micro TF card, Flash USB, AUX-in, and Bluetooth connectivity. Compatible with Android mobile phones, TVs, iPads, tablets, and PCs.
- **Dynamic Multi-color LED Lights:** Features 6 light modes that sync with music, customizable via an independent button.
- **5 Magic Voice Effects:** Includes Monster, Baby, Karaoke Mode, Pop Mode, and Original/Accompaniment voice effects.

- **Ultra-Portable Design:** Measures 7.48*7.08*4.72 inches and weighs 1 KGS, with a handle for easy transport.
- **Rechargeable Battery:** Built-in large-capacity lithium-ion battery provides 4-10 hours of continuous music playback (actual playtime varies with volume and usage).



Figure 1: Front view of the ultramic Portable Bluetooth Karaoke Machine with two wireless microphones and LED lights activated.

SUPERIOR SPEAKER SYSTEM

Studio-quality sound
that brings your music to life!



Hifi Fidelity

HD Sound Quality

Sound Balance

Figure 2: Illustration of the speaker's internal components, highlighting Hi-fi Fidelity, HD Sound Quality, and Sound Balance.

5 Magic Voice Change Effect



Original



Monster Voice



Baby Voice



Pop Mode



Karaoke Mode

Figure 3: Depiction of the five magic voice change effects: Original, Monster Voice, Baby Voice, Pop Mode, and Karaoke Mode.

6 Dynamic Colorful Light Show

6 dynamic LED lighting effects for your party show



Figure 4: The karaoke machine displaying its six dynamic LED lighting effects, enhancing the party atmosphere.

Multiple Functional Modes



Figure 5: The karaoke machine demonstrating its multiple functional modes, including Bluetooth 5.0 connectivity up to 50 feet, and compatibility with various devices and music platforms.

Sing for Hours

– Karaoke's Battery Lasts All Night Long!

Up to **10** Working time



Note: Up to 10H playtime under 50% volume and light off

Figure 6: The karaoke machine's long-lasting battery, providing up to 10 hours of working time under 50% volume and with lights off.

SETUP

1. Charging the Device

Before first use, fully charge the karaoke machine and both wireless microphones. Use the provided Type-C charging cables. The charging indicator will show charging status and turn off when fully charged.

2. Powering On/Off

Press and hold the power button on the karaoke machine to turn it on or off. Similarly, press and hold the power button on each microphone to power them on or off.

3. Bluetooth Pairing

1. Ensure the karaoke machine is powered on and in Bluetooth pairing mode (indicated by a flashing light or audio prompt).

2. On your device (smartphone, tablet, PC), enable Bluetooth and search for "ultramic Karaoke Machine".
3. Select the device to pair. A confirmation sound will indicate successful pairing.
4. The wireless microphones will automatically connect to the karaoke machine when both are powered on.

OPERATING INSTRUCTIONS

1. Playing Music

- **Bluetooth:** Once paired, play music from your connected device.
- **USB/TF Card:** Insert a USB flash drive or TF card into the respective port. The machine will automatically play supported audio files.
- **AUX-in:** Connect an external audio device using a 3.5mm AUX cable (not included) to the AUX-in port.

2. Using Microphones

- Ensure microphones are charged and powered on.
- Adjust microphone volume using the +/- buttons on the microphone.
- Press the mode button on the microphone to cycle through the 5 magic voice effects (Monster, Baby, Karaoke, Pop, Original/Accompaniment).

3. LED Light Control

Press the dedicated light button on the karaoke machine to switch between the 6 dynamic LED light modes or to turn the lights off.

4. Volume Control

Adjust the main volume of the karaoke machine using the volume control buttons on the unit.

MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the device away from water and excessive moisture.
- Store in a cool, dry place when not in use.
- Avoid dropping or subjecting the device to strong impacts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is low or depleted.	Charge the karaoke machine and microphones fully.
No sound from speaker	Volume is too low; device not paired correctly; incorrect input mode.	Increase volume; re-pair Bluetooth; select correct input (Bluetooth, USB, TF, AUX).
Microphone not working	Microphone is off or low battery; not paired with machine.	Ensure microphone is charged and powered on; it should automatically pair. If not, restart both devices.
Bluetooth connection unstable	Device is too far from the karaoke machine; interference.	Move the connected device closer to the karaoke machine (within 50 feet); avoid obstacles.

SPECIFICATIONS

Feature	Detail
Brand	ultramic
Model Number	K26
Mounting Type	Portable
Power Source	Battery Powered
Connectivity Technology	Bluetooth, Auxiliary, USB, Wireless, TF card
Material	Plastic
Item Weight	2.27 pounds
Product Dimensions (L x W x H)	7.48 x 7.08 x 4.72 inches
Color	Pink Red
Compatible Devices	Computer, Headphone, PA System, Laptop, Smartphone, Television, iPhone, iPad, Pad

WARRANTY AND SUPPORT

The ultramic Karaoke Machine comes with lifetime technical support. If you encounter any issues during use, please contact our support team for assistance. We are committed to resolving any issues within 24 hours. For support, please refer to the contact information provided in your Quick Start Guide or visit the official ultramic website.