

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sorbus](#) /

› [Sorbus Kids Dresser with 7 Drawers - Model DRW-6D-TID6 Instruction Manual](#)

Sorbus DRW-6D-TID6

Sorbus Kids Dresser with 7 Drawers

MODEL: DRW-6D-TID6

Brand: Sorbus

INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your new Sorbus Kids Dresser with 7 Drawers. Please read these instructions carefully before assembly and retain them for future reference. This dresser is designed to offer versatile storage for clothing, toys, and other items in various rooms such as bedrooms, nurseries, and playrooms.



Figure 1: Fully assembled Sorbus Kids Dresser with 7 Drawers in Rainbow Sparkle.

SAFETY INFORMATION

- **Anti-Tip Device:** Always secure the dresser to the wall using the provided anti-tip kit to prevent accidental tipping, which can cause serious injury or death.
- **Adult Assembly Required:** This product contains small parts and requires adult assembly. Keep children away during assembly.
- **Weight Limits:** Do not overload drawers or the top surface. Refer to specifications for maximum weight capacity.
- **Supervision:** Children should be supervised when using the dresser to prevent misuse or climbing.
- **Placement:** Place the dresser on a flat, stable surface.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Steel Frame Components

- Wood Top Panel
- Fabric Drawers (7 units: 4 small, 3 large)
- Drawer Handles (7 units)
- Adjustable Feet (4 units)
- Assembly Hardware (screws, Allen wrench, anti-tip kit)
- Instruction Manual

SETUP & ASSEMBLY INSTRUCTIONS

No additional tools are necessary for assembly; an Allen wrench is included. Assembly typically takes approximately 15-30 minutes.

Step 1: Assemble the Steel Frame

Connect the steel frame components according to the diagrams provided in the included instruction manual. Ensure all screws are tightened securely using the provided Allen wrench. The frame forms the structural support for the drawers and wood top.



Figure 2: Key components including the sturdy steel frame and wood top.

Step 2: Attach the Wood Top and Adjustable Feet

Once the steel frame is complete, place the wood top panel onto the frame and secure it with the designated screws. Screw the adjustable feet into the bottom of the frame. These feet help stabilize the dresser on uneven surfaces.

Step 3: Prepare and Insert Fabric Drawers

Unfold each fabric drawer. Insert the reinforced base panel into the bottom of each drawer to give it shape and stability. Attach the handles to the front of each drawer using the provided screws and Allen wrench. Once assembled, slide the drawers into their respective slots within the steel frame.




Figure 3: Fabric drawers with reinforced bases and ample storage capacity.

Step 4: Install Anti-Tip Kit

For safety, it is crucial to install the anti-tip kit. Follow the specific instructions provided with the kit to secure the dresser to a wall stud. This prevents the dresser from tipping over, especially if children attempt to climb on it or pull out multiple drawers.

OPERATING INSTRUCTIONS

The Sorbus Kids Dresser is designed for easy and functional use.

- **Opening/Closing Drawers:** Gently pull or push the drawer handles to open and close the fabric drawers. Avoid forcing them.
- **Loading Items:** Distribute weight evenly within each drawer. Avoid placing excessively heavy items in the drawers to maintain their shape and longevity.
- **Drawer Removal:** Drawers can be easily removed and folded flat for storage or transport when not in use. Simply lift the drawer out of its slot.

MAINTENANCE

Proper care will extend the life of your dresser.

- **Cleaning Fabric Drawers:** The fabric drawers are made of breathable, waterproof material. For minor spills, wipe with a damp cloth and mild soap. Air dry completely. Do not machine wash or tumble dry.
- **Cleaning Frame and Top:** Wipe the steel frame and wood top with a soft, dry or slightly damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.

TROUBLESHOOTING

If you encounter any issues, refer to the following common solutions:

- **Drawers not fitting/sliding smoothly:** Ensure the steel frame is assembled correctly and all bars are in their proper positions. Check that the reinforced base is fully inserted into each fabric drawer.
- **Dresser feels wobbly:** Verify that all frame screws are tightened. Adjust the leveling feet on the bottom of the dresser to ensure it sits evenly on the floor. Confirm the anti-tip kit is securely installed.
- **Missing parts:** Do not attempt to assemble with missing parts. Contact Sorbus customer support for replacements.

SPECIFICATIONS

Feature	Detail
Brand	Sorbus
Model Name	DRW-6D-TID6
Product Dimensions	25"D x 28.75"W x 11.87"H
Number of Drawers	7 (4 small, 3 large)
Color	Rainbow Sparkle
Material	Fabric, Steel Frame, Wood Top
Assembly Required	Yes
Item Weight	19.16 pounds

I Compact Size




Figure 4: Detailed dimensions of the dresser and its drawers.

WARRANTY & SUPPORT

For warranty information, product support, or to order replacement parts, please contact Sorbus customer service. Refer to the original packaging or the official Sorbus website for contact details. Please have your model number (DRW-6D-TID6) and purchase date available when contacting support.