

**NDHWHE NP-HBH10C, HLH10, HBF10, NP-HLH10, NP-HBQ10**

# **IH Rice Cooker Inner Bowl Instruction Manual**

Brand: NDHWHE

## **1. INTRODUCTION**

This manual provides essential information for the proper use and maintenance of your new NDHWHE replacement inner bowl for IH rice cookers. Designed for durability and optimal cooking performance, this black gold steel pot is a direct replacement for specific Zojirushi models, ensuring your rice cooker continues to function efficiently.

### **Compatibility**

This inner bowl is compatible with the following ZOJIRUSHI IH rice cooker models:

- NP-HBH10C
- HLH10
- HBF10
- NP-HLH10
- NP-HBQ10



*Figure 1: The replacement inner bowl for IH rice cookers. The bowl is made of black gold steel and features clear markings on its interior wall for measuring rice and water levels, including specific lines for white rice and brown rice. A hand is shown holding the bowl, providing a sense of its size and form.*

## 2. SETUP AND INSTALLATION

Before first use, ensure the inner bowl is clean. This replacement bowl is designed to fit directly into your compatible Zojirushi IH rice cooker. No special tools or procedures are required for installation.

1. **Unpack:** Carefully remove the new inner bowl from its packaging.
2. **Inspect:** Check the bowl for any signs of damage from shipping. If damaged, do not use and contact customer support.
3. **Initial Cleaning:** Wash the inner bowl thoroughly with warm water and mild dish soap. Rinse completely and dry with a soft cloth.
4. **Placement:** Place the clean, dry inner bowl into the main body of your compatible Zojirushi IH rice cooker, ensuring it sits securely and flat at the bottom.

The inner bowl is now ready for use with your rice cooker.

## 3. OPERATING INSTRUCTIONS

The NDHWHE replacement inner bowl functions identically to the original bowl it replaces. Refer to your specific Zojirushi rice cooker's instruction manual for detailed cooking procedures, rice-to-water ratios, and cooking modes. The markings inside the bowl are designed to assist with accurate measurements for various types of rice.

- **Measuring Rice:** Use the measuring cup provided with your rice cooker. Add the desired amount of rice to the inner bowl.
- **Adding Water:** Fill water up to the corresponding water level mark inside the inner bowl for the type and quantity of rice you are cooking. The bowl features markings for white rice and other rice types.
- **Placement:** Ensure the outer surface of the inner bowl is dry before placing it into the rice cooker's main unit.
- **Cooking:** Close the rice cooker lid and select the appropriate cooking program on your rice cooker.

Always ensure the inner bowl is properly seated before starting the cooking cycle to prevent uneven cooking or damage to the rice cooker.

## 4. MAINTENANCE AND CARE

Proper care and maintenance will extend the life of your inner bowl and ensure continued optimal cooking performance.

### Cleaning

- **After Each Use:** After the bowl has cooled, wash it with warm water and a soft sponge or cloth using mild dish soap.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or metal utensils, as these can damage the non-stick coating and the black gold steel surface.
- **Stubborn Residue:** If rice sticks, soak the bowl in warm water for a few minutes to loosen the residue before cleaning.
- **Drying:** Dry the bowl thoroughly with a soft cloth before storing or placing it back into the rice cooker.

### Storage

- Store the inner bowl in a dry place.
- If storing inside the rice cooker, ensure both the bowl and the cooker are completely dry to prevent moisture buildup.

## 5. TROUBLESHOOTING

This section addresses common issues related to the inner bowl. For issues related to the rice cooker's electrical functions or cooking programs, refer to your rice cooker's original manual.

Problem	Possible Cause / Solution
Rice sticking to the bottom of the bowl.	<p><i>Insufficient water:</i> Ensure you are using the correct water-to-rice ratio as per your rice cooker's instructions and the bowl's markings.</p> <p><i>Damaged coating:</i> Avoid using metal utensils or abrasive cleaners that can scratch the non-stick surface.</p> <p><i>Not soaking:</i> For certain rice types, a short pre-soak can help.</p>
Bowl does not fit properly in the rice cooker.	<p><i>Incorrect model:</i> Verify that your rice cooker model is listed under the compatible models in Section 1.</p> <p><i>Obstruction:</i> Check for any food debris or foreign objects inside the rice cooker's main unit that might prevent the bowl from seating correctly.</p>

Problem	Possible Cause / Solution
Scratches or wear on the inner coating.	<i>Improper utensils:</i> Always use plastic, silicone, or wooden utensils when stirring or serving rice. <i>Abrasive cleaning:</i> Use only soft sponges and mild dish soap for cleaning.

## 6. SPECIFICATIONS

Key specifications for the NDHWHE replacement inner bowl:

Product Name	Rice Cooker Inner Pot
Material	Black Gold Steel
Compatible Models	ZOJIRUSHI NP-HBH10C, HLH10, HBF10, NP-HLH10, NP-HBQ10
Item Weight	1.76 ounces (approx. 50 Grams)
Package Dimensions	1.18 x 0.79 x 0.39 inches
Color	One Color (typically dark grey/black)

## 7. IMPORTANT INFORMATION

This inner bowl is a replacement part designed to restore the functionality of your compatible rice cooker. For any issues not covered in this manual, or for specific warranty information regarding your original rice cooker unit, please refer to the manufacturer's documentation for your Zojirushi rice cooker.

For product support regarding this NDHWHE replacement inner bowl, please contact the seller directly through the platform where it was purchased.