

## PERFASCIN YKR-K002E

# PERFASCIN YKR-K/002E Replacement Remote Control User Manual

Model: YKR-K002E

## 1. INTRODUCTION

Thank you for choosing the PERFASCIN YKR-K/002E Replacement Remote Control. This manual provides detailed instructions on how to set up, operate, and maintain your new remote control. This remote is designed as a direct replacement for various AUX AC Air Conditioner models, ensuring seamless compatibility and ease of use without the need for complex programming.

**Compatible Models:** YKR K002E, YKR K204E, YKR K001E, YKR-K/204E, YKR-K/001E

## 2. PRODUCT OVERVIEW

The YKR-K/002E remote control is a user-friendly device designed to provide full control over your compatible AUX AC Air Conditioner. It features a clear LCD display and intuitively placed buttons for various functions.





Figure 2.1: Front view of the YKR-K/002E Remote Control.



Figure 2.2: Angled view of the YKR-K/002E Remote Control.





Figure 2.3: Back view of the YKR-K/002E Remote Control with model identification.

## 3. SETUP

---

### 3.1 Battery Installation

The YKR-K/002E remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 3.1: Battery compartment with cover removed.

**Important: Ensure correct battery polarity. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period.**

## 4. OPERATING INSTRUCTIONS

---

Once batteries are installed, the remote is ready for use. Point the remote control directly at the infrared receiver on your AUX AC Air Conditioner unit.

### 4.1 Basic Functions

- **ON/OFF Button:** Press to turn the air conditioner on or off.
- **MODE Button:** Press repeatedly to cycle through operating modes: Auto, Cool, Dry, Fan, Heat (modes may vary by AC unit).
- **SPEED Button:** Adjusts the fan speed (e.g., Auto, Low, Medium, High).
- **SET Button:** Used in conjunction with the Up/Down arrow buttons to confirm settings or enter specific menus.
- **Up/Down Arrow Buttons (▲ / ▼):** Adjust temperature, timer settings, or navigate menu options.

### 4.2 Advanced Functions

- **SWING / SWING2 Buttons:** Control the horizontal and vertical movement of the air conditioner's louvers for optimal air distribution.
- **TIMER Button:** Press to set the auto-on or auto-off timer for the air conditioner. Use the Up/Down arrows to adjust the time.
- **STRONG Button:** Activates a rapid cooling or heating function for quick temperature changes.
- **FEELING Button:** Often refers to an "I FEEL" mode, where the remote's built-in sensor measures the ambient temperature and adjusts the AC operation for enhanced comfort.
- **CLEAN Button:** Initiates the self-cleaning function of the indoor unit (if supported by your AC model).
- **HEALTH Button:** Activates air purification or health-related functions (e.g., ionizer, specific filters) if available on your AC unit.
- **SLEEP Button:** Engages sleep mode, which typically adjusts temperature and fan speed for comfortable sleep and energy saving.
- **SCREEN Button:** Controls the display backlight or screen settings on the remote or AC unit.
- **FUNGUSPROOF Button:** Activates an anti-mildew or fungus prevention function, often by running the fan after cooling to dry the coil.

## 5. MAINTENANCE

---

### 5.1 Cleaning the Remote

To maintain the remote control's appearance and functionality, clean it regularly:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, abrasive cleaners, or immerse the remote in water.

### 5.2 Battery Replacement

Replace batteries when the remote's display becomes dim or its range decreases. Refer to Section

3.1 for battery installation instructions.

### 5.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.

## 6. TROUBLESHOOTING

If you encounter issues with your remote control, please refer to the following common problems and solutions:

| Problem                                 | Possible Cause                                                                   | Solution                                                                                                                            |
|-----------------------------------------|----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| Remote not responding                   | Dead or incorrectly installed batteries. Obstruction between remote and AC unit. | Replace batteries, ensuring correct polarity. Remove any obstructions. Ensure remote is pointed directly at the AC unit's receiver. |
| Limited operating range                 | Weak batteries. Interference from other electronic devices.                      | Replace batteries. Move away from other electronic devices that might cause interference.                                           |
| AC unit not performing desired function | Incorrect mode selected. AC unit not supporting the specific function.           | Verify the correct operating mode is selected. Consult your AC unit's original manual to confirm supported functions.               |

## 7. SPECIFICATIONS

- **Model:** YKR-K002E
- **Dimensions:** 15.24 x 7.62 x 1.27 cm (6 x 3 x 0.5 inches)
- **Weight:** 56.7 g (2 oz)
- **Power Supply:** 2 x AAA Batteries (not included)
- **Connectivity:** Infrared (IR)
- **Compatible AC Models:** YKR K002E, YKR K204E, YKR K001E, YKR-K/204E, YKR-K/001E

## 8. SUPPORT

For any questions, concerns, or assistance regarding your PERFASCIN YKR-K/002E Replacement Remote Control, please contact the seller or manufacturer directly through the platform where you purchased the product. We are committed to providing the best service and resolving any issues you may encounter.

