

ZAFRO 5323

ZAFRO Tower Fan Instruction Manual

MODEL: 5323

Important Safety Instructions

Please read this manual carefully before operating the ZAFRO Tower Fan. Keep these instructions for future reference.

- Ensure the fan is placed on a stable, flat surface to prevent tipping.
- Do not insert fingers or objects into the fan grille.
- Keep the fan away from water or moist environments.
- Unplug the fan from the power outlet before cleaning or maintenance.
- Do not operate the fan with a damaged cord or plug.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Product Overview

Package Contents

- ZAFRO Tower Fan Unit
- Fan Base (2 pieces)
- Remote Control
- Instruction Manual

Product Features

- **Multiple Wind Options:** 4 modes (Normal, Natural, Sleep, Automatic Temperature Control) for a comfortable and energy-saving experience.
- **Ultra-Wide 90° Oscillation:** Expands air delivery area for even and smooth breeze throughout the room.
- **Long-Range Air Delivery:** Powerful airflow up to 23 feet (approximately 7 meters) to cool large spaces

effectively.

- **12H Timer & Sleep Mode:** Built-in 12-hour precision timer and thoughtful sleep mode for energy-efficient nighttime use.
- **Intelligent Temperature Control & Remote Control:** Automatic mode adjusts wind speed based on ambient temperature. Includes a remote control for convenient operation.



Image: Front view of the ZAFRO Tower Fan, showcasing its sleek design.

Setup and Assembly

Assembling the Base

1. Take out the two base pieces from the packaging.
2. Connect the two pieces together by aligning the tabs and snapping them into place.
3. Fit the assembled base onto the bottom of the fan unit.
4. Rotate the base anti-clockwise to lock it securely in place.



Image: A diagram illustrating the step-by-step process of assembling the two-piece fan base.

Placing the Fan

Once assembled, place the ZAFRO Tower Fan on a firm, level surface. Ensure there is adequate space around the fan for optimal airflow and oscillation.

Video: Demonstrates the unboxing and assembly process of the ZAFRO Tower Fan, including attaching the base and initial power-on.

Operating Instructions

Control Panel and Remote Control

The ZAFRO Tower Fan can be operated using the touch control panel on the top of the unit or the included remote control. The control panel features intuitive icons for various functions.



Image: Close-up of the fan's LED display and touch control buttons, alongside the remote control with its corresponding functions.

Power On/Off

- Press the **Power button** () on the control panel or remote to turn the fan on or off.

Adjusting Fan Speed

- Press the **Speed button** () to cycle through 3 available fan speeds (Low, Medium, High).


Selecting Modes

The fan offers 4 distinct modes:

- **Normal Mode:** Provides a constant, steady airflow.
- **Natural Mode:** Simulates a natural breeze by varying fan speed.
- **Sleep Mode:** Gradually reduces fan speed and dims the display for undisturbed sleep.
- **Automatic Temperature Control Mode:** Adjusts fan speed automatically based on the ambient room temperature.

Press the **Mode button** () to switch between these modes.

1-12 Hours Timer



Turn on the timer
before bedtime

Turn off automatically
after falling asleep

Image: Visual representation of the four operating modes: Normal, Natural, Auto, and Sleep, with their respective icons.

Oscillation Function

- Press the **Oscillation button** () to activate or deactivate the 90° oscillation feature, distributing air across a wider area.




Image: A diagram illustrating the 90-degree oscillation capability of the tower fan, showing its wide coverage area.

Timer Setting

- Press the **Timer button** () to set the fan to automatically turn off after a specified period, from 1 to 12 hours. Each press increases the timer by one hour.

Making Cleaning A Breeze

Detachable Design



Washable grill and honeycomb



Image: A visual guide to setting the 12-hour timer, highlighting the timer button on the control panel.

Video: Demonstrates the various modes and speed settings of the ZAFRO Tower Fan, including how to switch between them.

Maintenance and Cleaning


General Cleaning

Regular cleaning helps maintain the fan's performance and extends its lifespan.

1. Always unplug the fan before cleaning.
2. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
3. The fan features a detachable design for easy cleaning of the internal components. Carefully detach the front grille and internal honeycomb structure.
4. Wash the detachable grille and honeycomb with mild soap and water. Ensure they are completely dry before reassembling.
5. Do not immerse the main fan unit in water.

Making Cleaning A Breeze

Detachable Design



Washable grill and honeycomb



Image: Illustrates the detachable front grille and internal honeycomb, highlighting the ease of cleaning for maintenance.

Troubleshooting

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Power button not pressed.	Check if the power cord is securely plugged into a working outlet. Press the Power button on the fan or remote.
Weak or no airflow.	Air inlet/outlet blocked. Fan speed set too low.	Ensure air inlets and outlets are clear of obstructions. Increase the fan speed using the Speed button.
Oscillation not working.	Oscillation function is off.	Press the Oscillation button to activate the feature.
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and fan.	Replace batteries (1 C battery required, included) and ensure correct polarity. Remove any obstructions. Ensure remote is pointed at the fan.

Specifications

Feature	Detail
Brand	ZAFRO
Model Name	5323
Color	Grey

Feature	Detail
Electric Fan Design	Floor Fan (Tower Style)
Power Source	AC
Product Dimensions	11.81"D x 11.81"W x 35.43"H
Item Weight	7.92 Pounds
Special Features	Portable, Remote Controlled, Timer, Oscillation, 4 Modes, 3 Speeds
Noise Level	50 Decibels
Wattage	50 watts
Voltage	120.0 V
Indoor/Outdoor Usage	Indoor, Outdoor (<i>Note: Ensure protection from elements if used outdoors</i>)
Control Method	Remote, Touch Panel
Batteries	1 C battery required (included for remote)
Assembly Required	Yes (Base assembly)

Warranty and Support

ZAFRO products are manufactured to high-quality standards. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, warranty inquiries, or replacement parts, please contact ZAFRO customer service. Contact details can typically be found on the product packaging or the official ZAFRO website.

Please visit [the ZAFRO Store on Amazon](#) for more information and support resources.