Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Proscenic P-US-SH-F10Pro

Proscenic F10 Pro Cordless Wet Dry Vacuum Cleaner User Manual

Model: P-US-SH-F10Pro

Product Overview

Key Features

- **3-in-1 Vacuum/Mop/Wash:** The F10 Pro is the ultimate vacuum mop all in one, featuring 550 RPM spin and strong suction to tackle tough stains on hard floors. Perfect as a mop vacuum cleaner for hard floor.Choose from three modes: Smart mode for daily cleaning, Max mode for heavy-duty stains, and Suction mode for liquid absorption
- **Automated Self-Cleaning:** With just one press, the wet dry vacuum cleaner cleans the roller brush and inner tube using fresh water, ensuring everything stays clean and odor-free. The vacuum and mop combo makes maintenance a breeze, saving you time and effort
- **High Capacity With Long Battery Life:** Designed for large spaces, the mop and vacuum all in one features a 6x2,600 mAh battery for 35 mins* of runtime and a 650 mL clean water tank paired with a 500 mL dirty water tank. Clean up to 970 sqft without interruption, making it an ideal wet vacuum cleaner for hard floor
- **User-Friendly LED Display & Voice Guidance:** The vacuum mop comes with an intuitive LED screen and voice prompts, keeping you informed about battery life, cleaning modes, and maintenance alerts. Its user-friendly design ensures anyone can operate it with ease
- **Self-Propelled & Effortless Cleaning:** The vacuum mop all in one features a self-propulsion system for effortless forward motion and a flexible floor brush for superior maneuverability. Whether you're cleaning hard floors or carpets, the F10 Pro delivers a comfortable and thorough cleaning experience
- **Easy Maintenance:** The solid-liquid separator in the dirty water tank makes dirt removal quick and easy. The charging base stores and charges the F10 Pro for utmost convenience



Figure 1: The Proscenic F10 Pro Cordless Wet Dry Vacuum Cleaner with its charging base and cleaning solution.

Setup and Assembly

Unboxing and Initial Assembly

The Proscenic F10 Pro is designed for quick and easy assembly. You can have it ready for use in less than 2 minutes right out of the box by following a few simple and straightforward instructions.



Figure 2: Simple assembly of the Proscenic F10 Pro.

Filling the Clean Water Tank

The device is equipped with a high-capacity 650 mL clean water tank. To fill, simply remove the tank, open the cap, and pour in clean water up to the MAX line. You can also add the recommended cleaning solution.

Figure 3: Filling the clean water tank for optimal performance.

Video 1: Official Proscenic F10 Pro Wet Dry Vacuum Cleaner overview, including assembly and water tank filling.

Operating Instructions

Understanding the LED Display and Voice Guidance

The F10 Pro features a user-friendly LED display and voice prompts. The LED screen provides real-time information on battery life, current cleaning mode, and maintenance alerts. Voice guidance will assist you through the cleaning process, confirming mode changes and alerting you to necessary actions, such as refilling the clean water tank or checking the roller brush.



Figure 4: Intuitive LED display showing battery, mode, and alerts.

Cleaning Modes

The F10 Pro offers three versatile cleaning modes:

- **Smart Mode:** Ideal for daily cleaning tasks.
- **Max Mode:** Provides increased power and suction for tackling heavy-duty stains and stubborn messes.
- **Suction Mode:** Specifically designed for absorbing liquids, preventing spills from spreading.



Figure 5: The F10 Pro's 3-in-1 functionality for vacuuming, mopping, and washing.

Self-Propelled Movement

The self-propulsion system of the F10 Pro ensures effortless forward motion, significantly reducing the physical effort required to operate the device. This feature makes cleaning large areas less tiring and more efficient.

Figure 6: The self-propelled system makes cleaning effortless.

Edge Cleaning

The F10 Pro features a specially designed narrow brush that allows for effective edge-to-edge cleaning. This ensures that dirt and debris are picked up even from hard-to-reach areas along walls and furniture, leaving no spot untouched.

Figure 7: The narrow brush design allows for thorough edge cleaning.

Maintenance

Automated Self-Cleaning

After each use, simply place the F10 Pro on its charging base and press the self-cleaning button. The device will automatically clean the roller brush and inner tubes with fresh water, ensuring it remains hygienic and odor-free for the next use.

Figure 8: The F10 Pro's automated self-cleaning function.

Video 2: Official Proscenic F10 Pro Wet Dry Vacuum Cleaner overview, including self-cleaning demonstration.

Emptying the Dirty Water Tank

The F10 Pro features a 500 mL dirty water tank with a solid-liquid separator, making disposal quick and easy. Simply remove the tank, empty the dirty water and any collected debris, and rinse it thoroughly.



Figure 9: The dirty water tank with solid-liquid separation.

Video 3: Demonstration of how to clean out the Proscenic F10 Pro's dirty water tank.

Cleaning the Roller Brush

The roller brush is easily removable for manual cleaning. Simply unlock the brush cover, pull out the brush from the narrow side, remove any tangled hair or debris, and rinse it under running water. Allow it to air dry completely before reinserting.

Troubleshooting

If you encounter any issues with your Proscenic F10 Pro, please refer to the following common problems and solutions:

- **"Dirty water tank full" alert:** This indicates that the dirty water tank has reached its capacity. Empty and clean the dirty water tank as per the maintenance instructions.
- **Roller brush clogs:** If the device's performance is reduced or the voice guidance alerts you to a brush issue, the roller

brush may be clogged. Remove and clean the roller brush thoroughly as per the maintenance instructions.

- **Low battery:** The LED display will show a low battery percentage and voice guidance will prompt you to charge. Place the device on its charging base to recharge.

Specifications

Attribute	Value
Brand	Proscenic
Special Feature	Wet/Dry, Lightweight, High Power, Cordless, Washable Filter
Filter Type	HEPA Filter
Included Components	Main unit*1 (including floor brush, roller brush, hepa), handle*1, base*1, adapter*1, cleaning brush*1, manual*1, after-sales card*1
Is Cordless?	Yes
Capacity	1200 Milliliters
Wattage	300 watts
Runtime	35 minutes
Recommended Uses For Product	Kitchen, Car, Pet Hair, Home
Form Factor	Stick
Color	White
Model Name	P-AMZ-CZZ-US-F10 Pro
Product Dimensions	43"L x 8"W x 10"H
Noise Level	68 dB
Battery Life	35 minutes
Manufacturer	Proscenic
Number of Items	1
Control Method	Touch, Voice
Style	Modern

Indoor/Outdoor Usage	Indoor
Item Weight	8.8 pounds
ASIN	B0DZ1TQ433
Country of Origin	China
Item model number	P-US-SH-F10Pro
Batteries	1 AAA batteries required. (included)
Customer Reviews	4.3 4.3 out of 5 stars 152 ratings 4.3 out of 5 stars
Best Sellers Rank	#686,651 in Home & Kitchen (See Top 100 in Home & Kitchen) #765 in Stick Vacuums & Electric Brooms
Specific instructions for use	Wet/Dry, Vacuum, Kitchen, Home, Mop
Batteries required	Yes
Included Components	(function(f) {var _np= (window.P._namespace("DetailPageProductOverviewTemplatesJava"));if(_np.guardFatal) {_np.guardFatal(f)(_np);}else{f(_np);}}(function(P) { P.when('A').execute(function(A){ A.on('a:truncate:po-attribute-truncate-3:updated', function(data) { var isTruncated = !data.truncateInstance.getIfTextFits(); var seeMoreElement = document.getElementById('po-attribute-see-more-id-3'); if(seeMoreElement) { seeMoreElement.style.display = isTruncated ? '' : 'none'; } }) });})); Main unit*1 (including floor brush, roller brush, hepa), handle*1, base*1, adapter*1, cleaning brush*1, manual*1, after-sales card*1 See more

Warranty and Support

The Proscenic F10 Pro comes with a 24-month warranty, ensuring peace of mind for your purchase. Protection plans for 2-Year and 3-Year are also available.

For any inquiries or support needs, please contact Proscenic Tech, the official seller. They offer 24/7 rapid responding service, 30-day money-back service, and lifetime technical support.



Figure 10: Proscenic's expert support team is available to assist you.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZ1TQ433

More documents and user manuals: **https://manuals.plus/**