

Manuals.plus /

› JANCANOPY /

› JANCANOPY 13x13 Canopy Replacement Top Instruction Manual

JANCANOPY 13x13 Canopy Replacement Top

JANCANOPY 13x13 Canopy Replacement Top Instruction Manual

Model: 13x13 Canopy Replacement Top

Brand: JANCANOPY



Image 0.1: The JANCANOPY 13x13 Canopy Replacement Top, featuring a red and white design, ready for installation on a compatible gazebo frame.

1. PRODUCT OVERVIEW AND COMPATIBILITY

This manual provides instructions for the JANCANOPY 13x13 Canopy Replacement Top. This product is designed to replace the canopy cover on specific 13x13 foot instant pop-up gazebo frames.

1.1 Package Contents

- One (1) JANCANOPY 13x13 Canopy Replacement Cover.

Note: Metal frame structure and netting are not included with this replacement cover.

1.2 Compatibility

This replacement top is specifically designed for the following 13 FT x 13 FT instant pop-up gazebo frames:

- Coleman Oasis models: 1606532, 2156426, 2156428, 2157498, 2622040
- CORE 13 FT x 13 FT models: #40155, #40363, #40325

Important: Before purchasing and installing, confirm your gazebo model and accurately measure your frame dimensions. This replacement top will not fit frames from other brands or models.



Image 1.2.1: The JANCANOPY 13x13 Canopy Replacement Top, illustrating its dimensions of 13ft x 13ft (156 inches / 396 cm) for the main canopy area. This image helps verify the size for compatibility with existing frames.

2. SETUP AND INSTALLATION

Follow these general steps to install your new JANCANOPY replacement top. Installation typically requires two people.

2.1 Preparation

1. Ensure your existing gazebo frame is clean and free of debris.
2. Carefully remove the old canopy top, if still present.
3. Inspect the frame for any damage or sharp edges that could tear the new canopy.
4. Unfold the new JANCANOPY replacement top on a clean, flat surface.

2.2 Installation Steps

1. With the gazebo frame partially collapsed (or at its lowest setting), carefully drape the new canopy top over the frame. Ensure the air vent is positioned correctly at the peak.
2. Align the corners of the canopy with the corners of the frame.
3. Secure the canopy to the frame using the integrated nylon buckles or straps. Start with one corner and work your way around, ensuring a snug fit.
4. Gradually extend the gazebo frame to its full height, ensuring the canopy fabric stretches evenly without excessive tension in any single area.
5. Once the frame is fully extended, double-check all attachments to ensure the canopy is securely fastened.



Image 2.2.1: An illustration showing the canopy replacement top positioned above a compatible gazebo frame, indicating the overall dimensions and how the top fits onto the frame structure.

3. FEATURES AND SPECIFICATIONS

The JANCANOPY 13x13 Canopy Replacement Top is engineered with specific features for durability and performance.


3.1 Key Features

- **Material:** High-quality 400D Polyester fabric.
- **Water Resistance:** 100% waterproof with PU coating on the outside, capable of withstanding 1800mm water pressure.
- **UV Protection:** Silver coating on the inside provides 99% UV protection, helping to keep the area underneath cool.
- **Air Vent Design:** Features two air vents at the roof peak for improved air circulation and stability in windy conditions.
- **Reinforcement:** Double-layer reinforcement at key stress points to enhance durability and prevent tearing.
- **Wear Resistance:** Designed to be wear-resistant and tear-resistant for extended use.


BETTER THAN ORIGINAL



Inside 99% UV Protection
with thickened silver-coated.



Outside 100% Waterproof
outside made of 400D polyester.



Manufacturer Original design
Check your gazebo frame structure.



Stress Point Reinforcement
double layer at each force point.



Image 3.1.1: Visual representation of the canopy's key features, including 99% UV protection from the silver-coated interior, 100% waterproof exterior made of 400D polyester, original manufacturer design, and double-layer reinforcement at stress points.





Image 3.1.2: A close-up view illustrating the dual-layer construction of the canopy fabric, highlighting the silver coating on the inside for 99% UV protection and the PU coating on the outside for 100% waterproofing.

WITH AIR VENT



Water-resistant



Wear-resistant



UV-resistant



Fire resistant

Image 3.1.3: The canopy top featuring an integrated air vent for improved airflow and stability. Accompanying icons denote its water-resistant, wear-resistant, UV-resistant, and fire-resistant properties.



Image 3.1.4: Detailed view of the JANCANOPY cover's construction, highlighting the air vent design for circulation, multiple nylon buckles for easy installation, 100% waterproof 400D polyester material, and double-layer reinforcement at stress points.

3.2 Technical Specifications

Specification	Detail
Dimensions	156 in x 156 in (13 ft x 13 ft / 396 cm x 396 cm)
Material	400D Polyester with PU and Silver Coating
Water Resistance Level	Waterproof (1800mm water pressure)
UV Protection	99% UV protective
Item Weight	2.49 Kilograms (5.48 pounds)
Assembly Required	No (for the cover itself, but installation onto frame is required)
Color	Red (as per current product variant)

4. CARE AND MAINTENANCE

Proper care and maintenance will extend the lifespan of your JANCANOPY replacement top.

- **Cleaning:** Clean the canopy top with mild soap and water. Do not use harsh chemicals or abrasive cleaners, as these can damage the fabric and coatings.
- **Drying:** Ensure the canopy is completely dry before folding and storing to prevent mildew and mold growth.
- **Storage:** When not in use for extended periods, remove the canopy top from the frame and store it in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Weather Conditions:** While the canopy is waterproof and UV-resistant, it is recommended to take it down during severe weather conditions such as heavy winds, snow, or hail to prevent damage to both the canopy and the frame.

- **Inspection:** Periodically inspect the canopy for any signs of wear, tear, or damage. Address minor issues promptly to prevent them from worsening.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your canopy replacement top.

5.1 Canopy Does Not Fit

- **Verify Model:** Double-check that your gazebo frame model number matches one of the compatible models listed in Section 1.2.
- **Measure Frame:** Confirm the dimensions of your frame. The JANCANOPY replacement top is designed for 13x13 ft frames. Slight variations in frame design can affect fit.
- **Installation Alignment:** Ensure the canopy is correctly aligned and stretched evenly across the frame. Sometimes, starting from one corner and working around can help achieve a better fit.

5.2 Water Pooling on Top

- **Frame Tension:** Ensure the gazebo frame is fully extended and locked into place, providing maximum tension to the canopy. A loose frame can cause sagging.
- **Canopy Tightness:** Verify that all buckles and straps securing the canopy to the frame are tightened appropriately to prevent slack.
- **Frame Leveling:** Ensure the gazebo frame is set up on level ground. Uneven ground can cause the frame to tilt, leading to water accumulation.

5.3 Tearing or Damage

- **Sharp Edges:** Inspect your gazebo frame for any sharp edges or burrs that could abrade or tear the fabric. File down any rough spots if found.
- **Over-Stretching:** Avoid excessive force during installation that could over-stretch the fabric.
- **Weather Conditions:** High winds or heavy snow/ice accumulation can cause damage. Always take down the canopy in adverse weather.

6. WARRANTY AND SUPPORT

For specific warranty information or further assistance, please contact JANCANOPY customer support through the retailer where the product was purchased.

Please retain your proof of purchase for any warranty claims.