

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [LAMA](#) /
- > [LAMA Mini Portable Electric Espresso Machine User Manual](#)

**LAMA 24070d23-d70a-4c31-b36e-49da660494c0**

# LAMA Mini Portable Electric Espresso Machine User Manual

Model: 24070d23-d70a-4c31-b36e-49da660494c0

## 1. INTRODUCTION

---

Thank you for choosing the LAMA Mini Portable Electric Espresso Machine. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.



Image: The LAMA Mini Portable Electric Espresso Machine in grey, showcasing its compact design.

## 2. SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not immerse the main unit in water or other liquids.
- Keep out of reach of children.
- Use only the provided USB-C charging cable.
- Do not operate if the appliance is damaged.
- Ensure the water tank capacity is not exceeded (60 ml).
- Exercise caution when handling hot water or hot coffee.
- Avoid touching heating elements directly.

## 3. PACKAGE CONTENTS

Verify that all items are present in the package:


- 1 x Portable Espresso Machine
- 1 x Type-C Charging Cable
- 1 x Coffee Powder Spoon
- 1 x User Manual

## 4. PRODUCT FEATURES

---

- **3-in-1 Compatibility:** Supports ground coffee, small capsules (NS type), and large capsules (Dolce Gusto/Starbucks type).
- **Portable Design:** Weighs 584g with a 7500 mAh battery for easy transport.
- **Automatic Rapid Heating:** Heats cold water in 3-4 minutes for hot brewing. Instant brewing with hot water.
- **Easy Operation:** One-click start and automatic extraction. Three different extraction modes.
- **LED Display:** Monitors battery level and displays extraction temperature.
- **High Pressure Extraction:** 15 bars of pressure for rich crema.

# EXTRACTING & LONG LASTING USE



**1** Fully Charge  
=



**4 Cups**  
50ml cold water



**50+ Cups**  
hot water



Image: Illustration of battery life, indicating 4 cups with cold water and over 50 cups with hot water per full charge.

# WIRELESS & PORTABLE

Enjoy your beloved espresso anytime anywhere




Image: A person hiking with the portable espresso machine attached to their backpack, highlighting its wireless and portable nature.



Image: The espresso machine in use across different environments, including an office, outdoor camping, at home, and in an RV, demonstrating its versatility.

## 5. SETUP

### 5.1 Initial Charge

Before first use, fully charge the espresso machine using the provided USB-C cable. Charging typically takes 3-4 hours.

### 5.2 Preparing for Coffee Extraction

The machine supports three types of coffee preparation:

1. **For Large Coffee Capsules:** Insert the large capsule adapter, then place the large capsule into the adapter.
2. **For Small Coffee Capsules:** Insert the small capsule adapter, then place the small capsule into the adapter.
3. **For Ground Coffee:** Fill the coffee powder basket with ground coffee using the provided spoon. Ensure it is level and not overfilled.

# LED DISPLAY



Image: Detailed instructions showing the assembly process for using coffee capsules (large and small) and ground coffee with the machine.

## 6. OPERATING INSTRUCTIONS

### 6.1 Adding Water

Unscrew the top section of the machine and fill the water reservoir with up to 60 ml of water. You can use either cold or hot water depending on your desired brewing method.

# SUITABLE FOR BOTH HOT/COLD WATER

## Add hot water

Long press for 2s to enter direct extraction mode



## Add cold water

Double click to enter heating extraction mode



## Add cold water

Long press for 2s to enter direct extraction mode



Image: Visual guide for adding hot or cold water to the machine, illustrating the options for direct extraction with hot water, heating extraction with cold water, and direct extraction with cold water.

## 6.2 Brewing Coffee

Place the prepared coffee (capsule or ground) into the designated chamber and reassemble the machine. Place a cup under the dispenser.

- **Direct Extraction (Cold or Hot Water):** Press and hold the power button for 2 seconds. The machine will begin extraction.
- **Heating Extraction (Cold Water Only):** Double-click the power button. The machine will first heat the water to 95°C, then begin extraction. This process takes 3-4 minutes.

To stop extraction at any time, click the power button once.

# HOW TO USE ?

## Coffee Capsules (large cup)



## Coffee Capsules (small cup)



## Coffee Powder



Image: The espresso machine in operation, dispensing coffee into a cup, with the LED display showing the heating temperature, battery level, and controls for direct or heating extraction.

## 7. MAINTENANCE AND CLEANING

### 7.1 Daily Cleaning

After each use, disassemble the coffee basket/capsule adapter and rinse all removable parts under running water. Wipe the main unit with a damp cloth. Do not immerse the main unit in water.

### 7.2 Automatic Cleaning

For a more thorough cleaning of the internal system, fill the water reservoir with clean water (without coffee) and run a direct extraction cycle. This helps flush out any residual coffee.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not turn on.	Low battery.	Charge the machine fully.
Coffee is not hot enough.	Used cold water with direct extraction mode.	Use hot water for direct extraction or select heating extraction mode for cold water.
No coffee or slow extraction.	Clogged coffee filter/capsule. Insufficient water.	Clean the filter/capsule adapter. Ensure sufficient water is added.
Leakage during operation.	Parts not assembled correctly. Water tank overfilled.	Ensure all parts are securely tightened. Do not exceed 60 ml water capacity.

## 9. SPECIFICATIONS

---

**Brand:** LAMA

**Model Number:** 24070d23-d70a-4c31-b36e-49da660494c0

**Material:** ABS + 304 Stainless Steel + PA/GF

**Power:** 72 W

**Battery Capacity:** 7500 mAh

**Power Supply:** USB-C Charging Cable

**Operating Voltage:** 12 V

**Charging Voltage:** 12V / 1.5A

**Charging Time:** 3-4 hours

**Water Tank Capacity:** 60 ml

**Water Cup Capacity:** 150 ml

**Water Heating Temperature:** 95°C

**Anti-Dry Burn Temperature:** 145°C

**Dimensions (L x W x H):** 9 x 9 x 27 cm

**Item Weight:** 700 g

## 10. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official LAMA website. Keep your proof of purchase for warranty claims.

**Return Policy:** 30 days (refund/replacement).

**Seller:** LAMA Shop

**Seller Link:** [LAMA Shop on Amazon.fr](#)

