

[manuals.plus](#) /› [Fanttik](#) /› [Fanttik Slim V9 Mix & Slim V10 Mate Cordless Car Vacuum User Manual](#)

Fanttik Slim V9 Mix, Slim V10 Mate

Fanttik Slim V9 Mix & Slim V10 Mate

CORDLESS CAR VACUUM USER MANUAL

Model: Slim V9 Mix, Slim V10 Mate

1. Introduction

Thank you for choosing the Fanttik Slim V9 Mix or Slim V10 Mate Cordless Car Vacuum. These compact and powerful devices are designed for efficient cleaning of car interiors, small spaces, and various household items. This manual provides essential information for safe operation, optimal performance, and proper maintenance of your vacuum cleaner.

Please read this manual thoroughly before first use and keep it for future reference.

2. Safety Information

- Do not use the vacuum cleaner to pick up flammable or combustible liquids, hot ashes, or sharp objects.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not operate the vacuum cleaner with a damaged cord or plug.
- Ensure the filter is properly installed before use to prevent damage to the motor.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Only use the charging cable provided by the manufacturer.
- Store the vacuum cleaner in a dry place when not in use.

3. Package Contents

Please check the package for the following items:

- Fanttik Slim V9 Mix or Slim V10 Mate Car Vacuum
- Various Nozzle Attachments (e.g., brush nozzle, flat nozzle, extension hose)
- USB Charging Cable
- User Manual



Image: Fanttik Slim V9 Mix vacuum with its included accessories, such as different nozzles, a USB charging cable, and a cleaning brush.



Image: Fanttik Slim V10 Mate vacuum with its included accessories, including various nozzles, an extension hose, and a USB charging cable.

4. Product Overview

Familiarize yourself with the main components of your Fanttik car vacuum.



Image: The Fanttik Slim V9 Mix (left, L-shaped) and Slim V10 Mate (right, cylindrical) cordless car vacuums displayed together, highlighting their distinct designs and control buttons.

Key Components:

- **Dustbin:** Transparent container for collected debris.
- **Filter:** HEPA filter inside the dustbin.

- **Power Button:** To turn the device on/off.
- **Mode Button (V10 Mate):** To switch between suction modes.
- **LED Display/Indicators:** Shows battery level and suction mode.
- **Charging Port:** USB-C port for charging.
- **Nozzle Attachment Point:** Where accessories are connected.

5. Setup

5.1 Initial Charging

1. Before first use, fully charge the vacuum cleaner.
2. Connect the provided USB charging cable to the vacuum's charging port and a suitable USB power adapter (not included).
3. The LED indicators will show charging status. A full charge typically takes 2-3 hours.
4. Once fully charged, disconnect the charging cable.

5.2 Attaching Accessories

Select the appropriate nozzle for your cleaning task.

- **Crevice Nozzle:** Ideal for tight spaces, corners, and car seats.
- **Brush Nozzle:** Suitable for dusting surfaces, vents, and upholstery.
- **Extension Hose:** Provides flexibility for hard-to-reach areas.
- **Blowing Nozzles:** For blowing dust or inflating items (V9 Mix).
- **Inflating/Deflating Nozzles:** For air pump functions (V10 Mate).

To attach, simply push the desired nozzle firmly onto the vacuum's intake or exhaust port until it clicks into place. To remove, pull the nozzle off.

6. Operating Instructions

6.1 Powering On/Off and Suction Modes (Slim V9 Mix)

1. **Power On:** Press and hold the power button for 1 second. The LED display will show the current battery level and suction mode.
2. **Change Mode:** Briefly press the power button to cycle between Low Speed Mode (L) and High Speed Mode (H).
3. **Power Off:** Press and hold the power button for 1 second.

UPGRADED LED DISPLAY

Brings Interactive Experience



Battery
Level



Eco Mode:
30 mins



Max Mode:
13 mins



Image: Close-up of the Fonttik Slim V9 Mix's LED display, indicating battery level and the 'H' (High Speed) and 'L' (Low Speed) modes. The display shows 30 minutes for Eco Mode and 13 minutes for Max Mode.

6.2 Powering On/Off and Suction Modes (Slim V10 Mate)

- Power On:** Press and hold the power button for 1 second. The LED ring will illuminate, showing battery level.
- Change Mode:** Briefly press the mode button to cycle between Low Speed Mode (L) and High Speed Mode (H).
- Power Off:** Press and hold the power button for 1 second.

UPGRADED SMART DISPLAY



Image: Close-up of the Fanttik Slim V10 Mate's LED display, showing the battery level and 'H' (High Speed) and 'L' (Low Speed) indicators. The display shows 15 minutes for High Speed Mode and 35 minutes for Low Speed Mode.

6.3 Vacuuming Function

Attach the desired vacuum nozzle to the intake port. Turn on the vacuum and select the appropriate suction mode. Move the vacuum over the surface to be cleaned. Empty the dustbin when it reaches the MAX fill line.

VACUUM & BLOW IN ONE DESIGN

Versatile, fits for various scenarios



Image: Four panels demonstrating the vacuum's versatility: cleaning car seats, cleaning under car seats, cleaning car floor mats, and blowing leaves off a car windshield.

6.4 Blowing Function (V9 Mix & V10 Mate)

Attach a blowing nozzle to the exhaust port. Turn on the vacuum. Use the blowing function to clear dust from keyboards, car vents, or other hard-to-reach areas.

6.5 Inflating/Deflating Function (V10 Mate)

Attach the appropriate inflating or deflating nozzle to the designated port. Turn on the vacuum. Use for inflating air mattresses, swimming rings, or deflating storage bags.

4 IN 1 FOR VARIOUS SCENARIOS



Car Detailing



Keyboards



Air Pump



Storage Bag

Image: Four panels illustrating the 4-in-1 functionality: car detailing, cleaning keyboards, inflating an air pump, and deflating a storage bag.

7. Maintenance

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

7.1 Emptying the Dustbin

1. Ensure the vacuum is turned off.
2. Locate the dustbin release button or twist mechanism.
3. Remove the dustbin from the main body.
4. Empty the contents into a trash receptacle.

7.2 Cleaning the Filter

1. After emptying the dustbin, carefully remove the filter.
2. Tap the filter gently over a trash can to dislodge dust.
3. If necessary, rinse the filter under running water. Ensure it is completely dry before reinserting it into the vacuum.
4. Reassemble the filter and dustbin, then attach them back to the vacuum.

7.3 General Cleaning

Wipe the exterior of the vacuum with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

8. Troubleshooting

Problem	Possible Cause	Solution
Vacuum not turning on	Low battery; Power button not pressed correctly	Charge the vacuum; Press and hold the power button for 1 second
Weak suction	Full dustbin; Clogged filter; Blocked nozzle/hose	Empty dustbin; Clean/replace filter; Clear any blockages
Short operating time	Battery not fully charged; Battery degradation	Ensure full charge; Contact customer support if battery life significantly reduced
Charging indicator not working	Faulty charging cable/adapter; Charging port issue	Try a different USB cable/adapter; Contact customer support

9. Specifications

Feature	Fanttik Slim V9 Mix	Fanttik Slim V10 Mate
Suction Power	Up to 30AW / 12kPa	Up to 40AW / 17kPa
Functions	Vacuum, Blow	Vacuum, Blow, Inflate, Deflate
Display	LED Display (Battery, Suction Mode)	LED Ring (Battery, Suction Mode)
Battery Life (Approx.)	13-30 minutes (Max/Eco Mode)	15-35 minutes (High/Low Speed Mode)
Charging Port	USB-C	USB-C

30AW/12kPa POWERFUL SUCTION



V9 MIX

Suction level:

2 Times

Compared to Brushed Motors

Weight:

45%

Compared to Brushed Motors

Air watt:

1.5 Times

Compared to Brushed Motors

Motor life:

10 Times

Compared to Brushed Motors

Rotation speed:

3.5 Times

Compared to Brushed Motors

Image: Diagram illustrating the 30AW/12kPa powerful suction of the V9 Mix, highlighting its internal components and comparing its performance metrics (weight, motor life, suction level, air watt, rotation speed) to brushed motors.

40AW/17000PA SUCTION POWER



Image: Two panels demonstrating the 40AW/17000Pa suction power of the V10 Mate. The top panel shows it cleaning debris from a sofa in Low Speed Mode (8000Pa/15AW), and the bottom panel shows it cleaning a car trunk in High Speed Mode (17000Pa/40AW).

10. Warranty and Support


Fanttik products come with a standard manufacturer's warranty. Please refer to the warranty card included in your package or visit the official Fanttik website for detailed warranty terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact Fanttik Customer Service:

- **Website:** www.fanttik.com
- **Email:** support@fanttik.com (Example email, please verify official contact)

When contacting support, please have your product model and purchase information ready.

Related Documents - Slim V9 Mix, Slim V10 Mate

	<p>Fanttik Slim V10 Mate/Apex Cordless Handheld Vacuum Cleaner User Manual</p> <p>User manual for the Fanttik Slim V10 Mate and Slim V10 Apex cordless handheld vacuum cleaners, including assembly, usage, cleaning, maintenance, troubleshooting, and specifications.</p>
	<p>Fanttik Slim V10 Mate/APEX Cordless Handheld Vacuum Cleaner User Manual</p> <p>User manual for the Fanttik Slim V10 Mate and Slim V10 APEX cordless handheld vacuum cleaners, detailing features, operation, maintenance, troubleshooting, and specifications. Includes safety instructions and warranty information.</p>
	<p>Fanttik V10 Mate/Fold V10 APEX Cordless Handheld Vacuum Cleaner User Manual</p> <p>Official user manual for the Fanttik V10 Mate and Fold V10 APEX cordless handheld vacuum cleaners. Learn about features, operation, safety, and maintenance for your Fanttik vacuum.</p>
<p>材质：105g铜版纸 尺寸：200 x 140 mm 印刷：单黑 装订：骑马钉 注：封面底背面不印刷</p> 	<p>Fanttik V10 Mate & V10 APEX Cordless Handheld Vacuum Cleaner User Manual</p> <p>Comprehensive user manual for the Fanttik V10 Mate and V10 APEX cordless handheld vacuum cleaners, covering safety instructions, product overview, usage, maintenance, troubleshooting, specifications, and warranty information.</p>
	<p>Fanttik Slim V9 Mix Cordless Handheld Vacuum Cleaner User Manual</p> <p>Official user manual for the Fanttik Slim V9 Mix cordless handheld vacuum cleaner. Includes setup, operation, maintenance, safety instructions, and specifications.</p>
	<p>Fanttik Slim V10 Lite Cordless Handheld Vacuum Cleaner User Manual</p> <p>User manual for the Fanttik Slim V10 Lite, a cordless handheld vacuum cleaner. Includes safety instructions, product overview, how to use, cleaning, maintenance, troubleshooting, and specifications.</p>