

[Manuals.plus](#) /

› [BoxWave](#) /

› BoxWave SlimKeys Bluetooth Keyboard with Backlight User Manual for Boox Palma E-Ink Tablet

BoxWave SlimKeys Bluetooth Keyboard

BoxWave SlimKeys Bluetooth Keyboard with Backlight User Manual

Model: SlimKeys Bluetooth Keyboard

INTRODUCTION

This manual provides instructions for the BoxWave SlimKeys Bluetooth Keyboard with Backlight. This device is designed to enhance your typing experience with its portable design, multi-platform compatibility, and customizable backlit keys. Please read this manual thoroughly before using the product to ensure proper operation and maintenance.



Image: The BoxWave SlimKeys Bluetooth Keyboard shown alongside a Boox Palma E-Ink Tablet, illustrating its intended use.

PRODUCT FEATURES

- **Backlit Keys:** Integrated LED backlight with seven customizable colors for typing in various lighting conditions.
- **Bluetooth 3.0 Connectivity:** Provides a stable and responsive wireless connection.
- **Multi-Platform Compatibility:** Works with Android, Windows, and iOS devices.
- **Chiclet Keys:** Low-profile keys designed for quiet and comfortable typing.
- **Slim and Portable Design:** Lightweight and compact for easy storage and transport.
- **Battery-Saving Power Switch:** Dedicated on/off switch to conserve battery life.
- **Specialized Function Keys:** Dedicated keys for common tasks like Home, Search, Copy, Paste, Volume, and Brightness control.



Image: A user typing on the SlimKeys keyboard, highlighting its comfortable design and multi-platform support for Android, Apple, and Windows devices.

SETUP

1. Charging the Keyboard

Before initial use, fully charge the keyboard. Connect the included charging cable to the keyboard's charging port and to a USB power source. The 'Charge' indicator light will illuminate during charging and turn off when fully charged.



Image: The SlimKeys keyboard connected to a charging cable, demonstrating the charging process and highlighting its long-lasting battery.

2. Pairing via Bluetooth

1. Ensure the keyboard is fully charged.
2. Slide the **ON/OFF** switch on the keyboard to the **ON** position. The 'Power' indicator light will turn on.
3. Press the **Connect** button. The 'Connect' indicator light will begin to flash, indicating the keyboard is in pairing mode.
4. On your Boox Palma E-Ink Tablet (or other compatible device), navigate to the Bluetooth settings.
5. Enable Bluetooth and search for available devices.
6. Select "BoxWave SlimKeys Keyboard" from the list of found devices.
7. Follow any on-screen prompts to complete the pairing process. Once paired, the 'Connect' indicator light will stop flashing.

OPERATING INSTRUCTIONS

Power On/Off

- To turn on the keyboard, slide the **ON/OFF** switch to **ON**.
- To turn off the keyboard, slide the **ON/OFF** switch to **OFF**. This conserves battery life.

Backlight Control

- Press the **Light Bulb** key (usually near the bottom right) to turn the backlight on or off.

- Press the **RGB Circle** key (next to the Light Bulb key) to cycle through the seven available backlight colors.

7 Backlight Colors

Express your style and brighten up your setup with SlimKeys



Image: The SlimKeys keyboard showcasing its seven customizable backlight colors, allowing users to personalize their typing experience.

Function Keys

The keyboard features specialized function keys (F1-F12) that provide quick access to various commands. These keys often require pressing the **Fn** key simultaneously with the desired function key, depending on your device's operating system.

Specialized Function Key Overview

Key	Function
Fn + Esc (Home)	Go to Home screen
Fn + F1 (Search)	Open search function
Fn + F2 (Select All)	Select all text/items

Key	Function
Fn + F3 (Copy)	Copy selected content
Fn + F4 (Paste)	Paste content
Fn + F5 (Cut)	Cut selected content
Fn + F6 (Skip Back)	Skip to previous track/item
Fn + F7 (Play/Pause)	Play or pause media
Fn + F8 (Skip Forward)	Skip to next track/item
Fn + F9 (Volume Down)	Decrease volume
Fn + F10 (Volume Up)	Increase volume
Fn + F11 (Brightness Down)	Decrease screen brightness
Fn + F12 (Brightness Up)	Increase screen brightness
Fn + Delete (Lock)	Lock the device screen



Specialized Function Keys



Image: A visual representation of the specialized function keys available on the SlimKeys keyboard, detailing their respective actions.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the keyboard surface. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use for extended periods, turn off the keyboard to conserve battery. Store in a cool, dry place.
- **Battery Care:** To prolong battery life, avoid fully discharging the keyboard frequently. Recharge when the battery indicator is low.

TROUBLESHOOTING

Keyboard not pairing:

- Ensure the keyboard is fully charged and turned on.
- Make sure Bluetooth is enabled on your device.
- Press the 'Connect' button on the keyboard to enter pairing mode.

- If previously paired, try "forgetting" the device on your tablet's Bluetooth settings and re-pairing.
- Ensure the keyboard is within the effective range (typically 10 meters) of your device.

Keys not responding:

- Check if the keyboard is turned on and properly paired.
- Recharge the keyboard if the battery is low.
- Restart both the keyboard (turn off and on) and your connected device.

Backlight not working:

- Press the 'Light Bulb' key to toggle the backlight.
- Ensure the keyboard has sufficient battery charge.

SPECIFICATIONS

Feature	Detail
Model	SlimKeys Bluetooth Keyboard
Connectivity	Bluetooth 3.0
Compatibility	Android, Windows, iOS (Boox Palma E-Ink Tablet compatible)
Backlight	7 LED colors
Dimensions	Approximately 9.5 in (Width) x 5.75 in (Depth) x 0.2 in (Height) / 23.2 cm x 14.6 cm x 0.5 cm
Weight	8.6 ounces (approx. 0.24 kg)
Battery Life	Up to 30 days (usage), 6 months (standby when powered off)
Color	Jet Black



Image: The SlimKeys keyboard with its ultra-slim and lightweight design highlighted, including approximate dimensions for width, depth, and height.

WARRANTY AND SUPPORT

This product includes limited 3rd party technical support for your device (up to 3 inquiries via messaging). This support is not affiliated with or endorsed by Boox. For further assistance or warranty inquiries, please contact BoxWave customer support through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question