Aoxun B0DZ5JDVG5

Aoxun 12' x 16' Outdoor Wood Gazebo Instruction Manual

Model: B0DZ5JDVG5

1. Important Safety Information

Read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always follow the assembly instructions carefully.
- Ensure the gazebo is securely anchored to the ground to withstand wind and other weather conditions.
- Do not assemble or use the gazebo in high winds or during severe weather.
- Keep children and pets away from the assembly area during installation.

WARNING: This product is heavy and requires multiple people for safe assembly.

2. Product Overview

The Aoxun 12' x 16' Outdoor Wood Gazebo is designed to provide a durable and elegant outdoor living space. It features a robust cedar wood frame and a galvanized steel double roof for enhanced stability and weather protection.



Image: The Aoxun 12' x 16' Outdoor Wood Gazebo, showcasing its design and size in an outdoor patio environment.

Key Features:

- **Widened Cedar Wood Frame:** Features 4.7"x4.7" columns for superior strength and stability.
- **Dual Roof Design:** Galvanized steel double roof promotes airflow and provides efficient rain and snow runoff.
- **All-Weather Suitability:** Designed to withstand up to 15 inches of snow loading and wind resistance up to 73 mph when properly anchored with expansion bolts.
- **Versatile Ceiling Hooks:** Includes hooks capable of holding up to 44 lbs for hanging fans, lights, or heaters.
- **UV Protection:** The roof material offers protection against ultraviolet light.




Image: A visual comparison highlighting the wider 4.7"x4.7" cedar wood columns of the Aoxun gazebo compared to smaller columns from other brands.



Image: A detailed view of the hardtop double roof, illustrating its design for air ventilation and waterproof capabilities.

3. Setup and Assembly

Assembly of the Aoxun Gazebo requires careful attention to detail and multiple individuals. It is recommended to have at least 2-3 people for efficient and safe installation.

3.1 Before You Begin:

- **Read Instructions:** Thoroughly review the entire instruction manual and diagrams before starting.
- **Check Parts:** Verify all parts are present and undamaged. A spare parts package is included.
- **Gather Tools:** Essential tools include a screwdriver and a nut bit. Having the proper tools will significantly streamline the assembly process.
- **Clear Area:** Ensure a clear, level, and safe assembly area.
- **Delivery:** The gazebo typically arrives in 6 separate boxes, which may be delivered on different days. Confirm receipt of all packages before starting assembly.




Image: An illustration depicting the delivery process, indicating that the gazebo components are shipped in 6 separate boxes.

3.2 Assembly Process:

- Follow the step-by-step pictorial instructions provided with your product. All holes are pre-drilled and aligned, requiring no additional drilling.
- For certain phases, such as raising the main frame, assistance from 2-3 people is crucial for safety and ease of installation.
- Typical assembly time for two people is approximately 8 hours.

3.3 Anchoring the Gazebo:

Proper anchoring is essential for the stability and safety of your gazebo, especially in varying weather conditions.

- **On the Ground (No Anchoring):** Provides wind resistance up to 35-40 MPH.
- **With Anchoring Stakes (Not Included):** Increases wind resistance to 40-60 MPH.
- **With Expansion Bolts (Included):** Provides maximum wind resistance of 64-73 MPH. It is highly recommended to use the included expansion bolts for permanent installation and enhanced stability.




Image: A diagram illustrating three different installation methods for the gazebo's posts and their corresponding wind resistance ratings.

4. Operating and Usage

Your Aoxun Gazebo is designed for versatile outdoor use, accommodating various activities and weather conditions.

4.1 General Use:

- The spacious 12' x 16' area can comfortably accommodate multiple people for gatherings, dining, or relaxation.
- Utilize the integrated ceiling hooks for hanging outdoor fans, decorative lights, or heaters (ensure weight does not exceed 44 lbs).



Image: A close-up view of the gazebo's ceiling, showing the hooks designed for hanging fans, decorations, and lights.

4.2 Weather Considerations:

- **Sun Protection:** The roof provides UV protection, making it suitable for sunny conditions.
- **Rain Protection:** The sloped roof and galvanized steel construction ensure efficient water runoff, keeping the area dry.
- **Snow Load:** The roof is designed to hold up to 15 inches of thick snow. However, it is advisable to clear heavy snow accumulation to prevent structural stress.
- **Wind Resistance:** With proper anchoring, the gazebo can withstand significant wind speeds. Refer to the anchoring section for details.




Image: The gazebo depicted in both snowy winter and sunny summer settings, highlighting its all-weather suitability.

Your browser does not support the video tag.

Video: An official product video from Aoxun Direct showcasing the features and all-weather capabilities of the outdoor wood gazebo, including its robust frame, double roof design, and anchoring options.

5. Maintenance

Regular maintenance will help preserve the appearance and longevity of your Aoxun Gazebo.

- **Cleaning:** Periodically clean the wood frame and metal roof with a mild soap and water solution. Rinse thoroughly with clean water. Avoid harsh chemicals or abrasive cleaners.
- **Fasteners:** Annually inspect all bolts, screws, and connections to ensure they are tight. Re-tighten as necessary.
- **Wood Care:** While cedar wood is naturally resistant to rot and insects, applying a wood sealant or stain every few years can help maintain its appearance and further protect it from the elements.
- **Snow Removal:** Although the roof is designed for snow load, it is recommended to remove excessive snow accumulation to prolong the life of the structure.
- **Drainage System:** Ensure the roof's slope drainage system remains clear of debris (leaves, branches) to allow for efficient water runoff.

6. Troubleshooting

This section addresses common issues you might encounter with your gazebo.

6.1 Missing or Damaged Parts:

If you discover any missing or damaged parts upon delivery or during assembly, contact Aoxun customer support immediately. Provide your purchase details and a description of the issue for prompt assistance.

6.2 Instability or Wobbling:

- Ensure all fasteners are securely tightened.
- Verify that the gazebo is installed on a level surface.
- Confirm that the gazebo is properly anchored to the ground using the recommended expansion bolts.

6.3 Roof Leaks or Poor Drainage:

- Check for any gaps or loose panels on the roof. Ensure all roof panels are correctly installed and sealed.
- Clear any debris (leaves, dirt) from the roof and drainage channels to ensure proper water flow.

7. Specifications

Feature	Specification
Brand	Aoxun
Model Number	B0DZ5JDVG5
Product Dimensions (L x W x H)	193"L x 146"W x 120"H (16'L x 12'W x 10'H)

Item Weight	573.98 Pounds
Frame Material	Cedar Wood (4.7"x4.7" columns)
Roof Material	Galvanized Steel Double Roof
Color	Gray
Water Resistance Level	Waterproof
Ultraviolet Light Protection	Yes
Snow Loading Depth	Up to 15 inches
Wind Resistance (with expansion bolts)	Up to 73 MPH (Level 9)
Assembly Required	Yes
Ceiling Hook Capacity	Up to 44 lbs

8. Warranty and Support

For warranty information and customer support, please contact Aoxun Direct, the seller of this product. It is recommended to retain your proof of purchase for any warranty claims.

If you encounter any issues or require assistance, please reach out to the seller directly through your purchase platform or their official contact channels. They can provide specific details regarding product warranty, replacement parts, and technical support.

© 2026 Aoxun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question