

CINMOORE CINMOORE 3K Indoor Security Camera

CINMOORE 3K Smart Security Camera Indoor User Manual

Model: CINMOORE 3K Indoor Security Camera

Brand: CINMOORE

INTRODUCTION


This user manual provides comprehensive instructions for the setup, operation, and maintenance of your CINMOORE 3K Smart Security Camera Indoor. Designed for versatile indoor monitoring, this camera offers high-resolution video, 360° coverage, advanced AI detection, and two-way audio communication. Please read this manual thoroughly before using the product to ensure proper functionality and safety.

WHAT'S IN THE BOX


Upon opening your CINMOORE 3K Smart Security Camera package, you should find the following components:

- CINMOORE Security Camera × 1
- Mounting Bracket Base × 1
- Power Adapter × 1
- Data Cable × 1
- Screw Anchors × 1
- User Manual × 1
- 64GB SD Card (pre-installed or included separately)


Packaging & Accessories




CINMOORE Security Camera
× 1



User Manual
× 1




Power Adapter
× 1



Mounting Bracket Base
× 1



Screw Anchors
× 1



Data Cable
× 1

Figure 1: Packaging & Accessories. This image displays the CINMOORE Security Camera, User Manual, Power Adapter, Data Cable, Mounting Bracket Base, and Screw Anchors.

SETUP

1. Physical Installation

The CINMOORE 3K Smart Security Camera is designed for indoor use and can be placed on a flat surface or mounted to a wall or ceiling. The included mounting bracket and screws facilitate secure installation.

1. **Choose a Location:** Select an indoor location that provides the desired viewing angle and is within reach of a power outlet. Ensure the camera has a clear line of sight to the area you wish to monitor.
2. **Mounting (Optional):**
 - Attach the mounting bracket base to your desired surface (wall or ceiling) using the provided screws and anchors.
 - Align the camera's base with the mounting bracket and twist to lock it into place.

3. **Power Connection:** Connect the provided data cable to the camera's USB-C port and the power adapter. Plug the power adapter into a standard electrical outlet. The camera will power on automatically.



Figure 2: The CINMOORE 3K Smart Security Camera, shown with a smartphone displaying its live feed and an included 64GB SD card, ready for setup.

2. App Installation & Device Pairing

To control and monitor your camera, you need to install the CINMOORE app on your smartphone or tablet.

1. **Download the App:** Search for "CINMOORE" in your device's app store (Google Play Store for Android or Apple App Store for iOS) and download the official app.
2. **Create an Account:** Open the app and follow the on-screen instructions to register a new account or log in if you already have one.
3. **Add Device:**

- Tap the "+" icon in the app to add a new device.
- Select your camera model from the list.
- Follow the app's prompts to connect the camera to your Wi-Fi network. Ensure your Wi-Fi is 2.4GHz or 5GHz compatible.
- The app will guide you to reset the device by pressing and holding the reset button for 5 seconds until you hear a prompt. Then, short press the reset button twice until you hear "Reset successful".
- Scan the QR code displayed in the app with the camera's lens. Hold the QR code approximately 4-8 inches (10-20 cm) away from the camera until you hear a confirmation sound.
- Once connected, you can name your camera (e.g., "Living Room," "Bedroom," "Office").

OPERATING THE CAMERA

1. Live View and Pan-Tilt Control

Access the live feed of your camera through the CINMOORE app. You can remotely control the camera's viewing angle.

- **Pan-Tilt Function:** Use the directional controls within the app to rotate the camera 360° horizontally and tilt it 110° vertically, eliminating blind spots.
- **Two-Way Audio:** Utilize the built-in microphone and speaker for real-time communication with individuals or pets in the camera's vicinity.
- **Privacy Mode:** Activate privacy mode through the app to physically conceal the camera lens, ensuring your privacy when needed.

360° Horizontal & 110° Vertical Visibility.

Also comes with privacy protection



Figure 3: The camera's 360° horizontal and 110° vertical visibility, providing comprehensive room coverage.

2. Recording and Storage

The camera supports local storage via a microSD card (up to 512GB, 64GB included) and optional cloud storage.

- **AOR Recording Technology:** This feature optimizes storage, allowing for up to 60% longer recording time on your SD card compared to traditional methods, by intelligently recording only relevant events.
- **Continuous Recording:** The camera can record 24/7 to the SD card.
- **Cloud Storage:** An optional cloud storage service is available for secure off-site backup of your recordings. Refer to the app for subscription details.

Figure 4: The camera includes a 64GB SD card for local storage, eliminating the need for monthly fees.

3. Smart AI Detection and Alerts

The camera features advanced AI capabilities to enhance monitoring and reduce false alarms.

- **Human/Pet/Face Detection:** The AI motion detection accurately identifies humans, pets, and faces, ensuring you receive relevant alerts.

- **Motion Tracking:** The camera can automatically track detected movement within its field of view.
- **Instant Alerts:** Receive real-time notifications on your smartphone when activity is detected.



Figure 5: Motion detection and human shape recognition capabilities, highlighting the camera's ability to identify and track subjects.

4. One-Touch Calls

The camera is equipped with a dedicated button for one-touch calls, allowing users in the camera's location to initiate a call to the connected app.

One-Touch Calls

Perfect for children or elder people who may need to get in touch with you quickly



Figure 6: The one-touch call feature, ideal for quick communication with family members or caregivers.

5. Night Vision

The camera provides clear monitoring even in low-light conditions with its infrared night vision and color night vision capabilities.

- **Infrared Night Vision:** Automatically switches to black and white mode in darkness for clear visibility up to 33 feet.
- **Color Night Vision:** Utilizes advanced technology to provide full-color video in low-light environments, offering more detail than traditional infrared.

Crystal Clear, Day or Night




Figure 7: Visual comparison demonstrating the camera's crystal-clear image quality during both day and night.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Avoid using harsh chemicals or abrasive materials that could damage the surface.
- **SD Card Management:** Regularly check the SD card storage status via the app. If the card is full, older recordings will be overwritten. Back up important footage to cloud storage or another device before it is deleted.
- **Firmware Updates:** Keep your camera's firmware updated to ensure optimal performance and access to new features. The app will notify you of available updates.

TROUBLESHOOTING

Problem	Possible Cause / Solution
---------	---------------------------

Problem	Possible Cause / Solution
Camera not connecting to Wi-Fi.	Ensure your Wi-Fi network is 2.4GHz or 5GHz. Check Wi-Fi password accuracy. Move the camera closer to the router. Reset the camera (see Setup section for instructions).
Poor video quality.	Check your internet connection speed. Ensure the camera lens is clean and free from obstructions. Adjust camera placement for optimal lighting.
No SD card capabilities / SD card not detected.	The CINMOORE 3K Smart Security Camera does include a 64GB SD card and has an SD card slot. Ensure the SD card is correctly inserted into the slot. Try re-inserting the SD card or using a different compatible microSD card (up to 512GB). Format the SD card through the app settings. If the issue persists, contact customer support.
Motion alerts are too frequent or not received.	Adjust motion detection sensitivity in the app settings. Configure detection zones to focus on specific areas. Ensure app notifications are enabled on your phone.

SPECIFICATIONS

Feature	Detail
Brand	CINMOORE
Model Name	CINMOORE 3K Security Camera Indoor
Indoor/Outdoor Usage	Indoor
Power Source	Corded Electric
Connectivity Technology	Wireless (Wi-Fi, Bluetooth)
Controller Type	App, Push Button
Mounting Type	Wall Mount, Freestanding
Video Capture Resolution	1920p (3K Ultra HD)
Color	White
Number of Items	1

Feature	Detail
Included Components	CINMOORE Security Camera × 1, Mounting Bracket Base × 1, Power Adapter × 1, Data Cable × 1, Screw Anchors × 1, User Manual × 1
Form Factor	Dome
Viewing Angle	360 Degrees (Pan-Tilt)
Night Vision Range	33 Feet
Material	Acrylonitrile Butadiene Styrene (ABS)
Water Resistance Level	Water Resistant (Note: For indoor use only)
Batteries Required?	No
Focus Type	Auto Focus
Low light technology	Night Color
Alert Type	Audio and Motion
Video Capture Format	MP4
Specific Uses For Product	Baby Monitoring, Elderly Care, Home Security Monitoring, Office Surveillance, Pet Monitoring
Effective Still Resolution	5 MP
Date First Available	March 4, 2025
Manufacturer	CINMOORE US

WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included in your product packaging or visit the official CINMOORE website. For technical support, troubleshooting assistance, or any product-related inquiries, please contact CINMOORE customer service through the contact information provided on their official website or within the CINMOORE app.

You can also find additional resources and FAQs on the CINMOORE support page.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can I share my CINMOORE 3K Indoor Security Camera account with two more people in my household?

Yes, you can share access to your CINMOORE 3K Indoor Security Camera with other members of your household. While the manual does not explicitly detail the step-by-step "Sharing" menu, most smart cameras using the...

[Read full answer](#)