

[Manuals.plus](#) /

› [CiBest](#) /

› CiBest Google TV Projector 4K Support User Manual

CiBest B0DZ69CXJ2

CiBest Google TV Projector 4K Support User Manual

Model: B0DZ69CXJ2

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your CiBest Google TV Projector. Designed for versatile use, this projector features 4K support, a native 1080p resolution, 1000 ANSI lumens brightness, HDR10+ technology, and a 20,000:1 contrast ratio. It comes with an officially licensed Google TV system, offering access to numerous streaming applications and smart functionalities.




Image: The CiBest Google TV Projector, a compact and modern device.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- CiBest Google TV Projector
- Remote Control

- HDMI Cable
- AV Cable (3-in-1)
- Power Cord
- User Manual (Quick Start Guide)
- Carrying Case (Fabric)

3. SETUP

3.1 Initial Placement

Place the projector on a stable, flat surface or mount it using the M6 mounting hole at the bottom. Ensure there is adequate space around the projector for ventilation.

3.2 Power Connection

1. Connect the power cord to the projector's power input.
2. Plug the other end of the power cord into a suitable electrical outlet.

3.3 Android TV Box Installation

The projector includes a built-in Android TV box. To ensure proper function:

1. Locate the compartment on the side of the projector.
2. Open the cover and connect the micro HDMI and micro USB cables from the projector to the Android TV box.
3. Securely place the Android TV box inside the compartment and close the cover.

4K Support

Turning your space into a world of breathtaking visuals and sound.



3000
ANSI

HDR10+
HDR+ technology

20000:1
Contrast ratio



AI Image Optimization

NTSC

98% Color Gamut



Image: A close-up view of the projector's side compartment with the Android TV box connected.

3.4 First-Time Power On and Language Selection

1. Press the power button on the projector or remote control to turn it on.
2. Follow the on-screen prompts to select your preferred OSD (On-Screen Display) language.
3. Connect to your Wi-Fi network as instructed.

3.5 Focus and Keystone Adjustment

The projector features automatic focus and keystone correction. For manual adjustments:

- **Autofocus:** The projector will automatically adjust focus when moved. You can also press the dedicated focus button on the remote for a quick adjustment.
- **Manual Focus:** Use the left/right buttons on the remote when the focus prompt is active for fine-tuning.
- **Keystone Correction:** Use the manual keystone knob on the projector to correct image distortion if the projector is not perfectly perpendicular to the screen.



Image: Visual representation of the flexible image adjustment options, including 50%-100% zoom and $\pm 15^\circ$ keystone correction.

4. OPERATING INSTRUCTIONS

4.1 Google TV Interface

The projector comes with an officially licensed Google TV system, providing a smart and intuitive interface for accessing content.

- **Streaming Apps:** Access popular apps like Netflix, Prime Video, YouTube, Disney+, Hulu, Max, ESPN, and more directly from the home screen.
- **Google Voice Assistant:** Use the built-in Google Voice Assistant via the remote control for hands-free operation, app launching, content search, and volume adjustment.
- **Google Cast & AirPlay:** Supports screen mirroring from Google phones and AirPlay for easy interaction with various smart devices.




Image: The Google TV home screen displaying various streaming apps and the Google Assistant voice command interface.



Image: A visual demonstrating the vast library of supported applications and free channels available through the Google TV system.

4.2 Connecting External Devices

The projector offers multiple connectivity options:

- **HDMI:** Connect devices like laptops, gaming consoles (PS5, Switch), or Blu-ray players using an HDMI cable. The projector supports HDMI ARC.
- **USB:** Plug in USB drives for media playback.

- **3.5mm Audio:** Connect external audio systems or headphones.
- **AV:** Use the included 3-in-1 AV cable for older devices.
- **Bluetooth 5.2:** Connect Bluetooth speakers, headphones, or game controllers wirelessly.
- **WiFi 6:** Ensures fast and stable wireless internet connection for streaming.



Image: An illustration highlighting the various input and wireless connectivity options available on the projector.

4.3 Remote Control

The included remote control provides full functionality for navigating the Google TV interface and adjusting projector settings. It features dedicated buttons for popular streaming services and voice commands.

5. MAINTENANCE

5.1 Dust-Free Optical Engine

The projector features a fully-sealed optical engine designed to prevent dust from entering and affecting image quality. This design extends the projector's lifespan and reduces the need for frequent lens cleaning.



Image: An internal view illustrating the fully sealed optical engine, designed to protect against dust.

5.2 Cooling System

The integrated cooling system ensures optimal operating temperature and contributes to low operating noise. Keep the ventilation vents clear of obstructions to maintain efficient cooling.

5.3 Lamp Life

The projector lamp is designed for a long lifespan of up to 100,000 hours under normal usage conditions.



Image: The projector highlighting its impressive 100,000-hour lamp life.

5.4 Cleaning

- Use a soft, dry cloth to clean the exterior of the projector.
- For the lens, use a lens cleaning cloth and specialized lens cleaning solution. Avoid abrasive materials.

6. TROUBLESHOOTING

If you encounter issues with your projector, refer to the following common solutions:

- **No Power:** Ensure the power cord is securely connected to both the projector and the power outlet.
- **No Image:** Check all cable connections (HDMI, AV). Verify the input source is correctly selected on the projector.
- **Blurry Image:** Adjust the focus using the autofocus feature or manual fine-tuning. Ensure the projection surface is flat.
- **Distorted Image (Trapezoid Shape):** Use the keystone correction feature to square the image.
- **No Sound:** Check the volume settings on the projector and any connected audio devices. Ensure external speakers are properly connected via Bluetooth or 3.5mm audio jack.
- **Wi-Fi/Bluetooth Connectivity Issues:** Restart the projector and your router. Ensure the projector is within range of your Wi-Fi network.
- **App Not Working:** Ensure the app is updated to the latest version. Check your internet connection.

For further assistance, please contact customer support.

7. SPECIFICATIONS

Feature	Specification
Brand	CiBest
Model	B0DZ69CXJ2
Display Resolution	1920 x 1080 (Native), 4K Support
Brightness	1000 ANSI Lumens
Contrast Ratio	20,000:1
Special Feature	Built-in Speakers, Autofocus, Keystone Correction, Google TV, Google Assistant, HDR10+
Connectivity Technology	Google TV, HDMI (ARC), USB, 3-in-1 AV, 3.5mm Audio, WiFi 6, Bluetooth 5.2
Recommended Uses	Indoor/Outdoor Home Theater
Item Weight	8.49 pounds
Product Dimensions	6 x 12 x 16.8 inches
Optical Engine	Fully-Sealed
Lamp Life	Up to 100,000 hours

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included in your product packaging or visit the official CiBest website. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question