**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## DUMOS DUMOS-TV5BC

# DUMOS TV Stand Dresser Instruction Manual

**Model: DUMOS-TV5BC**

**Brand: DUMOS**

## Product Overview

The DUMOS TV Stand Dresser is a versatile furniture unit designed for organizing and displaying media equipment and various household items. It features a sturdy metal frame, wooden board shelves, and five removable fabric storage drawers. This unit is suitable for use in living rooms, bedrooms, dorms, or hallways, accommodating TVs up to 45 inches.



**Figure 1:** Assembled DUMOS TV Stand Dresser with a television and open storage drawer.

## Safety Information

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result

in injury or damage to the product.

- **Anti-Tilt Device:** It is highly recommended to secure the TV stand dresser to a wall using the provided anti-tilt device. This prevents accidental tipping, especially in households with children or pets.
- **Weight Limits:** Do not exceed the specified weight capacities for the top shelf, open shelf, or individual drawers. Overloading can compromise the unit's stability and structural integrity.
- **Assembly:** Ensure all screws and fasteners are securely tightened during assembly. Periodically check all connections to ensure they remain tight.
- **Placement:** Place the unit on a flat, level, and stable surface to prevent wobbling or tipping.
- **Children and Pets:** Keep small parts and packaging materials away from children and pets during assembly. Do not allow children to climb on or play with the unit.




**Figure 2:** Details of the sturdy structure, including the anti-tilt device.

## Package Contents

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or

damaged, please contact customer support.

| Part | Description | Quantity |
|---|---|---|
| Metal Frame Components | Vertical and horizontal metal bars for the main structure. | Various |
| Wooden Boards | Top shelf and middle open shelf. | 2 |
| Fabric Drawers | Collapsible fabric drawers with handles. | 5 |
| Adjustable Feet | Leveling feet for stability on uneven surfaces. | 4 |
| Anti-Tilt Device | Wall anchor strap and hardware. | 1 Set |
| Assembly Hardware | Screws, bolts, and Allen wrench. | Various |

## Assembly Instructions

Assembly of the DUMOS TV Stand Dresser is designed to be straightforward and typically takes approximately 20 minutes. All necessary tools and accessories are included. For detailed visual guidance, refer to the installation video provided by DUMOS.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Refer to the "Package Contents" section to identify each part.
2. **Assemble the Metal Frame:** Connect the vertical and horizontal metal frame components according to the numbered labels. Secure them using the provided screws and the Allen wrench. Ensure all connections are firm.
3. **Attach Adjustable Feet:** Screw the four adjustable feet into the bottom of the metal frame. These can be adjusted later to level the unit.
4. **Install Wooden Boards:** Place the top wooden board onto the designated frame supports. Insert the middle wooden board into its respective position, forming the open shelf.
5. **Prepare Fabric Drawers:** Unfold each fabric drawer and insert the bottom support panel to give it shape.
6. **Insert Drawers:** Slide the prepared fabric drawers into their respective compartments within the metal frame. The unit includes three smaller drawers for the top row and two larger drawers for the bottom row.
7. **Install Anti-Tilt Device:** Attach the anti-tilt device to the back of the unit and secure it to a wall stud using the provided hardware. This step is crucial for safety.

If you encounter any difficulties during assembly, please refer to the official DUMOS installation video or contact customer support for assistance.

## Operating Instructions

The DUMOS TV Stand Dresser is designed for versatile use and organization.

- **TV Placement:** The top surface is designed to hold a television up to 45 inches. Ensure the TV's base fits securely within the dimensions of the top shelf and does not exceed the maximum weight capacity.
- **Open Shelf Usage:** The middle open shelf provides space for media devices such as gaming consoles, DVD players, soundbars, or decorative items. Ensure proper ventilation for electronic devices.
- **Fabric Storage Drawers:** Utilize the five fabric drawers for organized storage of various items. These drawers are ideal for clothing, toys, diapers, snacks, groceries, or other household essentials. The drawers are removable for easy access and portability.
- **Adjustable Feet:** If the unit appears wobbly, gently adjust the leveling feet at the bottom until the unit is stable on

your floor surface.




**Figure 3:** Illustration of spacious storage and drawer capacity.

## Maintenance

Regular maintenance will help prolong the life and appearance of your DUMOS TV Stand Dresser.

- **Cleaning Fabric Drawers:** The fabric drawers are designed to be waterproof and easy to clean. For minor spills or dust, wipe with a damp cloth and mild detergent. Allow to air dry completely. Do not machine wash or tumble dry.
- **Cleaning Metal Frame and Wooden Boards:** Wipe the metal frame and wooden surfaces with a soft, dry, or slightly damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Periodic Checks:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten if necessary. Check the adjustable feet for proper leveling and the anti-tilt device for secure attachment.





**Figure 4:** Key features including waterproof fabric and adjustable feet.




**Figure 5:** Composition and benefits of the upgraded fabric material.

## Troubleshooting

This section addresses common issues you might encounter with your DUMOS TV Stand Dresser.

| Problem | Possible Cause | Solution |
|---|---|---|
| Unit is wobbly or unstable. | Uneven floor surface; loose connections. | Adjust the leveling feet at the bottom until stable. Check and tighten all assembly screws. Ensure the anti-tilt device is properly installed. |
| Drawers do not slide smoothly or fit properly. | Drawer not fully shaped; overloaded drawer; frame misalignment. | Ensure the bottom support panel is fully inserted into the fabric drawer. Reduce the weight in the drawer. Check the metal frame for proper alignment during assembly. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Scratches or marks on fabric drawers. | General wear and tear; contact with sharp objects. | The fabric is wear-resistant, but minor marks can occur. Clean as per maintenance instructions. Avoid sharp objects. |

If the problem persists after attempting these solutions, please contact DUMOS customer support.

## Specifications

| Feature | Detail |
|---|---|
| Brand | DUMOS |
| Model Name | Dresser for Bedroom Entertainment Center with 5 Fabric Drawers |
| Model Number | DUMOS-TV5BC |
| Product Dimensions (D x W x H) | 11.8" x 39.4" x 31.9" |
| Item Weight | 31.3 pounds |
| Color | Black (5 Fabric Drawers-black) |
| Material | Metal Frame, Wooden Boards (100% Wood), Fabric Drawers (3-layer breathable fabric) |
| Mounting Type | Floor Mount |
| Assembly Required | Yes |
| Max TV Size Supported | Up to 45 inches |
| Top Board Capacity | 66 lbs |
| Drawer Capacity (Large/Small) | 11 lbs / 7 lbs |





**Figure 6:** Detailed size and weight capacity information.

## Warranty Information

Specific warranty details for the DUMOS TV Stand Dresser are not provided in this manual. For information regarding product warranty, please refer to the product packaging, purchase receipt, or contact DUMOS customer support directly.

## Customer Support

For any questions, concerns, or assistance with your DUMOS TV Stand Dresser, please reach out to DUMOS customer support.

- **Online Support:** Visit the official DUMOS Store on Amazon for product information and support resources:DUMOS Store
- **Assembly Video:** An installation video is available to guide you through the assembly process. Please check the product page or DUMOS support channels for access.

© 2023 DUMOS. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0DZ6KTS4N**

More documents and user manuals: **https://manuals.plus/**