



Manuals.plus /

› **BoxWave** /

› BoxWave SlimKeys Bluetooth Keyboard with Trackpad Instruction Manual

BoxWave SlimKeys Bluetooth Keyboard with Trackpad

BoxWave SlimKeys Bluetooth Keyboard with Trackpad Instruction Manual

Model: SlimKeys Bluetooth Keyboard with Trackpad

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your BoxWave SlimKeys Bluetooth Keyboard with Trackpad. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

PRODUCT OVERVIEW

The BoxWave SlimKeys Bluetooth Keyboard with Trackpad is a portable, slim keyboard designed for seamless connectivity with various devices. It features responsive chiclet-style keys and a full-functioning trackpad, enhancing productivity on the go.



Image: Top-down view of the BoxWave SlimKeys Bluetooth Keyboard with Trackpad, showing the full QWERTY layout and integrated trackpad.



SlimKeys

Bluetooth Keyboard with Trackpad



Image: Angled view of the BoxWave SlimKeys Bluetooth Keyboard with Trackpad, highlighting its slim profile.

SETUP

1. Charging the Keyboard

Before initial use, fully charge the keyboard. Connect the included charging cable to the keyboard's charging port and to a USB power source. The charging indicator light will illuminate during charging and turn off when fully charged.



Image: The BoxWave SlimKeys keyboard connected to a charging cable, illustrating the charging process.

2. Powering On/Off

Locate the ON/OFF switch on the side of the keyboard. Slide the switch to the 'ON' position to power on the keyboard. Slide it to 'OFF' when not in use to conserve battery power.

3. Bluetooth Pairing

1. Ensure the keyboard is charged and powered on.
2. Press the **Connect** button on the keyboard. The Bluetooth indicator light will begin to flash, indicating it is in pairing mode.
3. On your device (e.g., HP Spectre X360, Android tablet, iOS device), go to the Bluetooth settings.
4. Search for available devices. You should see "BoxWave SlimKeys Keyboard" or a similar name appear in the list.
5. Select the keyboard from the list to initiate pairing. Follow any on-screen prompts, such as entering a pairing code, if required.
6. Once successfully paired, the Bluetooth indicator light on the keyboard will stop flashing and remain solid or turn off, depending on the model.



Image: A hand using the integrated trackpad on the SlimKeys keyboard, demonstrating navigation capabilities.

4. Multi-Platform Compatibility

The SlimKeys keyboard is compatible with Android, Windows, and iOS devices. It automatically adapts to the operating system for optimal functionality.



Type Comfortably



**SlimKeys connects seamlessly across
Android, Windows & iOS devices**

Image: Hands typing on the SlimKeys keyboard, with icons representing Android, Apple (iOS), and Windows operating systems, indicating multi-platform compatibility.

OPERATING INSTRUCTIONS

1. Basic Keyboard Usage

The keyboard functions like a standard QWERTY keyboard. Simply type as you would on any other keyboard. The chiclet-style keys provide a comfortable and responsive typing experience.

- **F7 / Play/Pause:** Plays or pauses media.
- **F8 / Skip Forward:** Skips to the next track/media.
- **F9 / Volume Down:** Decreases audio volume.
- **F10 / Volume Up:** Increases audio volume.
- **F11 / Brightness Down:** Decreases screen brightness.
- **F12 / Brightness Up:** Increases screen brightness.
- **Delete / Lock:** Deletes characters or locks the device.




Image: A detailed diagram illustrating the specialized function keys and their corresponding actions on the SlimKeys keyboard.

MAINTENANCE

1. Cleaning

To clean the keyboard, gently wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish. Ensure no liquid enters the keyboard's internal components.

2. Battery Care

The keyboard features a long-lasting battery. To maximize battery life:

- Turn off the keyboard using the ON/OFF switch when not in use.
- Recharge the battery when the low battery indicator appears.
- Avoid exposing the keyboard to extreme temperatures.

The keyboard offers up to 30 days of active use and up to 6 months of standby time when powered off.

TROUBLESHOOTING

- **Keyboard not connecting:**

- Ensure the keyboard is powered on and fully charged.
- Make sure Bluetooth is enabled on your device.
- Try re-pairing the keyboard by following the Bluetooth Pairing steps in the Setup section.
- Ensure the keyboard is within the effective Bluetooth range (typically 10 meters or 33 feet).

- **Keys not responding:**

- Check if the keyboard is connected via Bluetooth.
- Restart both the keyboard and your device.
- Ensure the keyboard battery is not critically low.

- **Trackpad not working:**

- Verify the keyboard is properly connected.
- Check your device's settings for any trackpad or mouse-related configurations.
- Clean the trackpad surface to remove any debris.

- **Intermittent connection:**

- Move closer to your device to reduce interference.
- Ensure no other strong wireless signals are interfering with the Bluetooth connection.
- Disconnect and reconnect the Bluetooth connection.

SPECIFICATIONS

Feature	Detail
Brand	BoxWave
Model	SlimKeys Bluetooth Keyboard with Trackpad
Color	Jet Black
Material	Polycarbonate
Item Weight	10.9 ounces
Bluetooth Version	3.0
Dimensions (W x D x H)	9.5 in x 7.0 in x 0.2 in (23.2 cm x 17.8 cm x 0.5 cm)
Battery Life (Active Use)	Up to 30 days
Battery Life (Standby)	Up to 6 months
ASIN	B0DZ7MNDRF
Date First Available	December 3, 2021



Image: A diagram illustrating the width, depth, and height of the SlimKeys keyboard.

WARRANTY AND SUPPORT

Specific warranty information and detailed support contacts are not provided within this manual. For warranty details, technical support, or further assistance, please refer to the official BoxWave website or contact their customer service directly.