

AMINY U9

AMINY U9 AI Translation Earbuds User Manual

Model: U9 | Brand: AMINY

INTRODUCTION

Thank you for choosing the AMINY U9 AI Translation Earbuds. These innovative open-ear headphones are designed to provide seamless real-time language translation, high-fidelity audio, and comfortable wear for various scenarios including travel, business, and daily communication. Please read this manual carefully to ensure optimal performance and longevity of your device.

WHAT'S IN THE Box

- Wireless Earbuds (2)
- Charging Case (1)
- Charging Cable (1)
- User Manual (1)

SPECIFICATIONS

Feature	Detail
Model Name	U9
Brand	AMINY
Ear Placement	Open Ear
Connectivity Technology	Wireless, Bluetooth 5.4
Translation Languages	163 Languages & Accents
Control Type	Touch Control / App Control
Charging Time (Earbuds)	1.5 Hours
Charging Time (Case)	2 Hours
Playtime (Earbuds)	Up to 8 hours

Total Playtime (with Case)	35-48 hours
Bluetooth Range	10 Meters (33 feet)
Water Resistance Level	Water Resistant

SETUP GUIDE

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C charging cable to the charging port on the case and a compatible USB power source. The indicator light on the case will show charging status.

Type-C Rechargeable & High Efficiency Battery

* Low-power chip+ large-capacity lithium battery, long-lasting battery life to easily cope with long-term needs



5-6H
Talk Time

1.5-2H
Charging Time

7-8H
Music Time

Charging-the indicator light is always on.

Fully charged- the indicator light is off.

Image: Diagram showing the Type-C charging port on the earbud case and estimated charging times for talk, music, and full charge.

2. Downloading the Ear Dance App

The AMINY U9 earbuds require the dedicated "Ear Dance" app for full translation functionality. Scan the QR code provided in the included user manual or search for "Ear Dance" in your device's app store (Google Play Store for Android, Apple App Store for iOS).

Download APP & One Step Quick Pairing

Scan the QR code in the User Manual to download the APP, connected immediately when you open the charging case after first pairing.




Image: Visual guide for downloading the Ear Dance app and the one-step quick pairing process, showing compatibility with iOS/Android, Bluetooth, Wi-Fi, and long battery life.

3. Bluetooth Connection and Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your smartphone, go to Bluetooth settings and search for nearby devices.
3. Select "U9" from the list of available devices to connect.

4. Open the "Ear Dance" app. The app should automatically detect and connect to the earbuds.

Your browser does not support the video tag.

Video: An official product video from AMINY Store demonstrating the unboxing, physical features, and basic setup of the earbuds, including opening the case and showing the charging port.

OPERATING MODES

The AMINY U9 earbuds offer multiple modes to facilitate communication and audio enjoyment.

Suitable for Various Occasions



Headphone Mode

Speak to the phone and listen to the translation sound through the headset.

Free Talk Mode

Communicate through earphones, wears a headset to speaks, the earphones automatically recognizes the language and played back through the headset.



Speaker Mode

Press to speak, release to stop recording and play the translation sound through the mobile phone's speaker.

Open-ear Design

Stay connected with your surroundings while you listen to music, and enjoy warm moments with family and friends.



* AI simultaneous interpretation, fast and accurate translation

Image: Diagram illustrating different usage scenarios and modes: Headphone Mode, Free Talk Mode, Speaker Mode, and Open-ear Design benefits.

1. Free Talk Mode (Dual Ear)

- Communicate through both earbuds. The earphones automatically recognize the language spoken and translate it in real-time, enabling direct barrier-free conversation.
- Tap the language switch button in the top-right corner of the app to switch between 163 languages and exchange

languages between both sides.

2. Translation Machine Mode

- Click the speaking button corresponding to the language you speak. The phone will then play the translated content externally through its speaker.
- Click the language switch button at the top to switch among 163 languages.

3. Headphone + Phone Mode

- One person wears the earphones, and the other person holds the mobile phone. This mode is suitable for conversations where one party prefers not to wear an earbud.

4. AI Dialogue Mode

- Chat with the AI assistant. Click the speech button to start.
- Tap the button in the top-right corner to switch between 12 available languages for conversation.

5. Voice Note Mode

- Transcribe voices in real-time. Click the 'Recording' button, select the recording language, and click 'Confirm' to start recording.

6. Photo Translation

- Translate text from images. Enter the recording details page, click the edit button to edit transcription content.

7. Audio and Video Translation Mode

- Select 'My Language' and 'Their Language'. Tap the 'Invite Friend to Call' button and share the 'Invitation Link' with your friend. Your friend opens the 'Invitation Link' to start real-time barrier-free communication.

EARBUD TOUCH CONTROLS

The earbuds feature intuitive touch controls for managing calls and music playback.

Comfortable Wear

Non-In-Ear Design, Ergonomic Fit for All-Day Comfortable Wear



Volume +



Answer call



Volume -



Previous track

Next track



Play/pause



Reject call



Hang up call



Image: Diagram showing the touch sensitive area on the earbud and corresponding functions: Volume +, Volume -, Answer call, Reject call, Play/pause, Next track, Previous track, Hang up call.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap right earbud.
- **Previous Track:** Double tap left earbud.
- **Volume Up:** Triple tap right earbud.

- **Volume Down:** Triple tap left earbud.
- **Answer Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud during an incoming call.
- **Hang Up Call:** Press and hold either earbud during an active call.

CARE AND MAINTENANCE

- Clean the earbuds and charging case regularly with a soft, dry cloth.
- Avoid exposing the device to extreme temperatures, humidity, or corrosive substances.
- Do not attempt to disassemble or repair the earbuds yourself, as this will void the warranty.
- Store the earbuds in their charging case when not in use to protect them and keep them charged.

TROUBLESHOOTING

Earbuds not pairing:

- Ensure both earbuds are charged.
- Turn off and on your device's Bluetooth.
- Forget "U9" from your device's Bluetooth list and try pairing again.
- Restart your phone and the Ear Dance app.

Translation not working:

- Ensure the earbuds are properly connected to the app.
- Check your internet connection (Wi-Fi or mobile data) as real-time translation requires online access.
- Verify that the correct source and target languages are selected in the app.
- Speak clearly and at a moderate pace.

Poor audio quality:

- Ensure the earbuds are clean and free from debris.
- Check the audio settings in the Ear Dance app and your device.
- Move closer to your connected device to avoid signal interference.

WARRANTY AND SUPPORT

AMINY products come with a standard manufacturer's warranty. For detailed warranty information, product support, or service inquiries, please refer to the warranty card included in your package or visit the official AMINY website.

Contact Information: Please refer to the contact details provided on the product packaging or the official AMINY website for customer service.