Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TESSAN TS-709-C

TESSAN TS-709-C Magnetic Power Strip User Manual

Model: TS-709-C

1. Introduction

Thank you for purchasing the TESSAN TS-709-C Magnetic Power Strip. This device is designed to provide convenient and safe power distribution for your electronic devices, featuring multiple AC outlets and USB charging ports. Please read this manual thoroughly before use to ensure proper operation and safety.

2. Product Features

- **Magnetic Design:** Equipped with powerful built-in magnets for secure attachment to metallic surfaces, preventing accidental falls.
- **Versatile Power Outlets:** Features 9 AC outlets, 1 USB-C port (15W Max), and 2 USB-A ports (12W Max) for charging multiple devices simultaneously.
- **Flat Plug:** The ultra-thin 45-degree flat plug design allows for easy placement in narrow spaces, such as behind furniture, without obstructing other outlets.
- **Spaced Outlets:** AC outlets are strategically distributed in three directions to accommodate large adapters without blocking adjacent ports.
- **Safety Features:** Constructed from flame-retardant ABS 94V0 material, includes an insulation cap on the plug base, a centralized power switch, and a built-in overload protection breaker. An indicator light confirms power status.
- **2-Meter Extension Cord:** Provides ample reach for flexible placement.



Image 2.1: Overview of the TESSAN TS-709-C power strip, highlighting its magnetic base and flat plug design.



Image 2.2: The 45-degree flat plug allows the power strip to be used in tight spaces, such as behind furniture, without protruding.

3. Safety Instructions

To prevent electric shock, fire, or injury, always follow these basic safety precautions:

- Do not exceed the maximum total power output of 1500W (125V/15A).
- Do not use in wet environments or near water.
- Do not disassemble or modify the device.
- Keep out of reach of children.
- Ensure the plug is fully inserted into the wall outlet.
- Avoid placing heavy objects on the power cord.
- If the power strip becomes hot, emits smoke, or shows any signs of damage, immediately unplug it and contact customer support.
- The built-in circuit breaker will automatically trip if an overload is detected. If this occurs, unplug some devices and press the power switch to reset.




Image 3.1: Product dimensions and key safety features, including the insulation cap and internal breaker.

4. Setup

1. **Unpack:** Carefully remove the power strip from its packaging.
2. **Placement:** Choose a suitable location for the power strip. It can be placed on a desktop, mounted on a wall, or attached to a metallic surface using its magnetic feature.
3. **Magnetic Attachment:** For magnetic mounting, simply place the back of the power strip against a clean, flat iron surface (e.g., desk leg, metal cabinet). The strong magnets will secure it in place.
4. **Wall Mounting:** If wall mounting, use appropriate screws (not included) with the keyhole slots on the back of the power strip. Ensure the mounting surface is sturdy.
5. **Plug In:** Insert the power strip's flat plug into a standard 125V AC wall outlet.



Image 4.1: The power strip securely attached to a metal desk leg using its integrated magnets.



Image 4.2: Example of the power strip mounted on a wall, providing convenient access to power and charging ports.

5. Operating Instructions

1. **Power On/Off:** Press the centralized power switch located on the power strip to turn it on or off. The indicator light will illuminate when power is supplied.

2. **AC Outlets:** Plug your electronic devices into any of the 9 AC outlets. Ensure the total power consumption does not exceed 1500W.
3. **USB Charging:**
    - **USB-C Port:** Connect your USB-C compatible devices for fast charging (up to 15W).
    - **USB-A Ports:** Connect your USB-A compatible devices for charging (up to 12W).
4. **Optimal Use:** Utilize the spaced outlets to plug in bulky adapters without blocking other ports.



Image 5.1: A hand pressing the centralized power switch to control all connected devices.



Image 5.2: The power strip simultaneously charging a laptop, smartphone, and other USB devices.



Image 5.3: Visual representation of compatible devices for USB-C (earbuds, smartwatch, smartphone, tablet) and USB-A (camera,

smartphone, game controller, mobile battery) ports.

6. Maintenance

- **Cleaning:** Disconnect the power strip from the wall outlet before cleaning. Use a dry, soft cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, unplug the power strip and store it in a cool, dry place away from direct sunlight and moisture.
- **Inspection:** Periodically inspect the power cord and plug for any signs of damage. If damage is found, discontinue use and replace the unit.

7. Troubleshooting

Problem	Possible Cause	Solution
No power to devices	Power switch is off Power strip unplugged Wall outlet not working Overload protection tripped	Press the power switch to ON Ensure the power strip is securely plugged in Test the wall outlet with another device Unplug some devices and press the power switch to reset
USB ports not charging	Device not compatible Cable is faulty Power strip is off	Ensure device is USB-C/USB-A compatible Try a different USB cable Ensure the power strip is on
Power strip feels hot	Overload Poor ventilation	Reduce the number of connected devices Ensure the power strip is in a well-ventilated area

8. Specifications

- **Model:** TS-709-C
- **AC Outlets:** 9
- **USB-C Output:** 1 port, 5V/3A (15W Max)
- **USB-A Output:** 2 ports, 5V/2.4A (12W Max)
- **AC Input/Output:** 125V~, 15A, 60Hz, 1500W Max
- **Cable Length:** 2 meters
- **Material:** ABS 94V0 Flame-Retardant
- **Dimensions:** Approximately 18.8 x 5.2 x 3.7 cm (L x W x H)
- **Weight:** Approximately 400g
- **Color:** Grey

9. Warranty and Support

TESSAN products come with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your purchase or visit the official TESSAN website.

If you encounter any issues or have questions regarding your TESSAN TS-709-C power strip, please contact our customer support team:

- **Email:** support@tessan.com
- **Website:** www.tessan.com

Please have your model number (TS-709-C) and purchase information ready when contacting support.

© 2025 Dongguan E-Chief Electronic Technologies Co.,Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZBYLZWT

More documents and user manuals: **https://manuals.plus/**