



Manuals.plus /

› Aeitto /

› Aeitto Nugget Ice Maker Countertop Instruction Manual

Aeitto CB24M-D

Aeitto Nugget Ice Maker Instruction Manual

Model: CB24M-D

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before operating the appliance. Retain this manual for future reference.

- Ensure the ice maker is placed on a stable, level surface away from direct sunlight and heat sources.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the ice maker before cleaning or when not in use for extended periods.
- Keep children and pets away from the ice maker during operation.
- Use only potable water in the water reservoir.
- Do not operate the appliance with a damaged cord or plug.
- This appliance is for household use only.

PRODUCT OVERVIEW

The Aeitto Nugget Ice Maker is designed to produce soft, chewable nugget ice quickly and efficiently for home, kitchen, or office use. It features a one-click operation and an automatic self-cleaning function.



Figure 1: Aeitto Nugget Ice Maker with ice bucket and a refreshing drink.

Components:

- Ice Maker Unit
- Ice Basket
- Ice Scoop
- Drip Tray
- Drain Hose (for water discharge)

3 Steps to Get Nugget Ice

No more waiting

STEP 1

Add Water



STEP 2

Press "ICE"



STEP 3

Enjoy Nugget Ice



Figure 2: Product dimensions and included accessories: ice scoop, ice basket, and drip tray.

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove the ice maker and all accessories from the packaging. Inspect for any damage.
2. **Placement:** Place the ice maker on a flat, stable surface. Ensure there is adequate ventilation around the unit (at least 4 inches of space on all sides).
3. **Cleaning Before First Use:**

- Wash the ice basket and ice scoop with warm, soapy water. Rinse thoroughly.
- Wipe the exterior of the unit with a soft, damp cloth.
- Perform a self-cleaning cycle as described in the "Maintenance" section.

4. **Power Connection:** Plug the ice maker into a grounded electrical outlet.

OPERATING INSTRUCTIONS

Making Ice:

1. **Add Water:** Open the top lid and fill the water reservoir with potable water up to the MAX fill line.

HIGHER DAILY OUTPUT
First Round of Ice Making 5 Mins

40 LBS

5000+
ICE CUBES
PER DAY

144+
CUPS PER
DAY

Aertto

Figure 3: Adding water to the ice maker.

2. **Insert Ice Basket:** Place the clean ice basket into its designated position inside the unit.
3. **Start Ice Production:** Press the "ICE" button on the control panel. The indicator light will illuminate. The ice maker will begin producing nugget ice within approximately 5 minutes.



Figure 4: Pressing the "ICE" button to start ice production.

4. **Ice Full Indicator:** The "ICE FULL" indicator light will illuminate when the ice basket is full, and the ice production will automatically pause. Remove ice to resume production.
5. **Add Water Indicator:** The "ADD WATER" indicator light will illuminate when the water reservoir is low, and the ice production will pause. Refill the reservoir to resume.

6. **Enjoy Ice:** Use the provided ice scoop to retrieve the nugget ice.

**WHY
NUGGET
ICE ?**

- ✓ Chewable
- ✓ Protect Teeth
- ✓ Absorb Flavor
- ✓ Quick Cooling

Figure 5: Nugget ice ready for use.

Video Demonstration:

Your browser does not support the video tag.

Video 1: A comprehensive guide to setting up and operating the Aeitto Nugget Ice Maker, demonstrating water addition, ice production, and ice retrieval. This video is provided by the seller.

MAINTENANCE

Automatic Self-Cleaning:

The ice maker features an automatic self-cleaning function to maintain hygiene and performance.

1. Ensure the water reservoir is filled with clean water.
2. Press the "CLEAN" button on the control panel. The unit will initiate a cleaning cycle that typically lasts about 15 minutes.



Figure 6: Visual representation of the automatic cleaning cycle.

3. After the cleaning cycle, drain the water from the unit using the drain pipe.

Draining Water:

To drain water from the unit, locate the drain pipe at the back of the ice maker. Remove the plug and allow the water to flow into a sink or container.



Figure 7: Illustration of the unique water outlet design for easy draining.


Descaling:

Regular descaling is important, especially in hard water areas, to prevent mineral buildup and maintain ice quality.

- Descale monthly in moderately hard water areas.
- Descale every two or three weeks in hard to very hard water areas.

Hard Water Can Affect Your Ice Maker

Descale it once a month, or more often if you live in a hard water area



Descale monthly
in moderately hard water areas



Descale every two or three weeks
in hard to very hard water areas

Concentration of calcium carbonate in the water :



Slightly Hard **1-60mg/L**



Moderately Hard **61-120mg/L**



Hard **121-180mg/L**



Very Hard **181-250mg/L**

Figure 8: Water hardness map and recommended descaling frequency.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir.	Fill water reservoir.
Ice production is slow.	Mineral buildup.	Perform descaling.
"ICE FULL" light is on, but basket is not full.	Ice sensor obstructed or dirty.	Clean the ice sensor.
Unusual noise during operation.	Unit not level or internal component issue.	Ensure unit is on a level surface. If noise persists, contact customer support.

SPECIFICATIONS

- **Model:** CB24M-D
- **Product Dimensions:** 12.99"D x 7.28"W x 12.79"H
- **Weight:** 19.4 Pounds
- **Ice Production Capacity:** Up to 40 lbs per day
- **Water Tank Capacity:** 1 Liter
- **Voltage:** 120 Volts
- **Wattage:** 110 watts
- **Ice Type:** Nugget (Chewable)

WARRANTY AND SUPPORT

Aeitto provides 2-years technical support for this ice machine. If you have any questions, concerns, or require assistance, please reach out to Aeitto customer support.

For further assistance, please visit the official Aeitto Store: [Aeitto Store on Amazon](#)



Figure 9: Aeito customer support information.